The Filtration Solution... whatever your business!

FERRAFILTER®

Kubota



ISO/TS 16949
ISO 9001
ISO 14001
OHSAS 18001
BUREAU VERITAS
Certification

EAC TSE

www.ferrafilter.com

V.23-01

FERRAFILTER®

Kubota

CROSS LIST

OR. NO	FERRA NO
11249911210	FSO 67/6
15 741-1108-0	FA 1426 M
15000-37101	FA 1629 MK
1500037111	FA 725 S
15056-32432	FSO 99/9
15104-11080	FA 1326 MK
1521132431	FSO 914/28
15221-1122-0	FA 1018 K
15221-1122-0	FA 1018 MK
15221-1122-3	FA 1018 K
15221-1122-3	FA 1018 MK
15221-1122-4	FA 1018 K
15221-1122-4	FA 1018 MK
15221-11221	FA 1018 K
15221-11221	FA 1018 MK
15221-1123-0	FA 1018 K
15221-1123-0	FA 1018 MK
15221-4308-0	FSF 77
15221-4308-1	FSF 77
15221-4317-0	FSF 77
15221-43170	FSF 77
1522111080	FA 1326 MK
1522143160	FEF 58/1
15221431600	FEF 58/1
15222-1122-0	FA 1018 K
15222-1122-0	FA 1018 MK
15222-1122-1	FA 1018 K
15222-1122-1	FA 1018 MK
15222-1122-3	FA 1018 K
15222-1122-3	FA 1018 MK
15222-11222	FA 1018 K
15222-11222	FA 1018 MK
15222-11224	FA 1018 K
15222-11224	FA 1018 MK
15222-11225	FA 1018 K
15222-11225	FA 1018 MK
1522443010	FSF 77
15227-11221	FA 1018 K
15227-11221	FA 1018 MK
15227-87481	FA 1018 K
15227-87481	FA 1018 MK
15231-4356-0	FEF 28
15231-4356-3	FEF 28
15231-43561	FEF 28
15231-43562	FEF 28
1523143160	FEF 28
15232-43160	FEF 28
15241-1101-7	FA 1018 K
15241-1101-7	FA 1018 MK
15241-3209-0	FSO 89
15241-3209-2	FSO 87
15241-3209-3	FSO 87
15241-32094	FSO 87

OR. NO	FERRA NO
15241-32099	FSO 87
15241-39092	FSO 87
1524132040	FSO 87
1524132091	FSO 87
15272-1122-1	FA 1018 K
15272-1122-1	FA 1018 MK
15272-1122-2	FA 1018 K
15272-1122-2	FA 1018 MK
15272-11220	FA 1018 K
15272-11220	FA 1018 MK
15284-87211	FSO 99/6
15287-11081	FA 1326 MK
15287-1149-1	FA 1326 MK
1528711080	FA 1326 MK
15291-43010	FEF 37 T
15291-43012	FEF 37 T
15319-11220	FA 1018 K
15319-11220	FA 1018 MK
15319-11221	FA 1018 K
15319-11221	FA 1018 MK
15321-11011	FA 1018 K
15321-11011	FA 1018 MK
15321-11221	FA 1018 K
15321-11221	FA 1018 MK
15321-4356-0	FEF 28
15321-4656-3	FEF 28
1532146563	FEF 28
15328-11221	FA 1018 K
15328-11221	FA 1018 MK
15372-8721-2	FSO 87
15401-1108-1	FA 1326 MK
15401-11080	FA 1326 MK
1540111082	FA 1326 MK
15402-32090	FSO 99/6
15402-32091	FSO 99/6
15402-32430	FSO 914/28
1542132090	FSO 87
1542132093	FSO 87
15451-4356-0	FSF 87/1
1545111080	FA 1916/1 MK
15501-11080	FA 1018 K
15501-11080	FA 1018 MK
15501-11081	FA 1018 K
15501-11081	FA 1018 MK
1550111220	FA 1018 K
1550111220	FA 1018 MK
15521-1108-0	FA 1326 MK
15521-3243-1	FSO 99/6
15521-4316-0	FEF 58/1
15521-43160	FEF 58/1
1552132430	FSO 99/6
1552143080	FSF 77
155214316	FEF 58/1

OR. NO	FERRA NO
1552143760	FEF 58/1
15562-11080	FA 1018 K
15562-11080	FA 1018 MK
15581-11081	FA 1326 MK
15606-11080	FA 1629 MK
15606-11081	FA 1629 MK
15606-11211	FA 1629 MK
1560611221	FA 1629 MK
15612-11180	FA 725 S
15741-11083	FA 1426 M
1574111081	FA 1426 M
15763-11081	FA 1629 MK
15831-43380	FEF 37 T
15831-43381	FEF 37 T
15841-3243-0	FSO 87
15841-32431	FSO 89
15841-32432	FSO 89
15841-32439	FSO 89
15852-11220	FA 1018 K
15852-11220	FA 1018 MK
15853-32430	FSO 66/1
15853-9917-0	FSO 67/1
15853-99179	FSO 66/1
1585332439	FSO 66/1
16098-31291	FSO 99/9
16231-43563	FEF 28
16271-3209-2	FSO 89
16271-32093	FSO 89
16271-43560	FEF 38
16631-43560	FSF 811/4
1665911221	FAR 918 M
17321-3243-0	FSO 99/6
17321-3243-1	FSO 99/6
1732511080	FA 1326 MK
1738111181	FA 725 S
1754111081	FA 1426 M
17904-0130	FA 1018 K
17904-0130	FA 1018 MK
1865911221	FAR 918 M
19237-87481	FA 1326 MK
19404-11081	FA 1326 MK
19404-3243-0	FSO 99/6
19404-3243-1	FSO 99/6
19433-11080	FA 1629 MK
19433-11081	FA 1629 MK
19478-1108-0	FA 1326 MK
1A001-43160	FEF 58/1
1C010-3243-0	FSO 99/9
1C020-3243-0	FSO 99/9
1G311-43380	FEF 37 T
1G65911221	FAR 918 M
1G65911222	FAR 918 M
1G772-43560	FSF 811/4

OR. NO	FERRA NO
1J521-43170	FSF 912
1T021-43560	FEF 28
271000000000	FSO 87
30401-37580	FSO 87
30401-37581	FSO 87
32 701-3795-0	FSO 913/1 H
3259038381	FSO 917/31 H
32721-58240	FAR 416 TS
32721-58242	FAR 416 TS
33960-38380	FSO 917/31 H
33960-82630	FSO 917/31 H
33960-82631	FSO 917/31 H
3396082632	FSO 917/31 H
3808721000	FSO 87
3A111-19130	FAR 831 S
3A431-82623	FSO 910/13 H
3A431-82630	FSO 910/13 H
3A431-82632	FSO 910/13 H
3J028-08961	FSO 924 HMT
4025156400	FA 1326 MK
4137894	FSO 87
5185211080	FA 1018 K
5185211080	FA 1018 MK
51852110801	FA 1018 K
51852110801	FA 1018 MK
5185211081	FA 1018 K
5185211081	FA 1018 MK
52200-15320	FSO 917/26 H
5471123410	FSF 77
55231-26150	FAR 933 S
59700-26112	FAR 1635 M
59800-26110	FAR 1432 M
66021-3606-0	FSO 810
6760958210	FA 1018 K
6760958210	FA 1018 MK
67800-58300	FA 1018 K
67800-58300	FA 1018 MK
67841-58300	FA 1018 K
67841-58300	FA 1018 MK
67955-37710	FSO 812 H
6816143610	FA 1018 K
6816143610	FA 1018 MK
68335-43620	FA 725 S
6833543621	FA 725 S
6A100-82630	FAR 917/2 M
6A100-82632	FAR 917/2 M
6A320-59930	FEF 45/1
6C060-99410	FAR 917/2 M
6C6099410	FAR 917/2 M
70000-1108-1	FA 1326 MK
70000-11080	FA 1629 MK
70000-11221	FA 1018 K
70000-11221	FA 1018 MK

OR. NO	FERRA NO
70000-14500	FA 1629 MK
70000-14555	FA 1629 MK
70000-14556	FA 1326 MK
70000-14557	FA 1018 K
70000-14557	FA 1018 MK
70000-14632	FSF 87/1
70000-14647	FSO 914/28
70000-14650	FSO 87
70000-14652	FSO 1017/6
70000-14655	FA 1629 MK
70000-14656	FA 1326 MK
70000-14657	FA 1018 K
70000-14657	FA 1018 MK
70000-17500	FA 1916/1 MK
70000-32050	FSO 87
70000-3209-1	FSO 99/6
70000-37500	FSF 87/1
70000-43080	FSF 77
70000-43081	FSF 77
70000-57500	FSO 1013/2
70000-74034	FSO 87
72000-0052-5	FAR 417 S
7665025430	FSO 87
7665025431	FSO 87
87300-044	FSO 917/31 H
E1100780	FAR 917/2 M
HH150-32090	FSO 87
HH150-32094	FSO 87
HH150-32430	FSO 66/1
HH152-32432	FSO 89
HH160-32093	FSO 89
HH160-32430	FSO 1017/6
HH166-43560	FSF 811/4
HH1C0-32430	FSO 99/9
HH1CO-32430	FSO 99/9
HH1G0-43560	FSF 811/4
HH1J0-43170	FSF 912
HH330-82630	FSO 917/31 H
HH3A0-82623	FSO 910/13 H
HH3A0-82630	FSO 910/13 H
HH520-15320	FSO 917/26 H
HH660-36060	FSO 810
HH670-37710	FSO 812 H
HHTA0-37710	FSO 917/31 H
HHTAO-37710	FSO 917/31 H
HHTAO37710	FSO 917/31 H
HHV0051920	FSF 914/6
HWTAT-93230	FAR 1027/1 M
K1211-82320	FAR 918 M
K121182321	FAR 918 M
K2581-82311	FAR 918 M
K3181-82240	FAR 1125
K3181-82241	FAR 1125

OR. NO	FERRA NO
K3181-82250	FAR 523 S
K3181-82251	FAR 523 S
K5606-11081	FA 1629 MK
K7311-82390	FAR 917/2 M
K7561-82360	FAR 417 S
R1401-42270	FAR 1230 M
R140142280	FAR 1230 M
R1411-63860	FSO 913/1 H
R1411-64930	FEO 48 H
R141164930	FEO 48 H
R2401-42280	FAR 830 S
R240142281	FAR 830 S
R551142250	FAR 830 S
R551142270	FAR 1230 M
R561142250	FAR 831 S
R561142270	FAR 1432 M
RD452-42270	FAR 1230 M
RD452-42280	FAR 830 S
RD45242271	FAR 1230 M
RD45242281	FAR 830 S
RG108-23410	FSB 815
RG158-42920	FAR 417 S
RG158-42930	FAR 918 M
T0070-37711	FSO 917/31 H
T007037710	FSO 917/31 H
T007037711	FSO 917/31 H
TA040-37710	FSO 917/31 H
TA040-93220	FAR 626 MS
TA040-93230	FAR 1027/1 M
TA04093231	FAR 1027/1 M
TD270-63221	FAR 630 S
TD270-93220	FAR 630 S
TD270-93221	FAR 630 S
TD270-93230	FAR 1232
V062151920	FSF 914/6
W21ES-O1530	FSO 89
W21ES01C00	FSO 99/9
W21ESF1660	FSF 811/4
W21ESF1G00	FSF 811/4
W21ESO1C00	FSO 99/9
W21TS-H3300	FSO 917/31 H
W21TSH3300	FSO 917/31 H
W21TSH3A00	FSO 910/13 H
W21TSH3A10	FSO 910/13 H
W21TSH6700	FSO 812 H
W9501-15001	FSO 812 H

->							
->	->	->(->)				FEF 45/1	
B-1000-Serie							
B 1902	->	142(->)	01/82 -> 01/88		FSO 910/5		
B-2000-Serie							
B 2201	->	->(->)			FSO 910/5		
B-Serie							
B 20	D950-A-T	14.9(->)	01/90 -> 01/98			FEF 28	
L2800DTF	->	->(->)	->			FEF 28	
B-Series							
B 2050 / D-F	Kubota D 1105 E-TVCS	15(20)		FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 89		
B01-Series							
B 2301 / HSD	Kubota D 1005 E-TVCS	16(22)	-> 2018	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 87		
B 2601 / HSD	Kubota D 1005 E-TVCS	19(26)	-> 2018	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 87		
B02-Series							
B 1702	Kubota D 950	13(17)	1982 -> 1988	FA 1018 K	FSO 66/1		
				FA 1018 MK	FSO 87		
B 1902	Kubota D 1102	14(19)	1982 -> 1988	FA 1018 K	FSO 87		
				FA 1018 MK	FSO 89		
B1-Series							
B 1121 D / D-EC	Kubota Z 482 E-TVCS	8(11)	2018 ->	FAR 917/2 M	FSO 89		
				FAR 918 M	FSO 89		
B 1161 / D-EC	Kubota D 722 E-TVCS	11(15)	2018 ->	FAR 917/2 M	FSO 89		
				FAR 918 M	FSO 89		
B 1181 / DT-EC	Kubota D 782 E-TVCS	13(18)	2018 ->	FAR 917/2 M	FSO 89		
				FAR 918 M	FSO 89		
B 1241 / D-EC	Kubota D 1005 E-TVCS	16(22)	2018 ->	FAR 416 TS	FSO 89		
				FAR 917/2 M	FSO 89		
B 1700 / D / F	Kubota D905-D10	13(17)	1995 -> 1999	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 87		
B10-Series							
B 1410	Kubota D905 E-BX	10(13)	1998 -> 2008	FAR 917/2 M	FSO 66/1		
				FAR 918 M	FSO 87		
B 1410 D	Kubota D662	10(14)	1999 -> 2008	FAR 917/2 M	FSO 89		
				FAR 918 M	FSO 89		
B 1610 / D	Kubota D905 E-BX	11(15)	1998 -> 2008	FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 89		
B 1610 D	Kubota D722	12(16)		FAR 416 TS	FSO 89		
				FAR 917/2 M	FSO 89		
B 1710	Kubota D 905 E-BX	12(16)	2000 -> 2007	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 89		
B 2110 / H / D / DB / DS / HDB / HDI	Kubota D1105-D18	14(19)	1995 -> 2007	FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
B 2210 D	Kubota D 1105-D18	13(17)	2000 -> 2007	FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 66/1		
B 2410 /D/DB/HDB/H/HSE/HSD/HSI	Kubota D1105-D18	18(24)	2000 -> 2005	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 87		
B 2710 / H / HSD / HDB	Kubota V1305-E-D12	20(27)	2000 -> 2005	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 89		









B1000-Serie							
B 1550 D	D850-5B	13(17)	01/88 ->			FEF 28	
B 1550 E	D850-5B	13(17)	01/88 ->			FEF 28	
B 1550 HST-D/-E	D850-5B	12(16)	01/88 ->			FEF 28	
B 1700	D 905	13(17)	01/95 -> 01/99			FEF 28	
B 1700 DT/E	D905-D10 PN1G035-00001	13(17)	01/95 -> 01/99			FEF 28	
B 1700 HST-D	D905-D10 PN1G035-00001	12(16)	01/95 -> 01/99			FEF 28	
B 1750 E/D	D950-5B	15(20)	01/88 ->			FEF 28	
B 1750 HST-D/-E	D950-5B	->(->)	01/88 ->			FEF 28	
B1000-Serie (Tarım Makinaları)							
B1700DT	D905-D10	->(->)					FSO 812 H
B1700E	D905-D10	->(->)					FSO 812 H
B1700HST	D905-D10	->(->)					FSO 812 H
B1000-Series							
B 1200	Kubota D 750 L	12(16)	1999 ->	FA 1018 K	FSO 89		
				FA 1018 MK	FSO 89		
B 1400	Kubota D 850 L	14(19)	1999 ->		FSO 89		
B 1402	Kubota D 850 L	14(19)	1982 -> 1988	FA 1018 K	FSO 89		
				FA 1018 MK	FSO 89		
B 1502	Kubota D 850	11(15)	1982 -> 1988	FA 1018 K	FSO 89		
				FA 1018 MK	FSO 89		
B 1550 D/E/ HST-D / -E	Kubota D 850-5B	13(17)	1988 -> 1997		FSO 810		
					FSO 87		
B 1600	Kubota D 950	16(22)	-> 1998		FSO 89		
B 1700 /DT / E / HST-D	Kubota D950-D10	13(17)	1995 -> 1999	FAR 917/2 M	FSO 810		
				FAR 918 M	FSO 87		
B 1710 D	Kubota D 905-D18	13(17)	2000 -> 2007	FAR 917/2 M	FSO 87		
				FAR 918 M	FSO 89		
B 1750 E / D / HST-D / -E	Kubota D950-5B	15(20)	1988 ->		FSO 66/1		
					FSO 810		
B2-Series							
B 2201	Kubota D 1105 E-TVCS	14(19)	2018 ->		FSO 87		
					FSO 89		
B 2231 DB / HC / HDB-C	Kubota D 1105 E-TVCS	15(21)	2018 ->	FAR 416 TS			
				FAR 917/2 M			
B 2261 DB / HDB / HDB-C	Kubota D 1305 E-TVCS	18(24)	2018 ->	FAR 416 TS			
				FAR 917/2 M			
B 2311 HDB / HDB-C	Kubota V1505 E-TVCS	21(28)	2018 ->	FAR 416 TS	FSO 89		
				FAR 917/2 M	FSO 89		
B20-Series							
B 1220 / D	Kubota Z 482 E-TVCS	9(12)	2009 -> 2017	FAR 917/2 M	FSO 66/1		
				FAR 918 M	FSO 89		
B 1620 / D / DT	Kubota D 722 E-TVCS	12(16)	2009 -> 2017	FAR 917/2 M	FSO 66/1		
				FAR 918 M	FSO 89		
B 1820 / D / DS / DST	Kubota D 782 E-TVCS	13(18)	2009 -> 2017	FAR 917/2 M	FSO 66/1		
				FAR 918 M	FSO 89		
B 2320 DT / DTN / DWO / HSD	Kubota D 1005-E-3D22	17(23)	2008 -> 2015	FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 87		
B 2420 / D-F / M	Kubota D 1105 E-TVCS	18(24)	2009 -> 2013	FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
B 2601 HSD	Kubota D 1005-E4-D32	16(22)		FAR 416 TS	FSO 810		
				FAR 416 TS	FSO 87		









B20-Series							
B 2620 HSD	Kubota D 1105-E3-D22	19(26)	2008 -> 2015	FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
B2000-Serie							
B 2100 DT	D1005-D10 PN1G036-20001	15(20)	01/95 -> 01/99			FEF 28	
B 2100 HST-D	D1005-D10 PN1G036-20001	->(->)	01/95 -> 01/99			FEF 28	
B 2100 HST-DB	D1005-D10	->(->)	01/95 -> 01/99			FEF 28	
B 2150 DT	V1200-5B	18(24)	01/90 ->			FEF 28	
B 2150 E	V1200-5B	18(24)	01/90 ->			FEF 28	
B 2150 HSE / HSD	V1200-5B	17(23)	01/90 ->			FEF 28	
B 2400	D 1105-D10	16(22)	01/95 -> 01/99			FEF 28	
B 2400 HST-D	D1105-D10 PN1G037-20001	->(->)	01/95 -> 01/01			FEF 28	
B 2400 HST-E	D1105-D10 PN1G037-20001	->(->)	01/95 -> 01/01			FEF 28	
B2000-Serie (Tarım Makinaları)							
B2100	D1005D10	->(->)					FSO 812 H
B2100DT	D1005D10	->(->)					FSO 812 H
B2400DT	D1105D10	->(->)					FSO 812 H
B2400HSTD	D1105D10	->(->)					FSO 812 H
B2410HSD	D1105	->(->)					FSO 812 H
B2710HSD	V1305	->(->)					FSO 812 H
B2910HSD	V1505E	->(->)					FSO 812 H
B2000-Series							
B 2100 / D / DT / H	Kubota D1005-D10	16(22)	1995 -> 1999	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 87		
B 2150 DT / E / HSE / HSD	Kubota V1200-5B	18(24)	1988 -> 1996	FA 1426 M	FSO 66/1		FSO 913/1 H
				FA 1426 M	FSO 87		FSO 913/1 H
B 2400 / HD / HST-D / HST-E	Kubota D 1105-D10	18(24)	1995 -> 1999	FAR 917/2 M	FSO 66/1		
				FAR 918 M	FSO 810		
B 2910 HSD	Kubota V1505-E-D16	22(30)	1998 -> 2005	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 89		
B 2920 HSD	Kubota D 1305 E3-D22	20(27)	2008 ->	FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
B30-Series							
B 1830 / D	Kubota D 905 E-TVCS	13(18)	2007 -> 2013	FAR 917/2 M	FSO 87		
				FAR 918 M	FSO 87		
B 2230 /D/DC/H/HC/HDB/HDBC	Kubota D 1005	16(22)		FAR 917/2 M	FSO 87		
				FAR 918 M	FSO 87		
B 2530 / C / D / DC / HDB / HDBC	Kubota D 1105 E-TVCS	18(25)	2010 ->	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 87		
B 2630 HSD	Kubota D 1105-E2-D21	19(26)	2006 -> 2012	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 87		
B 3030 H / HC / HDB / HDB-C	Kubota V1505 E-TVCS	22(30)	2006 -> 2012	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 89		
B3000-Series							
B 3000 HSDC / HSDCC	Kubota V1505 E3-D21-Q	22(30)	2011 ->	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 810		
B 3030 HSD / HSDC	Kubota V1505-E2-D21	22(30)	2007 ->	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 810		
B 3200 HSD	Kubota V1505-E3-D24	24(32)	2008 -> 2015	FAR 917/2 M	FSO 810		
				FAR 918 M	FSO 89		
B 3300 SU	Kubota V1505-E3-D24H	24(32)	2008 ->	FAR 917/2 M	FSO 810		
				FAR 918 M	FSO 89		









B4000-Serie							
B 4200 D	Z600-A	->(->)	->			FEF 28	
B4000-Series							
B 4200 D	Kubota Z600-A	10(13)	1987 -> 1996	FA 1018 K	FSO 810		
				FA 1018 MK	FSO 87		
B50-Series							
B 2050 / D / -F	Kubota D 1105 E-TVCS	15(20)	2014 ->	FAR 416 TS			
				FAR 917/2 M			
B 2350 /DB/DB-F/HC/HDB/HDB-C/H	Kubota D 1105 E-TVCS	17(23)	2014 ->	FAR 416 TS			
				FAR 917/2 M			
B 2650 / H / C / DB-F / HDB-C / HDE	Kubota D 1305 E-TVCS	19(26)		FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 87		
B 2650 HSD / C	Kubota D 1305-E4-D26Q	19(26)	2013 ->		FSO 810		
					FSO 87		
B 3150 / H / HC / HDB-C / HDB-F	Kubota V1505 E-TVCS	23(31)	2014 -> 2018	FAR 416 TS	FSO 89		
				FAR 917/2 M	FSO 89		
B 3350 HSD / HSDC	Kubota V1505-E4-D26-Q	25(33)	2013 ->		FSO 810		
					FSO 89		
B 3350 SUHSD	Kubota V1505-E4-D26-Q	25(33)	2013 ->		FSO 810		
					FSO 89		
B5000-Serie							
B 5100	Kubota	10(13)	01/73 -> 12/77			FEF 28	
B 5100 D/E	Z500-B	->(->)	->			FEF 28	
B 5200	Kubota	10(13)	01/83 -> 12/96			FEF 28	
B 5200 D/E	D750	10(13)	01/83 ->			FEF 28	
B5000-Series							
B 5000	Kubota Z500	7(9)	1973 -> 1977	FA 1018 K	FSO 87		
				FA 1018 MK	FSO 87		
B 5001	Kubota Z500	7(9)	1976 -> 1979	FA 1018 K	FSO 87		
				FA 1018 MK	FSO 87		
B 5100 / DT / E	Kubota Z500-1A / -B	10(13)	1973 -> 1977	FA 1018 K	FSO 66/1		
				FA 1018 MK	FSO 87		
B 5200 / D / E	Kubota D750	10(13)	1983 -> 1996	FA 1018 K	FSO 66/1		
				FA 1018 MK	FSO 87		
B6000-Serie							
B 6000	Kubota ZL600	10(13)	01/73 -> 12/77			FEF 28	
B 6000 E	ZL600	9(12)	01/74 ->			FEF 28	
B 6100 D	D650-B	->(->)	->			FEF 28	
B 6100 E	Kubota D650-B	10(14)	01/78 ->			FEF 28	
B 6100 HST-DT/HST-E	D650-B	->(->)	->			FEF 28	
B 6200	Kubota	11(15)	01/83 -> 12/84			FEF 28	
B 6200 D/E	D850-5B	11(15)	01/83 ->			FEF 28	
B 6200 HST-D/HST-E	D850-5B	->(->)	01/83 -> 01/92			FEF 28	
B6000-Series							
B 6000 / E	Kubota ZL600	10(13)	1973 -> 1977		FSO 87		
B 6001	Kubota D650	10(14)	1976 -> 1984	FA 1018 K	FSO 66/1		
				FA 1018 MK	FSO 87		
B 6100 / D / E / HST-DT / HST-E	Kubota D650-A / -B	10(14)	1978 -> 1984	FA 1018 K	FSO 66/1		
				FA 1018 MK	FSO 810		
B 6200 / D / E / HST-D / HST-E	Kubota D850-5B	11(15)	1983 -> 1992	FA 1018 K	FSO 810		
				FA 1018 MK	FSO 87		









B7000-Serie							
B 7100	Kubota D750-B	12(16)	01/77 -> 12/84			FEF 28	
B 7100 HST-DT/HST-E	D750-B	->(->)	->			FEF 28	
B 7100 HST-II-DT	D750-B	->(->)	->			FEF 28	
B 7200 D	D950-LA	->(->)	->			FEF 28	
B 7200 E	D950	13(17)	01/83 ->			FEF 28	
B 7200 HST-D/HST-E	D950	->(->)	->			FEF 28	
B 7300 HSD	D722-D10SP PN1J007-02001	9(12)	01/97 ->			FEF 28	
B7000-Series							
B 7000	Kubota Z650	10(14)	1973 -> 1977		FSO 87		
B 7001	Kubota D750	12(16)	1976 -> 1979		FSO 66/1		
					FSO 87		
B 7100 / HST-DT / -E / HST II-DT	Kubota D750-A /-B	12(16)	1977 -> 1984	FA 1018 K	FSO 810		
				FA 1018 MK	FSO 87		
B 7200	Kubota D950	13(17)	1983 -> 1990		FSO 66/1		
					FSO 87		
B 7200 D / E	Kubota D950-LA	13(17)	1983 -> 1990	FA 1018 K	FSO 87		
				FA 1018 MK	FSO 87		
B 7200 HST-D / HST-E	Kubota D950	13(17)		FA 1018 K	FSO 810		
				FA 1018 MK	FSO 87		
B 7300 HSD	Kubota D722-D10SP	12(16)	1997 -> 1999	FAR 917/2 M	FSO 66/1		
				FAR 918 M	FSO 810		
B 7400 HSD	Kubota D722-E-D16	12(16)	1998 -> 2003	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 810		
B 7410 DT	Kubota D782-E2-D20	13(18)	2004 -> 2007	FAR 416 TS			
				FAR 917/2 M			
B 7500 / DT /HSD	Kubota D1005-E-D16	15(21)	2000 -> 2003	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 810		
B 7510 HSD / DT / DTN	Kubota D1005-E2-D16	15(21)	2004 -> 2007	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 810		
B 7610 HSD	Kubota D1005-E-D16	18(24)	2004 -> 2007	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 87		
B 7800 HSD	Kubota V1505-E-D16	22(30)	2003 -> 2008	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 810		
B8000-Serie							
B 8200	Kubota	14(19)	01/83 -> 12/90			FEF 28	
B 8200 D	D950A-DT-M	->(->)	->			FEF 28	
B 8200 E	D950A-DT-M	14(19)	01/81 ->			FEF 28	
B 8200 HST-D	D950A-DT-M	->(->)	->			FEF 28	
B 8200 HST-E	D950-A	->(->)	->			FEF 28	
B8000-Series							
B 8100	->				FSO 66/1		
					FSO 87		
B 8200 / D / E / HST / HST-D / HST-	Kubota D950-A-DT-M	14(19)	1983 -> 1990	FA 1018 K	FSO 87		FSO 913/1 H
				FA 1018 MK	FSO 87		FSO 913/1 H
B9000-Serie							
B 9200 D	V1200-A	->(->)	->			FEF 28	
B 9200 E	V1200-A	16(22)	01/87 ->			FEF 28	
B 9200 HSD-TOW	V1200-A	->(->)	->			FEF 28	
B 9200 HST-D / HST-E	V1200-A	16(22)	01/87 ->			FEF 28	
B9000-Series							
B 9200 D / E / HSD-TOW / HST-D /	Kubota V1200-A	17(23)	1986 -> 1990	FA 1426 M	FSO 87		FSO 913/1 H









Bulltra-Series							
B1-10	->	8(10)	1985 -> 1992		FSO 87		
					FSO 89		
B1-14	D 850	-17		FA 1018 K	FSO 87		
				FA 1018 MK	FSO 89		
B1-15	D 850	-17		FA 1018 K	FSO 87		
				FA 1018 MK	FSO 89		
B1-16	D 950	16(21)		FA 1018 K	FSO 87		
				FA 1018 MK	FSO 89		
B1-17	D 950	16(21)		FA 1018 K	FSO 87		
				FA 1018 MK	FSO 89		
BX-50 Series							
2350	Kubota D902	17(23)	2006 -> 2008	FAR 918 M	FSO 89		
BX-60 Series							
2360	Kubota D902-E2	17(23)	2006 -> 2008		FSO 66/1		
2360	Kubota D902-E2	17(23)	2009 -> 2013	FAR 918 M			
BX-70 Series							
1870 / 1870-1	Kubota D722	13(18)	2013 -> 2014	FAR 417 S	FSO 66/1		
				FAR 918 M	FSO 66/1		
2370 / 2370-I	Kubota D902	17(23)	2013 -> 2014	FAR 417 S	FSO 66/1		
				FAR 918 M	FSO 66/1		
2670 / 2670-1	Kubota D1005	19(26)	2013 -> 2014	FAR 417 S	FSO 87		
				FAR 918 M	FSO 87		
BX-80 Series							
1880	Kubota D722	13(18)	2017 ->	FAR 417 S	FSO 66/1		
				FAR 918 M	FSO 66/1		
2380	Kubota D902	16(22)	2017 ->	FAR 417 S	FSO 66/1		
				FAR 918 M	FSO 66/1		
2680	Kubota D1005	19(25)	2017 ->		FSO 87		
BX-Series							
1800 D	Kubota D722-E-TVCS	13(18)	2001 -> 2003	FAR 918 M	FSO 66/1		
1830 D	Kubota D722-E-BX	13(18)	2004 -> 2006	FAR 918 M	FSO 66/1		
1850 D	Kubota D722	13(18)	2006 -> 2008	FAR 918 M	FSO 66/1		
1860 D	Kubota D722	13(18)	2009 -> 2013	FAR 918 M	FSO 66/1		
2200 / D / E	Kubota D905 E-TVCS	16(22)	2001 -> 2003	FAR 918 M	FSO 87		
2230 D	Kubota D902-E-2-BX2	16(22)	2004 -> 2006	FAR 918 M	FSO 66/1		
2250 D	->			FAR 918 M	FSO 66/1		
2260	->	19(26)		FAR 918 M	FSO 66/1		
231 / C / D5-C / D5-R	Kubota D902-E4-BX-3EU	17(23)	2018 ->		FSO 66/1		
261 D-C / D-R / D-R1	Kubota D1005-E4-BX-3EU	18(25)		FAR 918 M	FSO 87		
2660	Kubota D1005-E3-BX	19(26)	2008 -> 2013	FAR 918 M	FSO 66/1		
B 1500 / -48 / -54	Kubota D850-58	14(19)	1980 -> 1982	FAR 918 M	FSO 66/1		
Engine							
->	KUBOTA-V2203A	->(->)			FSO 98/1		
F-Serie/FZ-Serie							
F 2000	D950-FM	15(20)	->			FEF 28	
F 2100/E	D950-FM	15(21)	->			FEF 28	
F-Series (Lawn Tractor)							
F 1900 / E	Kubota D722	13(18)			FSO 89		
F-Series/FZ-Series (Front-mount Mower)							
F 2000	Kubota D950-FM	15(20)	1986 -> 1987		FSO 810		
					FSO 87		









F-Series/FZ-Series (Front-mount Mower)							
F 2100 / E	Kubota D950-FM	15(21)	1988 -> 1997		FSO 810		
					FSO 87		
F 2400	Kubota D1105-FM	18(24)	1988 -> 1997	FA 1018 K	FSO 810	FEF 38	
				FA 1018 MK	FSO 89	FEF 38	
F Z 2100	Kubota D905-FZ	15(20)	1992 -> 1997		FSO 810	FEF 38	
					FSO 89	FEF 38	
F Z 2400	Kubota D905-FZ	18(24)	1992 -> 1997		FSO 810	FEF 38	
					FSO 89	FEF 38	
F60-Series (Frontmäher / Front-mount mower)							
F 2260 R	Kubota D1005-E-FM	16(22)	1997 -> 2005	FAR 917/2 M	FSO 810		
				FAR 918 M	FSO 87		
F 2560 / E	Kubota D1005-E-FM	19(25)	1997 -> 2005	FAR 917/2 M	FSO 810		
				FAR 918 M	FSO 87		
F 3060 / R	Kubota V1305-FM	22(30)	1997 -> 2005		FSO 810		
					FSO 89		
F 3560	Kubota V1505-FM	18(25)	1997 -> 2006		FSO 89		
F80-Series							
F 2680 E	Kubota D1105-E3-FM-3	19(26)	2008 -> 2013	FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 810		
F 2880 / E	Kubota D1105-E2-FM-2	21(28)	2006 -> 2007	FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 810		
F 3080	Kubota D1305-E3-FM-BB	22(30)	2008 -> 2013	FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 810		
F 3680	Kubota V1505-E2-FM3	26(36)	2006 -> 2013		FSO 89		
F90-Series							
F 2690 / E	Kubota D1105-E4-FM-2	19(26)	2014 ->	FAR 416 TS	FSO 810		
				FAR 917/2 M	FSO 87		
F 2890	Kubota D1105	21(28)		FAR 917/2 M			
				FAR 918 M			
F 3090	Kubota D1305	23(31)		FAR 416 TS			
				FAR 917/2 M			
F 3890	Kubota V1505	28(38)	2014 ->		FSO 89		
F 3990	Kubota V1505-T-E4-FM	29(39)	2014 ->	FAR 1027/1 M	FSO 810		
				FAR 626 MS	FSO 87		
G-Series (Garden Tractor)							
G 1700	Kubota D662	11(15)	1989 -> 2000		FSO 89		
G 1800 / S	Kubota D662	12(16)	1989 -> 2000		FSO 66/1		
					FSO 67/1		
G 2160	Kubota D782	15(21)	2004 -> 2012	FAR 918 M	FSO 66/1		
				FAR 918 M	FSO 810		
G 2460	Kubota WG752	18(24)	2001 -> 2007	FAR 918 M	FSO 66/1		
				FAR 918 M	FSO 810		
G 3200	Kubota Z400	7(10)	1983 -> 1988		FSO 89		
G 4200 H	Kubota Z430	9(12)	1984 -> 1990		FSO 810		
					FSO 89		
G 5200 H	Kubota D600	10(14)	1984 -> 1990		FSO 810		
					FSO 89		
G-Series (Mover)							
G 18	Kubota D722-E		1999 -> 2005	FAR 918 M	FSO 89		
G 18 HD / LD	Kubota D722-E		1999 -> 2005	FAR 918 M	FSO 89		









G-Series (Mower)							
G 21 / HD / LD	->	16(21)	2004 -> 2008	FAR 918 M	FSO 89		
G 21 E-LD / E-HD	Kubota D782		2015 ->		FSO 89		
G 21 E-LD / E-HD	Kubota D782	16(22)	2015 ->	FAR 918 M			
G 23 HD	Kubota D902	17(23)	2009 -> 2019	FAR 918 M	FSO 89		
G 23 I / II / III	Kubota D902	17(23)	2009 -> 2019	FAR 918 M	FSO 89		
G 23 LD	Kubota D902	17(23)	2009 -> 2019	FAR 918 M	FSO 89		
G 26 HD	Kubota D1005	19(26)		FAR 918 M			
G 26 I / II / III	Kubota D1005	19(26)		FAR 918 M			
G 26 LD	Kubota D1005	19(26)		FAR 918 M			
G 3 HST	Kubota D600	10(14)			FSO 66/1		
G/GL/GV-Serie							
2	D600	->(->)	->			FEF 28	
2-HST	D600	->(->)	->			FEF 28	
G3200	Z400 PN77700-05535	7(10)	->			FEF 28	
G4200H	->	9(12)	->			FEF 28	
G5200H	->	10(14)	->			FEF 28	
G6200H	D640	->(->)	->			FEF 28	
G/GL/GV-Series (Garden Tractor)							
G 1900 / 1900S	Kubota D722	13(18)	1989 -> 2000		FSO 810		
					FSO 89		
G 2000	Kubota WG750-G	15(21)	1989 -> 1997		FSO 66/1		
					FSO 810		
GF-Series (Mount Tractor)							
GF 1800 / E	Kubota D722	13(18)	1994 -> 2005		FSO 66/1		
					FSO 810		
GR-Series							
1600 EC	Kubota Z482	10(14)		FAR 918 M	FSO 66/1		
				FAR 918 M	FSO 89		
1600 EC II	Kubota Z482	10(14)		FAR 918 M	FSO 66/1		
				FAR 918 M	FSO 89		
GR-Series (Lawn Tractor)							
2100	Kubota D782	15(21)	2005 -> 2007	FAR 918 M	FSO 66/1		
				FAR 918 M	FSO 810		
2100 EC / II	Kubota D782	15(21)	2008 ->	FAR 918 M	FSO 89		
2110	Kubota D782-E2-GX	15(21)	2008 -> 2009	FAR 918 M	FSO 66/1		
				FAR 918 M	FSO 810		
2120 / S	Kubota D782-E4	15(21)	2010 ->	FAR 918 M	FSO 89		
2160	Kubota D782	15(21)	2001 -> 2008	FAR 918 M	FSO 66/1		
				FAR 918 M	FSO 810		
GR-Series (Garden Tractor)							
2020 G	Kohler GH 631	15(21)	2010 ->	FAR 918 M	FSO 66/1		
GT-Series (Lawn Tractor)							
GT 950 / S	Kubota D722	13(18)			FSO 66/1		
					FSO 810		
GZD-Series (Lawn Tractor)							
GZD 15 HD / LD / 15 HD II / LD II	Kubota Z602	11(15)	2003 -> 2012	FAR 917/2 M	FSO 89		
				FAR 918 M	FSO 89		
GZD 21 HD	Kubota D782	15(21)	2004 -> 2012	FAR 917/2 M	FSO 89		
				FAR 918 M	FSO 89		
K-Series (Minibagger / Mini Excavators)							
K008	D 722	12(16)	1997 -> 2002	FAR 416 TS	FSO 89		









K-Series (Minibagger / Mini Excavators)							
K008	D 722	12(16)	1997 -> 2002	FAR 917/2 M	FSO 89		
K008 Alpha	Kubota D722BH	8(11)	2001 -> 2003	FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
K008-3	D722-EBH-3 PN1J021-00001	7(10)		FAR 416 TS	FSO 89		
				FAR 917/2 M	FSO 89		
K/KGP/KHP-Serie							
K008	D 722	12(16)	01/97 -> 01/02			FEF 28	
K008 Alpha	Kubota D722BH	7.6(->)	01/01 -> 12/03			FEF 28	
K008-3	D722-EBH-3 PN1J021-00001	7(10)	->			FEF 28	
KC-Series (Mini Dumpers)							
100HD	Kubota Z482 (EPA)	8(11)	2012 -> 2019	FAR 917/2 M	FSO 89		
110HR-4	Kubota D722	11(15)		FAR 416 TS			
				FAR 917/2 M			
250HR-4	Kubota V2203-M	33(45)	2016 -> 2019	FAR 1230 M		FEF 58/1	
				FAR 830 S		FEF 58/1	
KH (Minibagger / Mini Excavators)							
008-2, 008-3	D850BH	->(->)	->			FEF 28	
101	V1902BH	25(34)	->	FA 1629 MK			
101	V1902BH	25(34)			FSO 910/5		
11	D1302BH	->(->)			FSO 910/5		
130	->	->(->)	->	FA 1629 MK			
151	V1902-BH-4	25(34)	->	FA 1629 MK			
170L	->	35(48)	01/85 ->	FA 1629 MK			
170L	S 2600	35(48)	01/85 ->	FA 1629 MK			
18	S2200	->(->)	->	FA 1629 MK			
191	S2800D	41(56)	01/88 ->	FA 1629 MK			
20	V1902DH	->(->)			FSO 910/5		
21	Z430K1	6(8)	01/87 ->			FEF 28	
26	D1402BH4	->(->)			FSO 910/5		
27	D1402BH4	->(->)			FSO 910/5		
28	S 2600	->(->)	->	FA 1629 MK			
30	D1402BH5	->(->)			FSO 910/5		
30	Z600K2	->(->)	->			FEF 28	
31	Z600K2	->(->)	->			FEF 28	
33	V1902BH3	->(->)	->	FA 1629 MK			
33	V1902BH3	->(->)			FSO 910/5		
40	V1902BH4	->(->)	->	FA 1629 MK			
40	V1902BH4	->(->)			FSO 910/5		
45	V1902BH4	->(->)	->	FA 1629 MK			
45	V1902BH4	->(->)			FSO 910/5		
5	Z600-K1	->(->)	->			FEF 28	
55	S2800D	->(->)	->	FA 1629 MK			
60	D1302	17(23)			FSO 910/5		
60	Nissan FD33	->(->)	->	FA 1629 MK			
66	D1402BH	19(26)			FSO 910/5		
7	Z430K1	6(8.5)	->			FEF 28	
90	Isuzu 4BD1	->(->)	->	FA 1629 MK			
90	V1702	22(30)			FSO 910/5		
KH-Serie (Minibagger / Mini Excavators) (İnşaat ve Maden Makinaları)							
KH130	KUBOTA-V1902-BH2	->(->)	01/90 ->		FSO 98/1	FEF 58	
KH151	KUBOTA-V1902-BH4	->(->)	01/90 ->			FEF 58	









KH-Serie (Minibagger / Mini Excavators) (İnşaat ve Maden Makinaları)							
KH191	KUBOTA-S2800D	->(->)	01/90 ->			FEF 58	
KH60	->	->(->)			FSO 98/1		
KH65/66	KUBOTA-D1402-BH4	->(->)	01/91 ->		FSO 98/1		
KHK151	->	->(->)	01/90 ->			FEF 58	
KH-Series (Minibagger / Mini Excavators)							
001.1D	D1100BH			FA 1326 MK		FSF 77	
5	Z600-K1			FA 1018 K	FSO 87		
				FA 1018 MK	FSO 87		
7	Z430K1	6(9)			FSO 87		
8	Kubota D850BH		1987 -> 1991	FA 1018 K	FSO 87		FSO 913/1 H
				FA 1018 MK	FSO 87		FSO 913/1 H
8	Z851BH					FSF 77	
008-1	->			FA 1018 K		FSF 77	
				FA 1018 MK		FSF 77	
008-2, 008-3	Kubota D850BH			FA 1018 K	FSO 87		FSO 913/1 H
				FA 1018 MK	FSO 87		FSO 913/1 H
11	D1302BH			FA 1326 MK	FSO 99/6		
12	Z620KW			FA 1018 K	FSO 87	FSF 77	
				FA 1018 MK	FSO 87	FSF 77	
14	D1301BH			FA 1326 MK		FSF 77	
15	D1301BH			FA 1326 MK		FSF 77	
016W	D1402BH			FA 1326 MK		FSF 77	
18	S2200				FSO 914/28		
20	V1902DH			FA 1326 MK	FSO 99/6		
21	Kubota D950BH2			FA 1018 K	FSO 87	FSF 77	
				FA 1018 MK	FSO 87	FSF 77	
21	Kubota Z430K1	6(8)	1987 ->		FSO 87		
24	D950BH2			FA 1018 K	FSO 87	FSF 77	
				FA 1018 MK	FSO 87	FSF 77	
26	D1402BH4			FA 1326 MK	FSO 99/6	FSF 77	
27	D1402BH4			FA 1326 MK	FSO 99/6	FSF 77	
28	S 2600			FA 1326 MK	FSO 914/28		
30	D1402BH5			FA 1326 MK	FSO 99/6	FSF 77	
30	Z600K2			FA 1018 K	FSO 87		
				FA 1018 MK	FSO 87		
31	Z600K2			FA 1018 K	FSO 87		
				FA 1018 MK	FSO 87		
31	Z600KW3	8(11)		FA 1018 K	FSO 87	FSF 77	
				FA 1018 MK	FSO 87	FSF 77	
33	V1902BH3				FSO 99/6	FSF 77	
35	D850-BH-W	10(14)		FA 1018 K	FSO 87	FSF 77	
				FA 1018 MK	FSO 87	FSF 77	
36	Z620KW	9(12)		FA 1018 K	FSO 87	FSF 77	
				FA 1018 MK	FSO 87	FSF 77	
40	V1902BH4				FSO 99/6	FSF 77	
41	D950	12(16)		FA 1018 K	FSO 87	FSF 77	
				FA 1018 MK	FSO 87	FSF 77	
45	V1902BH4				FSO 99/6		
50	D950BH			FA 1326 MK	FSO 87	FSF 77	
51	D950BH	14(19)		FA 1326 MK	FSO 87	FSF 77	
60	D1302	17(23)		FA 1326 MK		FSF 77	









KH-Series (Minibagger / Mini Excavators)							
66	D1402BH	19(26)		FA 1326 MK	FSO 99/6	FSF 77	
90	V1702	22(30)		FA 1326 MK	FSO 914/28	FSF 77	
10 (51041)	D 1101			FA 1326 MK			
10 (51042)	->			FA 1326 MK	FSO 914/28		
10 (SN 51042 ->)	D 1101				FSO 914/28		
101	V1902BH	25(34)		FA 1326 MK	FSO 99/6	FSF 77	
151	V1902-BH-4	25(34)				FEF 58/1	
170L	S 2600	35(48)	1985 ->		FSO 914/28		
191	S2800D	41(56)	1988 ->		FSO 914/28	FEF 58/1	
61	D 950-BH - 2			FA 1018 K	FSO 87	FSF 77	
				FA 1018 MK	FSO 87	FSF 77	
91	D 1402-BH-5			FA 1326 MK		FSF 77	
KX (Minibagger / Mini Excavators)							
101	V1502B4	25(34)	01/91 ->		FSO 910/5		
101 H	V1902-BH-5	26(35)			FSO 910/5		
121-2	V2203-BH-4	->(->)	01/96 -> 12/02	FA 1629 MK			
121-2 S	V2203-EBH-4	->(->)	->	FA 1629 MK			
121-3	V2203-M-EBH	29(39)	01/02 ->		FSO 910/5		
151	V1902B4	29(40)	01/91 ->		FSO 910/5		
151 H	V1902-BH-6	->(->)			FSO 910/5		
161-2	V2203-BH-5	->(->)	->	FA 1629 MK			
161-3	V2203-M-EBH	294(39)			FSO 910/5		
161-3 R2	V2203-M-EBH-2	->(->)			FSO 910/5		
161-3 S1	V2203-M-EBH-2	->(->)			FSO 910/5		
161-3 S2	V2203-M-EBH-2	->(->)			FSO 910/5		
33	->	->(->)			FSO 910/5		
40	->	->(->)			FSO 910/5		
45	->	->(->)			FSO 910/5		
71	V1502B4	22(30)	01/91 ->		FSO 910/5		
KX-Serie (Minibagger / Mini Excavators) (İnşaat ve Maden Makinaları)							
080-3	->	->(->)		FAR 1333 M			
080-3T	->	->(->)		FAR 1333 M			
101	->	->(->)					FEO 919/3 H
101H	->	->(->)					FEO 919/3 H
121-2	->	->(->)					FEO 919/3 H
151	->	->(->)					FEO 919/3 H
151H	->	->(->)					FEO 919/3 H
161-2	->	->(->)					FEO 919/3 H
KX121-3S	KUBOTA-V2203-M-E3	->(->)			FSO 98/1		
KX161-3	KUBOTA-KUBOTA	->(->)			FSO 98/1		
KX91-3S2	KUBOTA-D1703-M-E3	->(->)			FSO 98/1		
U35	->	->(->)					FEO 919/3 H
KX-Series (Minibagger / Mini Excavators)							
008-3	->			FAR 416 TS	FSO 89		
				FAR 917/2 M	FSO 89		
016-4	Kubota D782-BH	10(13)	2011 ->	FAR 417 S	FSO 89	FSF 77	
				FAR 918 M	FSO 89	FSF 77	
018-4	KuboD902E3BH3	12(16)	2011 ->	FAR 417 S	FSO 89	FSF 77	
				FAR 918 M	FSO 89	FSF 77	
019-4	Kubota D902-BH	12(16)	2011 ->	FAR 417 S	FSO 89	FSF 77	
				FAR 918 M	FSO 89	FSF 77	









KX-Series (Minibagger / Mini Excavators)							
027-4	Kubota V1505-E4	18(24)	2017 ->		FSO 89	FSF 77	
030-4	Kubota V1505-E4	18(24)	2017 ->		FSO 89	FSF 77	
037-4	Kubota V1505-E4		2019 ->			FSF 77	
042-4	Kubota D1803-CR-TE4	29(39)	2017 ->				FEO 48 H
057-4	Kubota V2607-DI-E3	33(46)	2009 ->	FAR 1230 M	FSO 99/9	FSF 77	FEO 48 H
				FAR 830 S	FSO 99/9	FSF 77	FEO 48 H
080-3	Kubota D722BH5	7(10)	2008 ->	FAR 1432 M	FSO 99/9	FEF 37 T	FEO 48 H
				FAR 1432/1 M	FSO 99/9	FSF 811/4	FEO 48 H
080-3	V3800DIE2BH		2006 -> 2008	FAR 1432 M	FSO 99/9	FEF 37 T	FEO 48 H
				FAR 831 S	FSO 99/9	FSF 77	FEO 48 H
080-3a	Kubota V3307 DI-T	48(65)	2008 -> 2015	FAR 1432/1 M	FSO 99/9	FSF 811/4	FEO 48 H
				FAR 831 S	FSO 99/9	FSF 811/4	FEO 48 H
080-3T	V3307DT3BH			FAR 1432 M	FSO 99/9	FSF 811/4	FEO 48 H
				FAR 831 S	FSO 99/9	FSF 811/4	FEO 48 H
080-4	Kubota V3307CR-TE4	48(65)	2013 -> 2016	FAR 1432 M	FSO 99/9	FSF 914/6	FEO 48 H
				FAR 1432/1 M	FSO 99/9	FSF 914/6	FEO 48 H
080-4 Alpha (KBCK0804)	Kubota V3307-CRT-EU6	47(63)	2019 ->	FAR 1432/1 M	FSO 99/6	FSF 914/6	
				FAR 831 S	FSO 99/6	FSF 914/6	
101	V1502B4	25(34)	1991 ->		FSO 99/6	FSF 77	
101 H (SN 11313)	V1902-BH-5	26(35)			FSO 99/6	FSF 77	
101 H (SN 11314)	V1902-BH-5	26(35)			FSO 99/6	FSF 77	
101-3	Kubota D1503-M-EBH-2-EC	20(27)			FSO 99/9	FSF 77	
101-3 (>= 70001)	D1803-M				FSO 99/9		
101-3 Alpha	->				FSO 99/9	FSF 77	
101-3 Alpha (>= 70001)	Kubota D1803-M				FSO 99/9	FSF 77	
101-3 Alpha 2	Kubota D1503-M-EBH-4-EC-N	20(27)	2007 -> 2011		FSO 99/9	FSF 77	
101-3 Alpha 3	Kubota D1803-M-E3-BH-EU1	23(30)	2011 ->	FAR 1027/1 M	FSO 99/9	FSF 77	
				FAR 626 MS	FSO 99/9	FSF 77	
101-3 Alpha 3	KUBOTA D1803-M-EU36		2013 ->	FAR 1027/1 M	FSO 99/9	FSF 77	
				FAR 626 MS	FSO 99/9	FSF 77	
101-3 Alpha 4	Kubota D1803-M-E3-BH	23(31)	2014 ->	FAR 1027/1 M	FSO 99/6	FSF 77	
				FAR 626 MS	FSO 99/6	FSF 77	
121 alpha (>= 70001)	V2203-M			FAR 1230 M		FSF 77	
				FAR 830 S		FSF 77	
121-2	V2203-BH-4		1996 -> 2002	FA 725 S		FEF 37 T	
				FA 725 S		FSF 77	
121-2 S	V2203-EBH-4			FA 725 S		FSF 77	
121-3	V2203-M-EBH	29(39)	2002 ->	FAR 1230 M	FSO 99/6		
				FAR 830 S	FSO 99/6		
121-3 Alpha	Kubota V2203-M-EBH-2-N	29(39)	2005 -> 2017	FAR 1230 M		FSF 77	
				FAR 830 S		FSF 77	
121-3 R3	V2203-M-EBH-2			FAR 1230 M			
				FAR 830 S			
121-3 R4 / R4 A	->			FAR 1230 M			
121-3 R4 A	V2203-M-EBH-2			FAR 1230 M			
				FAR 830 S			
121-3 S3	V2203-M-EBH-2			FAR 1230 M			
				FAR 830 S			
121-3 S4 / S4 A	->			FAR 1230 M			
121-3 S4 A	Kubota V2203-M-EBH-2	31(41)		FAR 1230 M		FSF 77	
				FAR 830 S		FSF 77	









KX-Series (Minibagger / Mini Excavators)							
121-3S	Kubota V2203-M-E2BH-2-N			FAR 1230 M		FSF 77	
				FAR 830 S		FSF 77	
14	->				FSO 87		
151	V1902B4	29(40)	1991 ->		FSO 99/6	FSF 77	
151 H (10610)	V1902-BH-6				FSO 99/6	FSF 77	
151 H (10611)	V1902-BH-6					FSF 77	
161-2	V2203-BH-5			FA 725 S		FSF 77	
161-2S	V2203-EBH-5			FA 725 S			
				FAR 1027/1 M			
161-3	V2203-M-EBH	29(39)		FAR 1230 M	FSO 99/6		
				FAR 830 S	FSO 99/6		
161-3 Alpha	Kubota V2203M-EBH-N	29(39)	2005 -> 2011	FAR 1230 M		FSF 77	
				FAR 830 S		FSF 77	
161-3 R1	Kubota V2203-M-EBH-2		2002 ->	FAR 1230 M			
				FAR 830 S			
161-3 R2	Kubota V2203-M-EBH-2			FAR 1230 M	FSO 99/6		
				FAR 830 S	FSO 99/6		
161-3 S1	Kubota V2203-M-EBH-2			FAR 1230 M	FSO 99/6	FSF 77	
				FAR 830 S	FSO 99/6	FSF 77	
161-3 S2	Kubota V2203-M-EBH-2			FAR 1230 M	FSO 99/6	FSF 77	
				FAR 830 S	FSO 99/6	FSF 77	
161-3ST	Kubota V2403-M-E2BH-1			FAR 1230 M		FSF 77	
				FAR 830 S		FSF 77	
21	->				FSO 87		
24	->				FSO 87		
251	->			FAR 1230 M	FSO 99/9	FSF 811/4	
				FAR 830 S	FSO 99/9	FSF 811/4	
251 Alpha	V3300-B	43(58)	2002 -> 2006	FAR 1230 M	FSO 99/9	FSF 811/4	
				FAR 830 S	FSO 99/9	FSF 811/4	
251-2	V3300			FAR 1230 M	FSO 99/9	FSF 811/4	
				FAR 830 S	FSO 99/9	FSF 811/4	
26	->				FSO 87		
27	->				FSO 87		
30	->				FSO 87		
33	->				FSO 99/6		
36 (H)	->			FA 1018 K	FSO 67/1	FSF 77	
				FA 1018 MK	FSO 67/1	FSF 77	
36 / G / HG	D662B4	10(14)	1991 ->	FA 1018 K	FSO 87	FSF 77	
				FA 1018 MK	FSO 87	FSF 77	
36-2	D1105BH	13(16)	1998 -> 2003		FSO 89	FSF 77	
36-2 Alpha	D1105BH	13(18)	2002 -> 2004		FSO 89		
36-3	Kubota D782-BH	9(12)	2004 -> 2011	FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 89		
40	->				FSO 99/6		
41 / G / HG	D1105B4	15(20)	1991 ->		FSO 87	FSF 77	
41 H	D 1105-BH	16(22)			FSO 88/3	FSF 77	
					FSO 89	FSF 77	
41-2	D1105-BH-7				FSO 87	FEF 37 T	
					FSO 87	FSF 77	
41-2 Alpha	->			FAR 416 TS	FSO 87	FSB 815	
				FAR 917/2 M	FSO 87	FSB 815	









KX-Series (Minibagger / Mini Excavators)							
41-2S	D 1105-EBH -7				FSO 87	FEF 37 T	
					FSO 87	FSF 77	
41-2SV	D 1105-EBH-6	16(22)			FSO 89	FSB 815	
41-3	Kubota D 902-EBH	16(22)	2004 -> 2011	FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 89		
41-3S (>= 55001)	D782-E			FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 66/1		
41-3V (>= 55001)	D782-E			FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 66/1		
45	->				FSO 99/6		
61 (H)	->			FA 1018 K	FSO 89	FSF 77	
				FA 1018 MK	FSO 89	FSF 77	
61 / G / HG	D1105B4G	19(26)	1991 ->		FSO 87	FSF 77	
61-2	D 1105-BH6	18(24)			FSO 89	FEF 37 T	
					FSO 89	FSF 77	
61-2 Alpha	D 1105-BH9	16(22)	2001 -> 2004		FSO 89		
61-2 S	D1105-EBH-6				FSO 87	FEF 37 T	
					FSO 89	FEF 37 T	
61-3	Kubota V1505-E2-BH	18(24)	2004 -> 2017		FSO 89		
61-3KBM	->				FSO 89		
71	V1502B4	22(30)	1991 ->	FA 1426 M	FSO 99/6	FSF 77	
71 H	V 1505 - BH	24(32)		FA 1426 M	FSO 87	FSF 77	
				FA 1426 M	FSO 89	FSF 77	
71-2Alpha	D1505EB	22(30)	2001 -> 2004	FA 1326 MK	FSO 89	FSB 815	
71-3	Kubota V1505-E2-BH-10EU	20(27)	2004 -> 2017		FSO 89		
71-3 (10339)	->				FSO 89		
71-3 (10340)	V1505-E2-BH10				FSO 89	FSF 77	
71-3 KBM	V1505-E				FSO 89		
80-4a (40556+40557=>)	Kubota V3307CR-TE4	47(63)		FAR 1432 M	FSO 99/9	FSF 914/6	FEO 48 H
				FAR 1432/1 M	FSO 99/9	FSF 914/6	FEO 48 H
91	->					FEF 37 T	
91-2	V1505-BH-7			FA 1326 MK	FSO 87	FEF 37 T	
				FA 1326 MK	FSO 89	FSF 77	
91-2	V1505-EBH-5	19(27)				FEF 37 T	
91-2 S	V1505-EBH-7			FA 1326 MK	FSO 89	FEF 37 T	
				FA 1326 MK	FSO 89	FSF 77	
91-3	D1503-M-EBH-2				FSO 99/9		
91-3	Kubota D1503-M-EBH-1-EC	20(26)	2005 -> 2008		FSO 99/9		
91-3 alpha (>= 70001)	D1503-M	19(26)	2005 -> 2008		FSO 99/9	FSF 77	
91-3 S	D1503-M-E2BH-2-N				FSO 99/9	FSF 77	
91-3a	Kubota D1503M	21(29)	2005 -> 2008		FSO 99/9	FSF 77	
91-3a2	Kubota D1503-M-EBH3-EC-N	20(27)			FSO 99/9	FSF 77	
L-Serie (Tarım Makinaları)							
L2250	->	->(->)				FEF 58	
L2250/GST	->	->(->)				FEF 58	
L2250DT	->	->(->)			FSO 98/1	FEF 58	
L2250F	->	->(->)				FEF 58	
L235	->	->(->)				FEF 58	
L2550	->	->(->)				FEF 58	
L2550/GST	KUBOTA-3 CYL	->(->)				FEF 58	
L2550DT	->	->(->)				FEF 58	









L-Serie (Tarım Makinaları)							
L2550DTGST	->	->(->)				FEF 58	
L2550F	->	->(->)				FEF 58	
L2650DT	->	->(->)				FEF 58	
L2650DTGST	->	->(->)				FEF 58	
L2650F	->	->(->)				FEF 58	
L2650GST	->	->(->)				FEF 58	
L275	KUBOTA-3 CYL	->(->)				FEF 58	
L2850	KUBOTA-4 CYL	->(->)				FEF 58	
L2850DT	->	->(->)				FEF 58	
L2850F	->	->(->)				FEF 58	
L2850GST	->	->(->)				FEF 58	
L2850GST	KUBOTA-4 CYL	->(->)			FSO 98/1	FEF 58	
L2850L	KUBOTA-4 CYL	->(->)				FEF 58	
L2850R	KUBOTA-4 CYL	->(->)				FEF 58	
L2900	->	->(->)			FSO 98/1	FEF 58	
L2900DT/GST	->	->(->)				FEF 58	
L2900F	->	->(->)				FEF 58	
L2950DT	->	->(->)				FEF 58	
L2950DTGST	->	->(->)				FEF 58	
L2950F	->	->(->)				FEF 58	
L2950GST	->	->(->)				FEF 58	
L3010DT/GST/HST	->	->(->)				FEF 58	
L3010F	->	->(->)				FEF 58	
L3130	->	->(->)				FEF 58	
L3130 SERIES	->	->(->)				FEF 58	
L3240	->	->(->)				FEF 58	
L3240DT	->	->(->)				FEF 58	
L3240HST	->	->(->)				FEF 58	
L3250	->	->(->)				FEF 58	
L3250 /DS	KUBOTA-4 CYL	->(->)	01/92 ->			FEF 58	
L3300	->	->(->)	01/94 ->			FEF 58	
L3350	->	->(->)				FEF 58	
L3410DT/GST/HST	->	->(->)				FEF 58	
L3430 SERIES	->	->(->)				FEF 58	
L345	->	->(->)			FSO 98/1		
L345/II	->	->(->)				FEF 58	
L3450DT	->	->(->)			FSO 98/1	FEF 58	
L3450DT/GST	->	->(->)				FEF 58	
L3450GST	->	->(->)			FSO 98/1	FEF 58	
L345W	->	->(->)			FSO 98/1		
L35-TLB	->	->(->)				FEF 58	
L355SS	->	->(->)				FEF 58	
L3600	->	->(->)	01/94 ->			FEF 58	
L3600DT/GST	->	->(->)				FEF 58	
L3600DT/GSTC	->	->(->)				FEF 58	
L3650DT	->	->(->)			FSO 98/1	FEF 58	
L3650DT/GST	->	->(->)				FEF 58	
L3650GST	->	->(->)			FSO 98/1	FEF 58	
L3710DT/GST/HST	->	->(->)				FEF 58	
L3750	->	->(->)				FEF 58	
L3750	KUBOTA-F2302-DI-L	->(->)			FSO 98/1	FEF 58	



L-Serie (Tarım Makinaları)							
L3830 SERIES	KUBOTA-D1803MEGST	->(->)				FEF 58	
L405	->	->(->)				FEF 58	
L4150	->	->(->)				FEF 58	
L4150	KUBOTA-F2302-DI-L	->(->)			FSO 98/1	FEF 58	
L4200	->	->(->)	01/94 ->			FEF 58	
L4200DT/GST	->	->(->)				FEF 58	
L4200DT/GSTC	->	->(->)				FEF 58	
L4300F/DT	KUBOTA-V2203	->(->)				FEF 58	
L4310DT/GST/HST	->	->(->)				FEF 58	
L4330	->	->(->)				FEF 58	
L4350DT	->	->(->)				FEF 58	
L4630 SERIES	KUBOTA-V2203	->(->)				FEF 58	
L4850DT	->	->(->)			FSO 98/1	FEF 58	
L5030	->	->(->)				FEF 58	
L5450DT	->	->(->)				FEF 58	
L-Series							
L 275 / DT	Kubota D1302-A	21(28)	1981 -> 1985	FA 1326 MK		FEF 58/1	
				FA 1326 MK		FSF 77	
L 285	Kubota V1501-A	22(30)	1975 -> 1981	FA 1326 MK		FSF 77	
L 3000 DT / F	Kubota D1503-ELA	24(32)	2000 -> 2003			FSF 77	
L 305	Kubota D1301-DA	22(30)	1979 -> 1985	FA 1326 MK		FEF 58/1	FSO 917/31 H
				FAR 1027/1 M		FSF 77	FSO 917/31 H
L 3200 / DT	Kubota D1703-MA-E2A	25(33)	2005 -> 2017	FAR 1027/1 M			FSO 910/13 H
				FAR 626 MS			FSO 910/13 H
L 3200 / F / DT / HST	Kubota D1503 E-TVCS	24(32)	2011 -> 2014	FAR 1027/1 M			FSO 910/13 H
				FAR 626 MS			FSO 910/13 H
L 3250 / F (2WD) / DT (4WD)	Kubota V1902-DI-AE	29(40)	1989 -> 1990	FA 725 S		FEF 58/1	
				FA 725 S		FSF 77	
L 3300 / DT-C	Kubota D1703-A	24(33)	1994 -> 1999	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3301 / HST (4WD)	Kubota D1803-CR-E4	25(33)	2014 ->	FAR 1230 M		FEF 37 T	
				FAR 830 S		FEF 37 T	
L 3350 HDT / MDT	Kubota V1902-DI-A	30(40)	1985 -> 1990	FA 725 S		FEF 58/1	
L 3400 HST (4WD Hydro) / DT (4WI	Kubota D1703-MA-E2A	26(35)	2004 -> 2010	FAR 1027/1 M			FSO 910/13 H
				FAR 626 MS			FSO 910/13 H
L 345 / W	Kubota V1501-DA	25(34)	1978 -> 1985	FA 1326 MK	FSO 914/28	FSF 77	
L 345 MK II	Kubota V1702-DI-A	28(38)	1984 -> 1986			FSF 77	
L 355 SS	Kubota V1702-A	26(36)	1982 ->	FA 1326 MK		FEF 58/1	
L 3600 DT / HST / DT-C / HST-C	Kubota D1703-A	24(33)	1994 -> 2004	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3600 DT-C/GST-C/DT/DT-GST	Kubota V1903-A	29(39)	1994 -> 1999	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3750 / F (2WD) / DT (4WD)	Kubota F2302-D1-L	33(45)	1984 -> 1990	FA 725 S		FEF 58/1	
L 3800 HST (4WD Hydro) / DT (4WI	Kubota D1803-ME3	28(37)	2011 -> 2014	FAR 1027/1 M			FSO 910/13 H
				FAR 626 MS			FSO 910/13 H
L 3901 / HST (4WD)	Kubota D1803-CR-E4	23(31)	2014 ->	FAR 1027/1 M		FEF 37 T	FSO 910/13 H
				FAR 626 MS		FEF 37 T	FSO 910/13 H
L 4100 HST / GEAR	Kubota V2203-M-E2	31(42)	2009 -> 2013	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4150 DT-Narrow / F / DT	Kubota F2302-DI-2	37(50)	1984 -> 1990	FA 725 S	FSO 914/28	FEF 58/1	
L 4200 DT/HST/DT-C/DT-GST/HST-	Kubota V2203-A	32(44)	1994 -> 1999	FAR 1027/1 M	FSO 99/9	FEF 58/1	FSO 917/31 H

FERRAFILTER®

Kubota

APPLICATIONS









L-Series							
L 4200 DT/HST/DT-C/DT-GST/HST-	Kubota V2203-A	32(44)	1994 -> 1999	FAR 626 MS	FSO 99/9	FEF 58/1	FSO 917/31 H
L 4300 F (2WD) / DT (4WD)	Kubota V2203	34(45)	2001 -> 2005	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4400 DT / DW / FV / FW	Kubota V2203-M-E2A-2	34(45)	2004 -> 2010	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4400 HST (4WD Hydro)	Kubota V2203-M-E2A-2	34(45)	2004 -> 2010	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4600 F (2WD Gear) / DT (4WD Ge	Kubota V2203-M-E3-LB3	34(46)	2011 -> 2014	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4600 HST (4WD Hydro)	Kubota V2203-M-E3-LB3	34(46)	2011 -> 2014	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4701 / HST (4WD)	Kubota V2403-CR-E4	35(47)	2014 ->	FAR 1230 M		FEF 37 T	FSO 917/31 H
				FAR 830 S		FEF 37 T	FSO 917/31 H
L 5450 DT	Kubota F2803-DI	44(60)	1991 -> 1997	FA 725 S		FEF 58/1	FSO 917/31 H
L02-Series							
L 1802	Kubota D1102	13(18)	1978 -> 1985	FA 1018 K		FEF 58/1	
				FA 1018 MK		FEF 58/1	
L 2-351 HSTC	Kubota D1803-M-E2-U1	27(37)		FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 2-421 DT-C / HSTC	Kubota V2203-M-E2-EU2	34(45)	2018 ->	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 2-501	Kubota V2403-M-TE2	36(49)	2018 ->	FAR 630 S		FEF 58/1	FSO 917/31 H
L 2-501 DCN / DT / HSTC	Kubota D 1703-M-DI-E4	19(25)	2018 ->	FAR 630 S		FEF 58/1	FSO 917/31 H
L 2001	Kubota D1101	16(22)	1975 -> 1978	FA 1018 K		FSF 77	
				FA 1018 MK		FSF 77	
L 2250 F / DT	Kubota D1302-DI-A	20(27)	1985 -> 1991	FA 1326 MK	FSO 99/9	FEF 58/1	
L 235 DT	Kubota D1102-A	18(25)	1991 -> 1998	FA 1018 K		FSF 77	
				FA 1018 MK		FSF 77	
L 235 F	Kubota D1102-A	18(25)	1991 -> 1998	FA 1018 K		FEF 58/1	
				FA 1018 MK		FEF 58/1	
L 245 / HC / DT / F	Kubota DH1101-A	18(25)	1977 -> 1982	FA 1018 K		FSF 77	
				FA 1018 MK		FSF 77	
L 2802	Kubota V1501	21(28)	1978 -> 1985	FA 1326 MK			
L 3202 (2WD) / DT (4WD)	Kubota V1501	24(32)	1978 -> 1985	FA 1326 MK			
L 3602 (2WD) / DT (4WD)	Kubota V1902	27(36)	1978 -> 1985	FA 1326 MK			
L 4202 (2WD) / DT (4WD)	Kubota VT1502	31(42)	1978 -> 1985	FA 1326 MK			
L1-Series							
L 1-421 / DW / HDW	Kubota V2203	33(45)	2018 ->	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 1-501 DW / HDW	Kubota V2403T	36(49)		FAR 630 S		FEF 58/1	FSO 917/31 H
L 1361 DT / HST	Kubota D1803-M-E2	27(37)	2017 ->	FAR 1027/1 M			FSO 910/13 H
				FAR 626 MS			FSO 910/13 H
L 1361 F	Kubota D1803-M-E2	27(37)	2017 ->	FAR 1027/1 M			FSO 910/13 H
				FAR 626 MS			FSO 910/13 H
L 1361 H	Kubota D1803-M-E2	27(37)	2017 ->	FAR 1027/1 M			FSO 910/13 H
				FAR 626 MS			FSO 910/13 H
L 1361 T	Kubota D1803-M-E2	27(37)	2017 ->	FAR 1027/1 M			FSO 910/13 H
				FAR 626 MS			FSO 910/13 H
L10-Series							
L 3010 DT/F (Gear)/GST (Glide Shift	Kubota D1503-L-AN	23(30)	1998 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H









L10-Series							
L 3410 DT (4WD Gear)/GST (4WD (	Kubota D1703-A	26(35)	1998 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3410 HST (4WD Hydro)	Kubota D1503-L-AN	20(27)	1998 ->	FAR 1027/1 M		FEF 58/1	
				FAR 626 MS		FEF 58/1	
L 3710 DT (4WD Gear ROPS)	Kubota V1903-AN	29(39)	1998 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3710 GST (4WD Glide Shift ROPS	Kubota V1903-AN	29(39)	1998 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3710 HST (4WD Hydro ROPS)	Kubota V1903-AN	29(39)	1998 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3710 HSTC (4WD Hydro Cab)	Kubota V1903-AN	29(39)	1998 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4310 F / DT (Gear) / GST (Glide Sl	Kubota V2203-AN	32(45)	1998 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4310 GST-C (Glide Shift)	Kubota V2203-AN	32(45)	1998 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4310 HST (Hydro) / HST-C (Hydro	Kubota V2203-AN	32(45)	1998 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4610 GST (Glide-Shift ROPS)	Kubota V2203-E-TVCS	36(48)	1999 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4610 HST / HST-C	Kubota V2203-E-TVCS	36(48)	1999 -> 2002	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L100-Series							
L 1501	Kubota Z751A	11(15)	1975 -> 1978			FSF 77	
L 175	Kubota Z750A	13(17)	1973 -> 1978	FA 1018 K		FSF 77	
				FA 1018 MK		FSF 77	
L 185 / 185 DT	Kubota Z751A	13(17)	1977 -> 1982	FA 1018 K		FSF 77	
				FA 1018 MK		FSF 77	
L1000-Serie							
L1500	->	->(->)			FSO 910/5		
L1501	->	->(->)			FSO 910/5		
L1511	->	->(->)			FSO 910/5		
L1801	->	->(->)			FSO 910/5		
L1802	->	->(->)			FSO 910/5		
L1000-Series							
L 1500	Kubota Z750	11(15)				FSF 77	
L 1801	Kubota Z851	13(18)	1976 -> 1978	FA 1018 K			
				FA 1018 MK			
L2-Series							
L 2-601 / DT	Kubota V2403-CR-T	45(61)				FEF 58/1	
L 2-602 / HSTC	Kubota V2403-CR-T	45(61)	2018 ->	FA 1326 MK			FSO 917/31 H
				FAR 630 S			FSO 917/31 H
L 225 / DT	Kubota D1100-A	18(24)	1974 -> 1976			FSF 77	
L 2550 DT / DT GST / F	Kubota D1402-DI-A	22(30)	1985 -> 1991	FA 1018 K	FSO 87	FEF 58/1	
				FA 1018 MK	FSO 87	FEF 58/1	
L 2600 / DT / F	Kubota D1403-AE	20(27)	2000 -> 2003			FSF 77	
L 2800 DT / F / DHV / DHW	Kubota D1403-M-E2A	22(29)	2004 -> 2008	FAR 1027/1 M			FSO 910/13 H
				FAR 626 MS			FSO 910/13 H
L 2850 / DT / GST / F / R	Kubota D1702-DI-A	28(38)	1985 -> 1993	FA 1326 MK		FEF 58/1	
				FA 725 S		FSF 77	
L 2900 DT / GST	Kubota D1503-L-A	24(32)	1994 -> 1999	FAR 1027/1 M		FEF 58/1	FSO 917/31 H









L2-Series							
L 2900 DT / GST	Kubota D1503-L-A	24(32)	1994 -> 1999	FAR 626 MS		FEF 58/1	FSO 917/31 H
L 2900 DT NEW	Kubota D1503-L-A	24(32)		FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 2900 F	Kubota D1503-L-A	24(32)	1994 ->	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L200-Series							
L 235	Kubota D1102-AE-2	18(24)	1981 -> 1985	FA 1326 MK			
L 295 DT / F	Kubota D1301-A	22(30)	1978 -> 1982	FA 1326 MK		FSF 77	
L2000-Serie							
44683	->	169(230)	02/08 -> 08/13	FA 1629 MK			
L2000	->	->(->)			FSO 910/5		
L2002	->	->(->)			FSO 910/5		
L2202	->	->(->)			FSO 910/5		
L2402	->	->(->)			FSO 910/5		
L2600	->	->(->)			FSO 910/5		
L2600 DT/F	D1403-AE	20(27)	01/99 ->		FSO 910/5		
L2601	->	->(->)			FSO 910/5		
L2602	->	->(->)			FSO 910/5		
L2802	->	->(->)			FSO 910/5		
L2850	Kubota D1702-DI-A	25(34)	01/85 -> 12/90	FA 1629 MK			
L2850DT	V1702-DI-A	->(->)	->	FA 1629 MK			
L2850DTGST	V1702-DI-AE	->(->)	->	FA 1629 MK			
L2850F	V1702-DI-A	20(27)	01/85 ->	FA 1629 MK			
L2850GST	Kubota V1702-DI-AE	->(->)	->	FA 1629 MK			
L2850L	->	->(->)	->	FA 1629 MK			
L2850R	->	->(->)	->	FA 1629 MK			
L2950DT	D1462-DI-AE	->(->)	->	FA 1629 MK			
L45	V2203-M-TE3-TLB1	->(->)	->	FA 1629 MK			
STV32	->	->(->)	->	FA 1629 MK			
L2000-Series							
L 2000	->	15(20)		FA 1018 K		FSF 77	
				FA 1018 MK		FSF 77	
L 2050 DT / F	Kubota D1102-AE-2	15(20)	1989 -> 1991	FA 1018 K		FSF 77	
				FA 1018 MK		FSF 77	
L 2202	Kubota D1402	16(22)	1978 -> 1985	FA 1326 MK			
L 2350	Kubota D1102-AE	18(25)	1991 -> 1997	FA 1018 K			
				FA 1018 MK			
L 2402	Kubota D1402	18(24)	1978 -> 1985	FA 1326 MK			
L 2500 F / DT	Kubota D1403-AE	20(27)	1998 -> 2000	FAR 1027/1 M		FSF 77	
				FAR 626 MS		FSF 77	
L30-Series							
L 3130 / F / DT / GST / HST (hydro)	Kubota D1503-MA-E	23(31)	2003 -> 2007	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3430 / D / DT / GST / HST / HSTC	Kubota D1703	26(35)	2003 -> 2007	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3830 / HST / DT / F / GST	Kubota D1803-ME	28(37)	2004 -> 2007	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4330 DT (8 Speed) / GST (12 Spe	Kubota V2203-MA-E-GST	31(41)	2003 -> 2007	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4330 HST (Hydro) / HST-C (Hydro	Kubota V2203-MA-E-HST	31(41)	2003 -> 2007	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H









L30-Series							
L 4630 /HSTC/HST/DT/GST/DTC/G	Kubota V2203-MA-E	33(45)	2003 -> 2007	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 5030 DT / DT-C / HC / GST-C / HS	Kubota V2403-MA-E	37(50)	2003 -> 2007	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
L300-Serie							
3.6 V6	->	190(258)	09/07 ->	FA 1629 MK			
L345/II	->	->(->)	->	FA 1629 MK			
L3000-Serie							
2.5 GT	EJ255	195(265)	07/10 ->	FA 1629 MK			
2.5i	FB25	127(173)	07/12 ->	FA 1629 MK			
L3000 DT/F	D1503-ELA	23(32)	01/99 ->		FSO 910/5		
L3001	->	->(->)			FSO 910/5		
L3202	->	->(->)	01/78 -> 01/85		FSO 910/5		
L3250	Kubota V1902-DI-A	29(40)	01/89 -> 12/90	FA 1629 MK			
L3250/DS	->	->(->)	-> 01/90	FA 1629 MK			
L3250DT	V1902-DI-A	24(32)	01/89 ->	FA 1629 MK			
L3250F	V1902-DI-A	24(32)	01/89 ->	FA 1629 MK			
L3350	Kubota V1902-DI-A	29(40)	01/85 -> 12/90	FA 1629 MK			
L3350HDT/MDT	V1902-DI-A	24(32)	01/85 ->	FA 1629 MK			
L3600	V 1903-A	273(37)	01/94 -> 01/99		FSO 910/5		
L3602	->	->(->)	01/78 -> 01/85		FSO 910/5		
L3750	Kubota D2302-DI-L	33(45)	01/84 -> 12/90	FA 1629 MK			
ZP330LP-72	WG972-GL-E3-ZG-1PNEG801-5	->(->)	->	FA 1629 MK			
L3000-Series							
L 3700 SUHSTP	Kubota D1803-M-E3	28(37)	2010 -> 2012	FAR 1027/1 M			FSO 910/13 H
				FAR 626 MS			FSO 910/13 H
L40-Serie (Tarım Makinaları)							
L5040 GSTC	->	->(->)		FAR 1333 M			
L5240 HSTC	->	->(->)		FAR 1333 M			
L5740 HSTC	->	->(->)		FAR 1333 M			
L40-Series							
L 3240 DT / F / GST (12Speed)	Kubota D1703-M-E2	24(32)	2007 -> 2013	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3240 HST (Hydro) / HSTC (Hydro (	Kubota D1703-M-E2	24(32)	2007 -> 2013	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3540 / GST / HST / HSTC	Kubota D1803-M-E2	28(37)	2007 -> 2013	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3940 DT (8 Speed) / GST (12 Spe	Kubota V2003-M-E2	30(41)	2007 -> 2013	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 3940 HST (Hydro) / HSTC (Hydro (	Kubota V2003-M-E2	30(41)	2007 -> 2013	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4240 DT/DTC/GST/HST/HSTC/HS	Kubota V2203-M-T	33(44)	2007 -> 2013	FAR 1027/1 M		FEF 58/1	FSO 917/31 H
				FAR 626 MS		FEF 58/1	FSO 917/31 H
L 4740	Kubota V2403-M-E2	37(49)	2007 -> 2013	FAR 1432/1 M		FEF 58/1	FSO 917/31 H
				FAR 831 S		FEF 58/1	FSO 917/31 H
L 4740 GST-III	Kubota V2403-M-E3-GST1	37(49)	2007 -> 2013	FAR 1432/1 M		FEF 58/1	FSO 917/31 H
				FAR 831 S		FEF 58/1	FSO 917/31 H
L 4740 HST-III / HSTC-III	Kubota V2403-M-E3-HST1	37(49)	2007 -> 2013	FAR 1432/1 M		FEF 58/1	FSO 917/31 H
				FAR 831 S		FEF 58/1	FSO 917/31 H
L 5040 DT / GST / GSTC / GC / GST	Kubota V2403-M-T	39(52)	2007 -> 2013	FAR 1232		FEF 58/1	FSO 917/31 H
				FAR 1432/1 M		FEF 58/1	FSO 917/31 H









L40-Series							
L 5240 / HC / HST / HST-C / HST-C	Kubota V2403-M-TE3-EU	40(55)	2007 ->	FAR 1432/1 M		FEF 58/1	FSO 917/31 H
				FAR 630 S		FEF 58/1	FSO 917/31 H
L 5740 /HC/HST/HST III/HST-C II/HS	Kubota V2403-M-TE2	44(59)	2007 ->	FAR 1432/1 M		FEF 58/1	FSO 917/31 H
				FAR 630 S		FEF 58/1	FSO 917/31 H
L4000-Serie							
2.0D	->	110(150)	09/09 ->	FA 1629 MK			
L4150/DT	Kubota F2302-DI	37(50)	01/84 -> 12/90	FA 1629 MK			
L4150DT-N	F2302-DI	29(40)	01/88 ->	FA 1629 MK			
L4200	V 2203-A	321(437)	01/94 ->		FSO 910/5		
L4202	->	->(->)	01/78 -> 01/85		FSO 910/5		
L4000-Serie (Tarım Makinaları)							
L4060DT/GST	->	->(->)		FAR 1232 X			
L4060HST	->	->(->)		FAR 1232 X			
L4060HSTC	->	->(->)		FAR 1232 X			
L4740	->	->(->)		FAR 1333 M			
L4740GST-3	->	->(->)		FAR 1232 X			
L4740HST-3/HSTC-3	->	->(->)		FAR 1232 X			
L4760GST	->	->(->)		FAR 1232 X			
L4760HST	->	->(->)		FAR 1232 X			
L4760HSTC	->	->(->)		FAR 1232 X			
L4000-Series							
L 4850 DT	Kubota F 2503-DI	40(53)	1991 -> 1997			FEF 58/1	FSO 917/31 H
L50-Series							
L 2650 DT / DW / GST	Kubota D1402-DI-AE	22(29)	1991 -> 1993	FA 1326 MK	FSO 87	FEF 58/1	
				FA 1326 MK	FSO 89	FEF 58/1	
L 2650 F	D 1402-DI-AE	17(23)	1991 -> 1993	FA 1326 MK		FEF 58/1	
L 2950 DT	Kubota D1462-DI-AE	24(32)	1990 -> 1993	FA 1326 MK	FSO 87	FEF 58/1	
L 2950 DT GST	Kubota D1462-DI-AE			FA 1326 MK	FSO 87	FEF 58/1	
L 2950 F	Kubota D1462-DI-AE			FA 1326 MK		FEF 58/1	
L 3450 DT / DTGST / F	Kubota V1902-DI-AE	27(37)	1991 ->	FA 1326 MK	FSO 87	FEF 58/1	
L 3650 DT GST	Kubota V1902-DI-X-A	30(41)	1990 -> 1993	FA 1326 MK		FEF 58/1	
L 4350 DT	Kubota V2203-DI	35(48)	1991 -> 1997			FEF 58/1	FSO 917/31 H
L5000-Serie							
L5450DT	F2803-DI	->(->)	->	FA 1629 MK			
L5000-Serie (Tarım Makinaları)							
L5040-GSTC	->	->(->)		FAR 1333 M			
L5040GST	->	->(->)		FAR 1333 M			
L5040GST-3	->	->(->)		FAR 1232 X			
L5060GST	->	->(->)		FAR 1232 X			
L5240	->	->(->)		FAR 1333 M			
L5240-HSTC	->	->(->)		FAR 1333 M			
L5240HST-3	->	->(->)		FAR 1232 X			
L5460HST	->	->(->)		FAR 1232 X			
L5460HSTC	->	->(->)		FAR 1232 X			
L5740	->	->(->)		FAR 1333 M			
L5740-HSTC	->	->(->)		FAR 1333 M			
L5740HST-3/HSTC-3	->	->(->)		FAR 1232 X			
L60-Series							
L 3560 DT (4WD) / GST (4WD 12Sp	Kubota D1803-CR-E4	28(37)	2013 ->	FAR 1027/1 M		FEF 37 T	FSO 917/31 H
				FAR 626 MS		FEF 37 T	FSO 917/31 H
L 3560 HST (4WD Hydro)	Kubota D1803-CR-E4	28(37)	2013 ->	FAR 1027/1 M		FEF 37 T	FSO 917/31 H









L60-Series							
L 3560 HST (4WD Hydro)	Kubota D1803-CR-E4	28(37)	2013 ->	FAR 626 MS		FEF 37 T	FSO 917/31 H
L 3560 HSTC-C (4WD Hydro Cab)	Kubota D1803-CR-E4	28(37)	2013 ->	FAR 1027/1 M		FEF 37 T	FSO 917/31 H
				FAR 626 MS		FEF 37 T	FSO 917/31 H
L 4060 DT (4WD) / GST (4WD 12 S	Kubota V2403-CR-E4	31(42)	2013 ->	FAR 1027/1 M		FEF 37 T	FSO 917/31 H
				FAR 626 MS		FEF 37 T	FSO 917/31 H
L 4060 HST (Hydro)	Kubota V2403-CR-E4	31(42)	2013 ->	FAR 1027/1 M		FEF 37 T	FSO 917/31 H
				FAR 626 MS		FEF 37 T	FSO 917/31 H
L 4060 HSTC (Hydro Cab)	Kubota V2403-CR-E4	31(42)	2013 ->	FAR 1027/1 M		FEF 37 T	FSO 917/31 H
				FAR 626 MS		FEF 37 T	FSO 917/31 H
L 4760 GST / HST / HSTC-C (Cab)	Kubota V2403-CR-E	37(49)	2013 ->	FAR 1232		FEF 37 T	FSO 917/31 H
				FAR 630 S		FEF 37 T	FSO 917/31 H
L 5060 GST	Kubota V2403-CR-T4	39(52)	2013 ->	FAR 1232		FEF 37 T	FSO 917/31 H
				FAR 630 S		FEF 37 T	FSO 917/31 H
L 5460 HST / HSTC	Kubota V2403-CR-TE4	42(56)	2013 ->	FAR 1232		FEF 37 T	FSO 917/31 H
				FAR 630 S		FEF 37 T	FSO 917/31 H
L 6060 HST (ROPS), HSTC (Cab)	Kubota V2403-CR-TE4	46(62)	2013 ->	FAR 1232		FEF 37 T	FSO 917/31 H
				FAR 630 S		FEF 37 T	FSO 917/31 H
L6000-Serie (Tarım Makinaları)							
L6060HST	->	->(->)		FAR 1232 X			
L6060HSTC	->	->(->)		FAR 1232 X			
M40-Serie**							
M8540 DTH-C	->	->(->)		FAR 1635/3 M			
M9540 DTH-C	->	->(->)		FAR 1635/3 M			
M40-Serie (Tarım Makinaları)**							
M6040	->	->(->)		FAR 1333 M			
M6040 DTH-C	->	->(->)		FAR 1333 M			
M6040DT	->	->(->)		FAR 1333 M			
M6040DTH	->	->(->)		FAR 1333 M			
M6040HDNB	->	->(->)		FAR 1333 M			
M7040	->	->(->)		FAR 1333 M			
M7040 DTH-C	->	->(->)		FAR 1333 M			
M7040DT	->	->(->)		FAR 1333 M			
M7040DTH	->	->(->)		FAR 1333 M			
M--40-Series							
M 8540	Kubota V3800-DI-T3	64(86)	2007 -> 2014	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 8540 DTH-C	Kubota V3800-DI-T3	65(89)	2009 -> 2020	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9540	Kubota V3800-DI-T3	71(95)	2007 -> 2014	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9540 DTH-C	Kubota V3800-DI-T3	73(99)	2009 -> 2020	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9540 DTH-C	Kubota V3800-DI-TE3	71(95)	2006 -> 2013	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9540 DTHL	Kubota V3800-DI-TE3-CDIS	73(99)	2018 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9540 DTHNBC	Kubota V3800 DI-TE3	73(99)	2019 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 910/13 H
M-Serie							
M100GXDTC	V3800-CR-TIE4 PN1J540-21001	->(->)		FAR 1635/3 M			
M100XDTC	V3800DICR-TIE3 PN1J576-1100	->(->)		FAR 1635/3 M			









M-Serie							
M105	->	->(->)		FAR 1635/3 M			
M105S	Kubota V3800-DI-TI	77(105)	12/04 ->	FAR 1635/3 M			
M105SDSC	V3800DI-TIE2-Q	->(->)		FAR 1635/3 M			
M105SDT	V3800DI-TIE2-Q	->(->)		FAR 1635/3 M			
M105SHC	V3800DI-TIE2-Q	->(->)		FAR 1635/3 M			
M105SHDC	V3800DI-TIE2-Q	->(->)		FAR 1635/3 M			
M105XDTC	V3800DI-TIE2-QY	->(->)		FAR 1635/3 M			
M108	->	->(->)		FAR 1635/3 M			
M108S	V38DICR-TIE3-S2 or V38CRE3S	->(->)	01/08 ->	FAR 1635/3 M			
M108SDTC	V3800-DICR-TIE3-S1	->(->)		FAR 1635/3 M			
M108XDTC	V38DICR-TIE3-S2 or V38CRE3S	->(->)		FAR 1635/3 M			
M110GXDTC	V3800-CR-TIE4 PN1J540-00001	->(->)		FAR 1635/3 M			
M110XDTC	V3800DICR-TIE3 PN1J575-1100	->(->)		FAR 1635/3 M			
M4050	Kubota S2600	35(48)	01/82 -> 12/85	FA 1629 MK			
M4050DT	S2600-AL	31(42)	01/82 ->	FA 1629 MK			
M4500	Kubota S2600	41(56)	01/78 -> 12/85	FA 1629 MK			
M4500DT	S2200-A	35(48)	01/79 ->	FA 1629 MK			
M8200/C/CCS	Kubota V3300	63(85)	01/99 ->	FAR 1635/3 M			
M8200DT	V3300 PN1G545-00001	54(73)	01/98 ->	FAR 1635/3 M			
M8200DTC	V3300 PN1G545-22001	54(73)	01/99 ->	FAR 1635/3 M			
M8200HD	V3300-TE PN1G545-23001	->(->)		FAR 1635/3 M			
M8200HDC	V3300-TE PN1G545-24001	->(->)		FAR 1635/3 M			
M8200SDNB	V3300 PN1G545-25001	54(73)	01/00 ->	FAR 1635/3 M			
M8200SDNBC	V3300 PN1G545-42001	->(->)		FAR 1635/3 M			
M8540DTH	V3800-DI-TE3-ZA7	->(->)		FAR 1635/3 M			
M8540DTHC	V3800-DI-TE3-ZA7	->(->)		FAR 1635/3 M			
M8540DTHNB	V3800-DI-TE3-ZA8	->(->)		FAR 1635/3 M			
M8540DTHNBC	V3800-DI-TE3-ZA8	->(->)		FAR 1635/3 M			
M8540DTHQ	V3800DI-TE2QZ-HSPN1J598-27	64(87)		FAR 1635/3 M			
M8540DTQ	V3800DI-TE2-QZ pn1G598-2200	65(88)		FAR 1635/3 M			
M8540HDNBC	V3800DI-TE3-ZA2 PN1J598-180	63(85)		FAR 1635/3 M			
M8540HDNBPC	V3800DI-TE3-ZA2	->(->)		FAR 1635/3 M			
M9000	Kubota V3300-TIE	68(92)	01/99 ->	FAR 1635/3 M			
M9000C	V3300 PN1G573-22001	->(->)		FAR 1635/3 M			
M9000DT	V3300 PN1G573-00001	59(80)	01/98 ->	FAR 1635/3 M			
M9000DTCCS	V3300 PN1G573-22001	59(80)	01/00 ->	FAR 1635/3 M			
M9000DTL/DTC	V3300 PN1G573-24001	59(80)	01/99 ->	FAR 1635/3 M			
M9000DTM/DTMW	V3300	->(->)		FAR 1635/3 M			
M9000DTMC	V3300-TIE	59(80)	01/01 ->	FAR 1635/3 M			
M9000DTMCW	V3300-TIE	->(->)		FAR 1635/3 M			
M9000HD	V3300-TIE PN1G573-23001	59(80)	01/02 ->	FAR 1635/3 M			
M9000HDC	V3300-TIE PN1G573-24001	->(->)		FAR 1635/3 M			
M9540DT	V3800DI-TE2-QZ PN1G597-000(	->(->)		FAR 1635/3 M			
M9540DTH	V3800-DI-TE3-Z7	->(->)		FAR 1635/3 M			
M9540DTH	V3800DI-TE2-QZ-HS	->(->)		FAR 1635/3 M			
M9540DTHC	V3800-DI-TE3-Z7	->(->)		FAR 1635/3 M			
M95S	->	70(95)	12/04 ->	FAR 1635/3 M			
M95SDSC	V3800DI-TE2-Q	->(->)		FAR 1635/3 M			
M95XDTC	V38DITE2X	->(->)		FAR 1635/3 M			
M96S	V3800DI-TE2-Q PN1G581-5400:	->(->)		FAR 1635/3 M			
M9960	V3800-CR-TE4 PN1J541-16001	338(460)	01/12 ->	FAR 1635/3 M			









M-Serie (Tarım Makinaları)							
M100GXDTC V3800-CR-TIE4 PN1J5	->	->(->)					FSO 917/14 H
M100XDTC V3800DICR-TIE3 PN1J5	->	->(->)					FSO 917/14 H
M105SDSC V3800DI-TIE2-Q	->	->(->)					FSO 917/14 H
M105XDTC V3800DI-TIE2-QY	->	->(->)					FSO 917/14 H
M108XDTC V38DICR-TIE3-S2 or V3	->	->(->)					FSO 917/14 H
M110DT F2803-A	->	->(->)					FSO 917/14 H
M110FC/DTC F5802	->	->(->)					FSO 917/14 H
M110GXDTC V3800-CR-TIE4 PN1J5	->	65(88)	01/99 ->				FSO 917/14 H
M110XDTC V3800DICR-TIE3 PN1J5	->	->(->)					FSO 917/14 H
M120DT F2803-A	->	->(->)					FSO 917/14 H
M120FC/DTC F5802	->	->(->)					FSO 917/14 H
M125XDTC F5802-TE2-AFQ	->	72(98)	01/99 ->				FSO 917/14 H
M126XDTC V6108EC3QB PN1G41(	->	->(->)					FSO 917/14 H
M126XDTPC V6108EB3QB PN1G41	->	->(->)					FSO 917/14 H
M135XDTC V6108EB3QB PN1G41(	->	->(->)					FSO 917/14 H
M4500 OC	KUBOTA-6 CYL 2598 CC	->(->)			FSO 98/1		
M4500DT	KUBOTA-6-158.5	->(->)			FSO 98/1		
M4700	->	->(->)				FEF 58	
M4700DT	->	->(->)				FEF 58	
M4800	->	->(->)				FEF 58	
M4900	->	->(->)				FEF 58	
M4950	KUBOTA-S2800-A	->(->)			FSO 98/1		
M4950DT	KUBOTA-S2800-A	->(->)			FSO 98/1		
M5030	->	->(->)			FSO 98/1		
M5040/DT	->	->(->)		FAR 1333 M			
M5040HDC	->	->(->)		FAR 1333 M			
M5400	->	->(->)				FEF 58	
M5500	->	->(->)		FA 1916/1 MK			
M5500DT	->	->(->)		FA 1916/1 MK			
M5700	KUBOTA-F2803EA	->(->)				FEF 58	
M5700SDN	->	->(->)				FEF 58	
M59	->	->(->)		FAR 1333 M			
M6040	->	->(->)		FAR 1333 M			
M6040DT	->	->(->)		FAR 1333 M			
M6040DTH	->	->(->)		FAR 1333 M			
M6040DTHC	->	->(->)		FAR 1333 M			
M6040DTHNB	->	->(->)		FAR 1333 M			
M6040HDNB	->	->(->)		FAR 1333 M			
M6060HD	->	->(->)		FAR 1333 M			
M6060HDC	->	->(->)		FAR 1333 M			
M6060HFC	->	->(->)		FAR 1333 M			
M6800	->	->(->)		FAR 1333 M			
M6800DT	->	->(->)		FAR 1333 M			
M6800HD	->	->(->)		FAR 1333 M			
M6800HDC	->	->(->)		FAR 1333 M			
M6800S	->	->(->)		FAR 1333 M			
M6800SC	->	->(->)		FAR 1333 M			
M6800SD	->	->(->)		FAR 1333 M			
M6800SDC	->	->(->)		FAR 1333 M			
M6800SDT	->	->(->)		FAR 1333 M			
M7040	->	->(->)		FAR 1333 M			









M-Serie (Tarım Makinaları)							
M7040DT	->	->(->)		FAR 1333 M			
M7040DTH	->	->(->)		FAR 1333 M			
M7040DTHC	->	->(->)		FAR 1333 M			
M7040DTHNB	->	->(->)		FAR 1333 M			
M7040DTHNBC	->	->(->)		FAR 1333 M			
M7040SUD	->	->(->)		FAR 1333 M			
M7040SUHD	->	->(->)		FAR 1333 M			
M7060HD/HD12	->	->(->)		FAR 1333 M			
M7060HDC/HDC12	->	->(->)		FAR 1333 M			
M7060HFC	->	->(->)		FAR 1333 M			
M7500	->	->(->)		FA 1916/1 MK			
M7500 ACL	->	->(->)		FA 1916/1 MK			
M7500DT	->	->(->)		FA 1916/1 MK			
M7500DT-ACL	->	->(->)		FA 1916/1 MK			
M8950DTS---60001	->	->(->)		FA 2026 M			
M8950S---60001	->	->(->)		FA 2026 M			
M8970	->	->(->)		FA 2026 M			
M9580	KUBOTA-V4702	->(->)		FA 2026 M			
M9580DT	->	->(->)		FA 2026 M			
MX5000DT	->	->(->)				FEF 58	
MX5000F	->	->(->)				FEF 58	
M-Series							
M 100 GXDTC	Kubota V3800-CR-TIE4	78(106)	2012 -> 2016	FAR 1635 M	FSO 99/9	FSF 811/4	
				FAR 933 S	FSO 99/9	FSF 816/1	
M 100 S	Kubota V4702	74(99)	2002 -> 2004			FEF 58/1	FSO 917/31 H
M 100 XDTC	Kubota V3800-DI-CR-TIE3	74(100)		FAR 1635 M	FSO 1017/6	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 105 S / SDSC / SDT / SHC / SHD	Kubota V3800-DI-TI	79(108)	2005 -> 2007	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/26 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 108	Kubota V3800-DI-TI	81(108)	2007 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 108 S	Kubota V3800-CR-E3-S2	81(108)	2007 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/26 H
M 108 S	Kubota V3800-DI-CR-TIE3-S1	81(108)	2007 ->	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 108 S	Kubota V3800-DI-CR-TIE3-S1	81(108)	2008 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 108 S	Kubota V3800-DI-CR-TIE3-S2	81(108)	2007 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/26 H
M 108 S	Kubota V3800-DI-CR-TIE3-S2	81(108)	2008 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 108 S	Kubota V3800-DT-TI-CRS	81(108)	2007 -> 2014	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 108 SDT	Kubota V3800-DI-TI-CRS	81(108)	2007 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 108 SDTC	Kubota V3800-DI-CR-TIE3-S1	81(108)	2007 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 108 SDTC	Kubota V3800-DI-CR-TIE3-S1	81(108)	2007 -> 2014	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 816/1	FSO 917/31 H
M 108 SDTC	Kubota V3800-DI-CR-TIE3-S1	81(108)	2008 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H









M-Series							
M 108 XDTC	Kubota V3800-CR-TIE3-S2	81(108)	2007 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/26 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 108 XDTC	Kubota V3800-DI-CR-TIE3-S2	81(108)	2007 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/26 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 110 / DT	Kubota F2803-A	82(110)	1998 -> 2004		FSO 99/9	FSF 811/4	FSO 910/13 H
					FSO 99/9	FSF 811/4	FSO 917/26 H
M 110 FC / DTC	Kubota F5802-TE2	82(110)	1999 -> 2004		FSO 1017/6	FSF 811/4	FSO 917/26 H
					FSO 1017/6	FSF 811/4	FSO 917/31 H
M 110 X DTC	Kubota V3800-DI-CR-TIE3	82(110)	2009 -> 2014	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/26 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 120 DT	Kubota F2803-A	90(120)	1998 -> 2004		FSO 1017/6	FSF 811/4	FSO 917/26 H
					FSO 1017/6	FSF 811/4	FSO 917/31 H
M 120 FC / DTC	Kubota F5802-TE2	90(120)	1999 -> 2004		FSO 1017/6	FSF 811/4	FSO 917/26 H
					FSO 1017/6	FSF 811/4	FSO 917/31 H
M 125 X	Kubota F5802-TE2	93(125)	2004 -> 2008	FAR 2029 M	FSO 99/9		FSO 917/26 H
				FAR 2029 M	FSO 99/9		FSO 917/31 H
M 125 XDT / XDTC	Kubota F5802-TE2	92(123)	2002 -> 2004	FAR 2029 M	FSO 1017/6	FSF 811/4	FSO 917/26 H
				FAR 2029 M	FSO 1017/6	FSF 811/4	FSO 917/31 H
M 126 XDTC / XDTPC	Kubota V6108-TI-CRS	94(126)	2009 -> 2017	FAR 2029 M	FSO 1013/2		FSO 917/26 H
				FAR 2029 M	FSO 1013/2		FSO 917/31 H
M 128 / X / XDT-C	Kubota V6108-TI-CRS	94(128)	2008 -> 2010	FAR 2029 M	FSO 1013/2	FEF 37 T	FSO 917/26 H
				FAR 2029 M	FSO 1017/6	FSF 811/4	FSO 917/31 H
M 130 XDTC	Kubota V6108-TIE3-GQ	103(140)	2010 ->	FAR 2029 M	FSO 1013/2	FSF 816/1	FSO 917/26 H
				FAR 2029 M	FSO 1013/2	FSF 816/1	FSO 917/31 H
M 135 XDTC	Kubota V6108-EB3-QB	101(135)	2009 -> 2014	FAR 2029 M	FSO 1013/2		FSO 917/26 H
				FAR 2029 M	FSO 1013/2		FSO 917/31 H
M 4000	Kubota S2200-A	36(48)	1976 -> 1983	FA 1326 MK	FSO 914/28		
M 4500 / DT (4WD)	Kubota S2600-AL	35(48)	1982 -> 1985	FA 1326 MK			
				FA 725 S			
M 4700 / DT	Kubota F2803-ELA	35(47)	1995 -> 1997	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
M 4800 SU	Kubota V2403-M-EA-SU	35(47)	1995 -> 1997	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
M 4900 / C / DTC	Kubota F2803-ELA	40(54)	2001 -> 2008	FAR 1230 M		FSF 811/4	FSO 917/31 H
				FAR 830 S		FSF 811/4	FSO 917/31 H
M 4900 / DT / S / SC / SCS-F	Kubota F2803-ELA	40(54)	2001 -> 2008	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
M 4900 SD / SDC / SU / SUD	Kubota F2803-ELA	40(54)	2001 -> 2008	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
M 5140 DT (4WD ROPS sync-shuttle	Kubota V2403-TE3-S4	39(52)	2010 ->	FAR 1230 M		FSF 811/4	FSO 917/31 H
				FAR 830 S		FSF 811/4	FSO 917/31 H
M 5140 DTC (4WD cab sync-shuttle)	Kubota V2403-TE3-S5	39(52)	2010 ->	FAR 1230 M		FSF 811/4	FSO 917/31 H
				FAR 830 S		FSF 811/4	FSO 917/31 H
M 5140 F (2WD ROPS sync-shuttle)	Kubota V2403-TE3-S4	39(52)	2010 ->	FAR 1230 M		FSF 811/4	FSO 917/31 H
				FAR 830 S		FSF 811/4	FSO 917/31 H
M 5140 FC (2WD cab sync-shuttle)	Kubota V2403-TE3-S5	39(52)	2010 ->	FAR 1230 M		FSF 811/4	FSO 917/31 H
				FAR 830 S		FSF 811/4	FSO 917/31 H
M 5140 HD (4WD ROPS hyd-shuttle	Kubota V2403-TE3-S2	39(52)	2010 ->	FAR 1230 M		FSF 811/4	FSO 917/31 H
				FAR 830 S		FSF 811/4	FSO 917/31 H
M 5140 HDC (4WD cab hyd-shuttle)	Kubota V2403-TE3-S3	39(52)	2010 ->	FAR 1230 M		FSF 811/4	FSO 917/31 H
				FAR 830 S		FSF 811/4	FSO 917/31 H









M-Series							
M 5400 / DT / DT-Narrow EMISSION	Kubota F2803-EA	39(54)	1995 -> 1999	FAR 1230 M		FEF 58/1	FSO 910/13 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
M 5500 / DT	Kubota D3000-A	46(63)	1979 -> 1984		FSO 1017/6	FSF 87/1	
M 5640 SUD	Kubota V2403-M-TE3	42(56)	2009 ->	FAR 1230 M			FSO 917/31 H
				FAR 830 S			FSO 917/31 H
M 5660 SUHD	Kubota V2403-CR-TE4	41(56)	2015 ->	FAR 1230 M		FEF 37 T	FSO 917/31 H
				FAR 830 S		FEF 37 T	FSO 917/31 H
M 5700 DT / SD Narrow	Kubota F2803-EA	46(62)	2001 -> 2005	FAR 1230 M	FSO 1017/6	FEF 58/1	FSO 910/13 H
				FAR 830 S	FSO 1017/6	FEF 58/1	FSO 910/13 H
M 5700 S / SD / SC / SDC	Kubota F2803-EA	38(52)	2000 -> 2005	FAR 1230 M	FSO 1017/6	FEF 58/1	FSO 910/13 H
				FAR 830 S	FSO 1017/6	FEF 58/1	FSO 910/13 H
M 6800 DT / HD / HDC / S / SC / SD	Kubota V3300-E	53(71)	2000 ->	FAR 1432/1 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 831 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 7030 SU / SUDT	Kubota V4000-3A-1	50(68)	1989 ->		FSO 1017/6	FSF 87/1	
M 7040 DT / DTH	Kubota V3307-DI-TE3-1-Q			FAR 1432/1 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 831 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 7040 DTH-C	Kubota V3307-DI-E2-1-SS	54(73)	2012 ->	FAR 1432 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 1432/1 M	FSO 99/9	FSF 811/4	FSO 917/31 H
M 7040 DTHC	Kubota V3307-DI-TE3-1-Q			FAR 1432/1 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 831 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 7040 DTHNB / DTHNBC	Kubota V3307-DI-TE3-1			FAR 1432/1 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 831 S	FSO 99/9	FSF 811/4	FSO 910/13 H
M 7500 / DT / DT / ACL	Kubota V4000-A	60(81)	1979 -> 1986		FSO 1017/6	FSF 87/1	
M 8030 / DT / MDT	Kubota V4300-1A	61(82)	1986 -> 1997		FSO 1017/6	FSF 87/1	
M 8200 /C/CCS/DT/DTC/HD/HDC/S	Kubota V3300-TE	54(73)	1997 -> 2005	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 8540	Kubota VI3800-DI-T3	65(89)	2009 -> 2014	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 8540 DTHC	Kubota V3800-DI-TE3	65(89)	2009 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9000 /C/F/DT/DTC/DTL/DTM/DTM	Kubota V3300-TIE	69(92)	1997 -> 2005	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 95 / S /SDSC	Kubota V3800DI-TE2-Q	70(95)	2005 -> 2006	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 95 XDTC	Kubota V3800-DI-TE2-X	71(95)	2005 -> 2006	FAR 1635 M	FSO 99/9		
				FAR 933 S	FSO 99/9		
M 9540 DT	Kubota V3800-DI-TE2	71(95)	2006 -> 2013	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9540 DTH	Kubota V3800-DI-TE2-QZ-HS	73(99)		FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9540 DTHC	Kubota V3800-DI-TE3-Z7	64(86)		FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9580 DT / DTC	Kubota V4702-TA	75(100)	1991 -> 1999		FSO 1017/6	FSF 811/4	FSO 917/31 H
M 96 S	Kubota V3800DI-TE2-Q	71(95)	2007 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9960 DTH	V3800-CR-TIE4	74(100)	2012 ->	FAR 933 S	FSO 99/6	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/6	FSF 811/4	FSO 917/31 H
M 9960 DTHQ	V3800-CR-TIE4	74(100)	2012 ->	FAR 933 S	FSO 99/6	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/6	FSF 811/4	FSO 917/31 H
M 9960 HDC	Kubota V3800-CR-TE4	75(105)	2012 ->	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H



M30-Series							
M 4030 / DT	Kubota S2602-DI-A	36(48)	1986 -> 1989		FSO 914/28		
M 4030 SU / TF	Kubota F2402-DI-A	38(51)	1988 -> 1998		FSO 914/28		
M 5030 /DTL/F/L/MDT/MDTL/MF/SU	Kubota S2802-DI-A	40(55)	1986 -> 1996		FSO 914/28		
M 6030	Kubota D3200-1A	49(66)	1986 -> 1998		FSO 1017/6		
M 6030 DT	Kubota D3200-2A	45(62)	1986 -> 1998		FSO 1017/6	FSF 87/1	
M 6030 DT Narrow / DTNB	Kubota D3200-2A	45(62)	1987 ->		FSO 1017/6	FSF 87/1	
M 7030	Kubota V4000-3A	57(77)	1986 -> 1998		FSO 1017/6	FSF 87/1	
M 7030 DT (4WD)	Kubota V4000-3A	54(72)	1986 -> 1998		FSO 1017/6	FSF 87/1	
M 7030 MDT / DT-NB	Kubota V4000	54(72)	1986 -> 1998		FSO 1017/6	FSF 87/1	
M 7030 Narrow	Kubota V4000-4A	50(68)	1986 -> 1998		FSO 1017/6	FSF 87/1	
M40-Series							
M 5040 / DT / HDC	Kubota V3007-DI-E2-SS	38(51)	2007 -> 2010	FAR 1432/1 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 831 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 6040 / HDNB / DTH / DTHC / DTH	Kubota V3307-DI-TE3-E-CDIS	49(66)	2009 -> 2014	FAR 1432/1 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 831 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 6040 DTN / Narrow	Kubota V3307-DI-TE3-E-CDIS	49(65)	2008 ->	FAR 1432/1 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 831 S	FSO 99/9	FSF 811/4	FSO 910/13 H
M 7040 /DTH/SUD/DTHQ/SUHD/DT	Kubota V3307-DI-TE3-E-CDIS	55(74)	2009 -> 2014	FAR 1432/1 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 831 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 7040 Narrow DTN / DTNQ	Kubota V3307-DI-TE3-E-CDIS	55(74)	2013 ->	FAR 1432/1 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 831 S	FSO 99/9	FSF 811/4	FSO 910/13 H
M 8540 DTH/DTHC/DTHNBC/DTHQ	Kubota V3800-DI-TE3-ZA7	65(89)	2009 -> 2014	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 8540 Narrow	Kubota V3800-DI-TE3-E-CDIS	65(89)	2009 -> 2014	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M4002-Series							
M 4062	Kubota V3307-CR-T	49(66)	2018 ->	FAR 1432/1 M	FSO 99/9		
				FAR 831 S	FSO 99/9		
M 4072	Kubota V3307-CR-T	55(74)	2018 ->	FAR 1432/1 M	FSO 99/9		
				FAR 831 S	FSO 99/9		
M4003-Series							
M4-063 DTH (ROPS)	Kubota V3307-CR-TE5	49(66)	2021 ->	FAR 1432/1 M	FSO 99/9		
				FAR 831 S	FSO 99/9		
M4-063 DTHC (CABINE)	Kubota V3307-CR-TE5	49(66)	2021 ->	FAR 1432/1 M	FSO 99/9		
				FAR 831 S	FSO 99/9		
M4-073 DTH (ROPS)	Kubota V3307-CR-TE5	55(74)	2021 ->	FAR 1432/1 M	FSO 99/9		
				FAR 831 S	FSO 99/9		
M4-073 DTHC (CABINE)	Kubota V3307-CR-TE5	55(74)	2021 ->	FAR 1432/1 M	FSO 99/9		
				FAR 831 S	FSO 99/9		
M40N-Series							
M 9540 DTHQ	Kubota V3800DI-TE2-QZ	73(99)	2009 -> 2016	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9540 DTNQ Narrow	Kubota V3800-DI-TE3-E-CDIS	73(99)	2014 -> 2017	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 910/13 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 9540 DTQ	Kubota V3800DI-TE2-QZ	63(84)	2014 -> 2017	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M50-Series							
M 4050 / DT (4WD)	Kubota S2600-AL	35(48)	1982 -> 1985	FA 1326 MK			
				FA 725 S			
M 4950 / DT	Kubota S2800-A	40(55)	1983 -> 1993		FSO 914/28		
M 5950 / C / DT / DTS / S	Kubota D3200-A	45(61)	1983 -> 1993		FSO 1017/6	FSF 87/1	

FERRAFILTER®

Kubota

APPLICATIONS









M50-Series							
M 6950 / C / DT / DTC / DTS / S	Kubota V4000-2A	52(71)	1983 -> 1993		FSO 1017/6	FSF 87/1	
					FSO 99/9	FSF 87/1	
M 7950 / DT	Kubota V4300-A	60(81)	1983 -> 1994		FSO 1017/6	FSF 87/1	
M 7950 S	Kubota V4300	60(81)	1983 -> 1994		FSO 1017/6	FSF 87/1	
M 8950	Kubota V4300-T-A	71(96)	1984 -> 1993		FSO 1017/6	FSF 87/1	
M 8950 DTS / S	Kubota V4300-T-A	71(96)	1984 -> 1993		FSO 1017/6	FSF 87/1	
M5001 N-Series							
M5091 N	Kubota V3800-CR-Tier 4 Final	68(93)	2021 ->	FAR 1635 M	FSO 99/9	FSF 811/4	
				FAR 933 S	FSO 99/9	FSF 811/4	
M5001-Series							
M 5-111 DTH / DTHQ	Kubota V3800-TIEF4	79(106)	2016 ->	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 5071 Narrow CAB / Narrow ROPS	Kubota V3800-CR-TIE4	54(73)	2016 ->	FAR 1635 M	FSO 99/9	FSF 811/4	
				FAR 933 S	FSO 99/9	FSF 811/4	
M 5091 DTH / DTHQ / Narrow CAB /	Kubota V3800-TIEF4	71(95)	2016 ->	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 5101 Narrow CAB / Narrow ROPS	Kubota V3800-CR-TIE4	77(105)		FAR 1635 M	FSO 99/9	FSF 811/4	
				FAR 933 S	FSO 99/9	FSF 811/4	
M5002-Series							
M5-092H (ROPS)	Kubota V3800 CR-TE5	71(96)	2021 ->	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M5-092HC (CABINE)	Kubota V3800 CR-TE5	71(96)	2021 ->	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M5-112H (ROPS)	Kubota V3800 CR-TE5	85(115)	2021 ->	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M5-112HC (CABINE)	Kubota V3800 CR-TE5	85(115)	2021 ->	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M60-Series							
M 6060 DTH / DTHC	Kubota V3307-CR-TE4	49(66)	2013 -> 2016	FAR 1635 M		FSF 811/4	FSO 917/31 H
				FAR 933 S		FSF 816/1	FSO 917/31 H
M 6060 HD / HDC	Kubota V3300- DIE2	49(66)	2013 -> 2016	FAR 1432/1 M	FSO 99/9	FSF 816/1	FSO 917/31 H
				FAR 831 S	FSO 99/9	FSF 816/1	FSO 917/31 H
M 7060 / HD / HD12 / HDC / HDC12	Kubota V3307-CR-TE4	55(74)	2013 -> 2016	FAR 1432/1 M	FSO 99/9		FSO 917/31 H
				FAR 1635 M	FSO 99/9		FSO 917/31 H
M 8560	Kubota V3800-CR-TE4	69(94)	2012 -> 2017	FAR 1635 M	FSO 99/6	FEF 37 T	FSO 910/13 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 910/13 H
M6001-Series							
M 6121	Kubota V6108-CR-TIE-F4	99(135)	2018 ->		FSO 1013/2	FEF 37 T	FSO 924 HMT
					FSO 1013/2	FSF 912	FSO 924 HMT
M6002-Series							
M6-122	Kubota V6108 TIEF5	91(123)	2020 ->		FSO 1013/2	FEF 37 T	FSO 913/1 H
					FSO 1013/2	FSF 912	FSO 913/1 H
M6-132	Kubota V6108 TIEF5	98(133)	2020 ->		FSO 1013/2	FEF 37 T	FSO 913/1 H
					FSO 1013/2	FSF 912	FSO 913/1 H
M6-142	Kubota V6108 TIEF5	106(143)	2020 ->		FSO 1013/2	FEF 37 T	FSO 913/1 H
					FSO 1013/2	FSF 912	FSO 913/1 H
M700-Series							
M 5700 /DT/DTC/HDC/HDF/DTH/Na	Kubota F2803-EA	46(62)	2001 -> 2005	FAR 1230 M	FSO 1017/6	FEF 37 T	FSO 910/13 H
				FAR 830 S	FSO 1017/6	FEF 58/1	FSO 917/31 H
M7001-Series							
M 7-131 Premium / KVT / POWERS	Kubota V6108-CR-TIEF4	95(130)	2015 -> 2018		FSO 1013/2	FEF 37 T	FSO 924 HMT









M7001-Series							
M 7-131 Premium / KVT / POWERS	Kubota V6108-CR-TIEF4	95(130)	2015 -> 2018		FSO 99/9	FSF 912	FSO 924 HMT
M 7-131 without Air Compressor	Kubota V6108-CR-TIEF4	95(130)	2015 -> 2018		FSO 1013/2	FEF 37 T	FSO 924 HMT
					FSO 1013/2	FSF 912	FSO 924 HMT
M 7-151 S	Kubota V6108-CR-TIEF4	110(150)	2015 -> 2018		FSO 1013/2	FEF 37 T	
					FSO 1013/2	FSF 912	
M 7-151 without Air Compressor	Kubota V6108-CR-TIEF4	110(150)	2015 -> 2018		FSO 1013/2	FEF 37 T	FSO 924 HMT
					FSO 1013/2	FSF 912	FSO 924 HMT
M 7-171 Premium / KVT / S	Kubota V6108-CR-TIEF4	125(170)	2015 -> 2018		FSO 1013/2	FSF 912	FSO 924 HMT
M 7-171 without Air Compressor	Kubota V6108-CR-TIEF4	125(170)	2015 -> 2018		FSO 1013/2	FEF 37 T	FSO 924 HMT
					FSO 1013/2	FSF 912	FSO 924 HMT
M7002-Series							
M 7132 P-KVTwith Air Compressor /	Kubota V6108-CR-TIEF4	95(130)	2018 ->		FSO 1013/2	FEF 37 T	FSO 924 HMT
					FSO 1013/2	FSF 912	FSO 924 HMT
M 7152 P-KVTwith Air Compressor /	Kubota V6108-CR-TIEF4	110(150)	2018 ->		FSO 1013/2	FEF 37 T	FSO 924 HMT
					FSO 1013/2	FSF 912	FSO 924 HMT
M 7172 P-KVTwith Air Compressor /	Kubota V6108-CR-TIEF4	125(170)	2018 ->		FSO 1013/2	FEF 37 T	FSO 924 HMT
					FSO 1013/2	FSF 912	FSO 924 HMT
M80-Series							
M 7580 DT (4WD)	Kubota V4302-A (ROPS)	57(77)	1991 -> 1999		FSO 1017/6	FSF 811/4	FSO 917/31 H
M 7580 DT (4WD)	Kubota V4302-AQ (CAB)	57(77)	1991 -> 1999		FSO 1017/6	FSF 811/4	FSO 917/31 H
M 8580 DT	Kubota V4702-A W/ROPS	59(80)	1991 -> 1999		FSO 1017/6	FSF 811/4	FSO 917/31 H
M800-Serie (Tarım Makinaları)							
M6800	->	->(->)		FAR 1333 M			
M6800DT	->	->(->)		FAR 1333 M			
M6800HD	->	->(->)		FAR 1333 M			
M6800HDC	->	->(->)		FAR 1333 M			
M6800S	->	->(->)		FAR 1333 M			
M6800SC	->	->(->)		FAR 1333 M			
M6800SD	->	->(->)		FAR 1333 M			
M6800SDC	->	->(->)		FAR 1333 M			
M6800SDT	->	->(->)		FAR 1333 M			
ME-Serie							
ME8200	->	->(->)	01/06 -> 01/07	FAR 1635/3 M			
ME8200DTHC	V3300-TE	->(->)		FAR 1635/3 M			
ME8200DTNC	V3300-TE	->(->)		FAR 1635/3 M			
ME9000	->	->(->)	01/06 -> 01/07	FAR 1635/3 M			
ME9000DTHC	V3300-TIE-Q	->(->)		FAR 1635/3 M			
ME-Series							
ME 5700 DTH / DTHC	Kubota F2803-EA-1	42(58)		FAR 1230 M		FEF 37 T	FSO 917/31 H
				FAR 830 S		FSF 811/4	FSO 917/31 H
ME 5700 DTH / DTHC	Kubota F2803-EA-2Q	42(58)		FAR 1230 M		FEF 37 T	FSO 917/31 H
				FAR 830 S		FSF 811/4	FSO 917/31 H
ME 5700 DTHQ	Kubota F2803-EA-E-TVCS	43(58)	2008 ->	FAR 1230 M	FSO 99/9	FEF 37 T	
				FAR 830 S	FSO 99/9	FSF 811/4	
ME 8200 / Narrow / DTHC / DTNC	Kubota V3300-TE	64(85)	1997 -> 2010	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
ME 8200 DTQ	Kubota V3300-TE	64(87)		FAR 1635 M		FEF 37 T	FSO 910/13 H
				FAR 933 S		FSF 811/4	FSO 917/31 H
ME 9000 / DTH	Kubota V3300T-IE	70(95)	2003 -> 2010	FAR 1635 M	FSO 99/6	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/6	FSF 811/4	FSO 917/31 H
ME 9000 / DTHC	Kubota V3300T-IE	69(94)	2003 -> 2010	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H



ME-Series							
ME 9000 / DTHC	Kubota V3300T-IE	69(94)	2003 -> 2010	FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
ME700-Series							
ME 5700 / DTH / Narrow	Kubota F2803-EA	42(58)	2003 -> 2010	FAR 1230 M		FEF 37 T	FSO 917/31 H
				FAR 830 S		FSF 811/4	FSO 917/31 H
MGX III-Series							
M 100 GX III	->			FAR 933 S	FSO 99/6	FSF 811/4	
M 105 GX-III	Kubota V3800-CR-TIEF4	82(111)	2016 -> 2018	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 115 GX III	Kubota V6108-CR-TIE4	90(123)	2016 -> 2018	FAR 2029 M	FSO 1017/6	FEF 37 T	
M 125 GX III	Kubota V6108-CR-Tier4F	98(133)	2017 ->	FAR 2029 M	FSO 1013/2	FEF 37 T	
				FAR 2029 M	FSO 1013/2	FSF 912	
M 135 GX III	Kubota V6108-CR-Tier4F	105(143)	2017 ->	FAR 2029 M	FSO 99/9	FEF 37 T	
				FAR 2029 M	FSO 99/9	FSF 912	
M 95 GX-III	Kubota V3800-CR-TIEF4	77(104)	2016 ->	FAR 1635 M	FSO 99/9	FSF 811/4	
				FAR 933 S	FSO 99/9	FSF 811/4	
MGX IV-Series							
M 105 GX-IV	Kubota V3800-CR-TIEF4	82(111)	2018 ->	FAR 1635 M	FSO 99/9	FSF 811/4	
				FAR 933 S	FSO 99/9	FSF 811/4	
M 115 GXDTC IV	Kubota V6108-CR-TIE4	90(123)	2018 ->	FAR 2029 M	FSO 1013/2	FEF 37 T	
				FAR 2029 M	FSO 1013/2	FSF 912	
M 125 GXDTC IV	Kubota V6108-CR-TIE4	98(133)	2018 ->	FAR 2029 M	FSO 1013/2	FEF 37 T	
				FAR 2029 M	FSO 1013/2	FSF 912	
M 125 GXDTC IV	Kubota V6108-CR-TIEF4	105(143)	2018 ->	FAR 2029 M	FSO 1013/2	FEF 37 T	
				FAR 2029 M	FSO 1013/2	FSF 912	
M 125 GXDTSC IV	Kubota V6108-CR-TIE4	105(143)	2018 ->	FAR 2029 M	FSO 1013/2	FEF 37 T	
				FAR 2029 M	FSO 1013/2	FSF 912	
M 95 GX-IV	Kubota V3800-CR-TIEF4	77(104)	2018 ->	FAR 1635 M	FSO 99/9	FSF 811/4	
				FAR 933 S	FSO 99/9	FSF 811/4	
MGX-Series							
M 100 GX	Kubota V3800-TI-CRS	75(100)	2012 ->	FAR 1635 M	FSO 99/9	FSF 811/4	FSO 917/26 H
				FAR 933 S	FSO 99/9	FSF 816/1	FSO 917/31 H
M 105 GX	Kubota V3800	76(104)	2016 ->	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/31 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/31 H
M 110 GX I + II / GX DTC	Kubota V3800-CR-TIE4	85(116)	2012 -> 2016	FAR 1635 M	FSO 99/9	FEF 37 T	FSO 917/26 H
				FAR 933 S	FSO 99/9	FSF 811/4	FSO 917/26 H
M 125 GX III	Kubota V6108-CR-TIEF4	98(133)	2016 ->	FAR 2029 M	FSO 1017/6	FEF 37 T	
M 126 GX DTC	Kubota V6108-TI-CRS	93(125)	2012 ->	FAR 2029 M	FSO 1013/2	FSF 912	
M 128 GX I / II	Kubota V6108-CR-TIE4	98(133)	2012 -> 2016	FAR 2029 M	FSO 1017/6	FEF 37 T	
				FAR 2029 M	FSO 1017/6	FSF 912	
M 135 GX I+II / GSX / XDT-C	Kubota V6108- TI-CRS	101(135)	2012 -> 2016	FAR 2029 M	FSO 1013/2	FEF 37 T	FSO 917/26 H
				FAR 2029 M	FSO 1017/6	FSF 912	FSO 917/31 H
M 95 GX	Kubota V3800-CR-TIEF4	77(104)	2016 ->	FAR 1635 M	FSO 99/9	FSF 811/4	
				FAR 933 S	FSO 99/9	FSF 811/4	
M135 GX III	Kubota V6108-CR-TIEF4	105(143)	2016 ->	FAR 2029 M	FSO 1017/6	FEF 37 T	
				FAR 2029 M	FSO 1017/6	FSF 912	
MK-Series							
MK 5000 4WD	Kubota V2403-M-DI-TM3-MX1	36(48)	2014 -> 2017	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
MX-Serie							
MX5000DT/F	V2403-M-EA PN1G813-00001	->(->)		FAR 1635/3 M			
MX5100F	V2403-M-TE3	->(->)		FAR 1635/3 M			









MX-Series							
MX 4700 DT (4WD Gear) / F (2WD (	Kubota V2403-E3-M	36(48)	2009 -> 2014	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
MX 4700 HST (4WD Hydro)	Kubota V2403-E3-M	36(48)	2009 -> 2014	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
MX 4800 DT / F / H	Kubota V2403-CR	37(49)	2014 ->	FAR 1230 M		FEF 37 T	FSO 917/31 H
				FAR 830 S		FEF 37 T	FSO 917/31 H
MX 5000 DT (4WD) / F (2WD)	Kubota V2403-M-EA	39(52)	2002 -> 2008	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 1635 M		FEF 58/1	FSO 917/31 H
MX 5100 DT (4WD Gear)	Kubota V2403-M-TE3	39(52)	2009 -> 2014	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
MX 5100 F (2WD Gear)	Kubota V2403-M-TE3	39(52)	2009 -> 2014	FAR 1635 M		FEF 58/1	FSO 917/31 H
				FAR 933 S		FEF 58/1	FSO 917/31 H
MX 5100 HST (4WD Hydro)	Kubota V2403-M-TE3	39(52)	2009 -> 2014	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
MX 5200 DT / F / H	Kubota V2403-CR-T	41(55)	2014 ->	FAR 1230 M		FEF 37 T	FSO 917/31 H
				FAR 830 S		FEF 37 T	FSO 917/31 H
MX 5400 DTC	Kubota V2403-CR-T	43(57)	2019 ->	FAR 1230 M			FSO 917/31 H
				FAR 830 S			FSO 917/31 H
MX 5400 F	Kubota V2403-CR-T	43(57)	2019 ->	FAR 1230 M			FSO 917/31 H
				FAR 830 S			FSO 917/31 H
MX 5400 H	Kubota V2403-CR-T	43(57)	2019 ->	FAR 1230 M			FSO 917/31 H
				FAR 830 S			FSO 917/31 H
MX 5800 HST	Kubota V2403-CR-T	46(61)	2015 ->	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
MX 6000 DTH-C / H	Kubota V2403-CR-T	47(63)	2019 ->	FAR 1230 M		FEF 58/1	FSO 917/31 H
				FAR 830 S		FEF 58/1	FSO 917/31 H
R-Serie (Compact Wheel Loaders)							
400	V1902	->(->)	->	FA 1629 MK			
400 / B / BU	->	28(38)	01/86 -> 12/87	FA 1629 MK			
410 (LST)	V1902	->(->)	->	FA 1629 MK			
410 / B	V1902	27(37)	01/88 ->	FA 1629 MK	FSO 910/5		
420 (LST) D1503-T	->	->(->)					FSO 917/14 H
420 / B	D1503T	28(38)	->	FA 1629 MK			
510 / B	V2203	35(48)	01/88 ->	FA 1629 MK	FSO 910/5		
510 NEW TYPE(LST)	V2203-DI-BDW	->(->)	->	FA 1629 MK			
510 NEW TYPE(LST) V2203-DI-BD\	->	->(->)					FSO 917/14 H
510 OLD TYPE(LST)	V2203-BDW	->(->)	->	FA 1629 MK			
510 OLD TYPE(LST) V2203-BDW	->	->(->)					FSO 917/14 H
520 / B	V2203	34.5(46)	->	FA 1629 MK			
520 S V2203-M-ERP	->	->(->)					FSO 917/14 H
520 V2203	->	->(->)					FSO 917/14 H
R520S	KUBOTA-V2203-M-E3	->(->)			FSO 98/1		
R-Series (Compact Wheel Loaders)							
65	Kubota V2607DI-E3	35(48)	2015 -> 2016	FAR 1230 M	FSO 99/9	FSF 77	FEO 48 H
				FAR 830 S	FSO 99/9	FSF 77	FEO 48 H
82	Kubota V2607DI-E3	35(47)	2017 ->	FAR 1230 M	FSO 99/9	FSF 77	FEO 48 H
				FAR 830 S	FSO 99/9	FSF 77	FEO 48 H
85	Kubota V2607CR	46(62)	2015 -> 2018	FAR 1230 M	FSO 99/9	FSF 914/6	FEO 48 H
				FAR 1432 M	FSO 99/9	FSF 914/6	FEO 48 H
310 (LST)	V1305			FA 1426 M	FSO 89	FSF 77	
310 / B / H	V1305-RP	18(25)	1988 ->	FA 1426 M	FSO 87	FSF 77	









R-Series (Compact Wheel Loaders)							
310 / B / H	V1305-RP	18(25)	1988 ->	FA 1426 M	FSO 88/3	FSF 77	
310 A	->			FA 1426 M	FSO 89	FSF 77	
400 / B / BU	->	28(38)	1986 -> 1987	FA 725 S			
410 / B	V1902	27(37)	1988 ->		FSO 99/6	FSF 77	
420 (LST)	D1503-T			FAR 1230 M		FSF 77	FSO 917/26 H
				FAR 830 S		FSF 77	FSO 917/26 H
420 / B	D1503T	28(38)		FAR 1230 M			
				FAR 830 S			
420 LS	->			FAR 1230 M			
				FAR 830 S			
420 S	D1503-M-T-E3	29(39)					FEO 48 H
420a	->		2004 -> 2013	FAR 1027/1 M			FEO 48 H
				FAR 626 MS			FSO 913/1 H
430	Kubota D1803-CR-TIE4-WL5	36(48)	2019 ->			FSF 912	FEO 48 H
						FSF 912	FSO 913/1 H
510 / B	V2203	35(48)	1988 ->	FA 725 S	FSO 99/6	FSF 77	
510 NEW TYPE(LST)	V2203-DI-BDW			FA 725 S			FSO 917/26 H
510 OLD TYPE(LST)	V2203-BDW			FA 725 S			FSO 917/26 H
510B NEW TYPE	->		1994 -> 1997			FSF 77	
510B OLD TYPE	->					FSF 77	
520	Kubota V2203-M-E3	32(44)		FAR 1230 M		FEF 37 T	FSO 917/26 H
				FAR 830 S		FSF 77	FSO 917/26 H
520 / B	V2203	35(46)		FAR 1230 M		FEF 37 T	
				FAR 830 S		FSF 77	
520 a	->		2004 -> 2013	FAR 1230 M			FSO 913/1 H
				FAR 830 S			FSO 913/1 H
520 S	V2203-M-ERP			FAR 1230 M	FSO 914/28		FEO 48 H
				FAR 830 S	FSO 914/28		FSO 917/26 H
520 S1	->			FAR 1230 M			
				FAR 830 S			
520 S2	->			FAR 1230 M			
				FAR 830 S			
630	Kubota V2607-CR-TE4 Tier4	48(64)		FAR 1432 M	FSO 99/9	FSF 914/6	FEO 48 H
				FAR 831 S	FSO 99/9	FSF 914/6	FEO 48 H
RTV-Series (Utility Vehicle)							
RTV 1100	Kubota D1105-E2-UV	18(25)	2011 ->	FAR 1027/1 M	FSO 89		
				FAR 626 MS	FSO 89		
RTV 1100 CW9 / RW9	Kubota D1105-E4-UV-2E	18(25)		FAR 1027/1 M			
				FAR 626 MS			
RTV 1140 CPX	Kubota D1105-E3-UV	18(25)			FSO 87		
RTV 400 Ci	SUBARU GH4120	11(16)	2013 ->	FAR 917/2 M	FSO 89		
				FAR 918 M	FSO 89		
RTV 500	Kubota GZ460F-E3-UV	12(16)	2013 -> 2017	FAR 416 TS	FSO 66/1		
				FAR 417 S	FSO 89		
RTV 900 G/G9/R/R6/R9/T/T5/T6/W/	Kubota D902-E2-KV	15(21)	2010 -> 2014	FAR 1027/1 M	FSO 66/1		
				FAR 417 S	FSO 89		
RTV-X 1100 CR / CW-A / CWI-A	Kubota D1105-E4-UV	19(25)	2014 ->		FSO 66/1		
RTV-X 1120 DR / DW-AS	Kubota D1105-E4-UV	19(25)	2014 ->		FSO 66/1		
RTV-X 1120 DW-HS / DWL-AS	Kubota D1105-E4-UV	19(25)	2014 ->		FSO 66/1		
RTV-X 900 G-A / G-H / R / W	Kubota D902-E2-KV	15(21)	2014 -> 2019		FSO 89		FSO 910/13 H
RTV-X-1110	Kubota D1105-E4-UV-2E	18(25)	2019 ->	FAR 1027/1 M			









RTV-Series (Utility Vehicle)							
RTV-X-1110	Kubota D1105-E4-UV-2E	18(25)	2019 ->	FAR 626 MS			
RW-Serie							
25	V1500BWD	->(->)			FSO 910/5		
30	V1902BDW	->(->)	->	FA 1629 MK			
30	V1902BDW	->(->)			FSO 910/5		
RW-Series (Baggerlader / Backhoe Loaders)							
25	V1500BWD			FA 1326 MK	FSO 99/6		
30	V1902BDW				FSO 99/6		
ST-Serie							
ST-25	V 1305	22.4(30)	01/96 ->			FEF 28	
ST-30	V 1505	25(33.5)	01/96 ->			FEF 28	
ST-Series							
ST 341 / C	Kubota D1703-E-TVCS	25(34)	2014 ->			FEF 38	FSO 917/31 H
ST 371 / C	Kubota D1803-E-TVCS	27(37)	2014 ->				FSO 917/31 H
ST 401 / C / R	Kubota D1803-E-TVCS	29(39)	2014 ->			FEF 38	FSO 917/31 H
ST Alpha 35 / D	Kubota D1703-EU	21(28)	2003 ->		FSO 810	FEF 38	FSO 910/13 H
ST-25	Kubota V1305	19(25)	1997 -> 2001		FSO 87		
ST-30	Kubota V1505	22(30)	1997 -> 2001	FA 1426 M		FEF 38	FSO 913/1 H
				FA 1426 M		FEF 58/1	FSO 913/1 H
STA-25	->	22(30)				FEF 38	FSO 910/13 H
STA-30	Kubota D1643	22(30)	2002 -> 2005		FSO 810	FEF 38	FSO 910/13 H
STA-35	->	26(35)	2002 -> 2005		FSO 810	FEF 38	FSO 910/13 H
STV-Series							
STV 32	Kubota D1503-M	24(32)	2006 -> 2014		FSO 810	FEF 38	FSO 910/13 H
STV 36	Kubota D1703-M	27(36)	2004 ->		FSO 810	FEF 38	FSO 910/13 H
STV 40	Kubota D1803-M	30(40)	2004 ->		FSO 810	FEF 38	FSO 910/13 H
STW-Series							
STW 34 / C	Kubota D1703-E-TVCS	25(34)	2014 ->			FEF 38	FSO 917/31 H
STW 34 D	Kubota D1703-M-EU39	25(34)	2017 ->			FEF 38	FSO 917/31 H
STW 37 / C	Kubota D1803-E-TVCS	27(37)	2014 ->			FEF 38	FSO 917/31 H
STW 40 / C	Kubota D1803-E-TVCS	29(39)	2014 ->			FEF 38	FSO 917/31 H
SVL-Serie							
SVL90	V3800-DI-TE3	->(->)		FAR 1635/3 M			
SVL-Serie (Tarım Makinaları)							
SVL75	->	->(->)		FAR 1333 M			
T-Serie (Tarım Makinaları)							
T1700H	->	->(->)		FA 1649 MS			
T1700HX	->	->(->)		FA 1649 MS			
T-Series (Lawn Tractor)							
T 1460 / S	Kawasaki FC420V	9(13)	1997 -> 2001		FSO 67/6		
T 1560 / S	Kawasaki FC420V	10(14)	1997 -> 2001		FSO 67/6		
T 1600 H	Kubota Z482	10(14)	1990 -> 1996		FSO 66/1		
					FSO 67/1		
T 1700 H	Kawasaki GH540V	13(17)	1990 -> 1996		FSO 67/6		
T 1700 HX	Kawasaki GH540V	13(17)			FSO 67/6		
T 1760 / S	Kawasaki FD501V	13(17)	1997 -> 2001		FSO 67/6		
T 1870 / A	Kohler	14(19)	2002 -> 2007		FSO 67/6		
TG-Series (Lawn Tractor)							
1860 A-48	Kubota D722-E-GX	13(18)		FAR 918 M	FSO 89		
1860 A-54 / 1860 AB-54	Kubota D722-E-GX	13(18)	1998 -> 2003	FAR 918 M	FSO 89		
1860 B-54	Kubota D722-E-GX	13(18)		FAR 918 M	FSO 89		









TG-Series (Lawn Tractor)							
1860 G-48 / 1860GA-48 / 1860 GAB	Kubota WG590V				FSO 67/6		
1860 G-54	Kubota WG590V				FSO 67/6		
1860 GA-54 / 1860GAB-54	Kubota WG590V				FSO 67/6		
1860-48	Kubota D722-E-GX	13(18)	1998 -> 2003	FAR 918 M	FSO 89		
1860-54	Kubota D722-E-GX	13(18)		FAR 918 M	FSO 89		
U-Serie							
U35-3S2	KUBOTA-D1703-M-E3	->(->)			FSO 98/1		
U45-3S	KUBOTA-V2203-M-E3	->(->)			FSO 98/1		
U-Series (Minibagger / Mini Excavators)							
080-4Alpha (<=40556)	Kubota V3307CR-TE4	47(63)	2016 -> 2019	FAR 1432 M	FSO 99/9	FSF 914/6	FEO 48 H
				FAR 831 S	FSO 99/9	FSF 914/6	FEO 48 H
10	D722BH	7(10)	1999 -> 2002	FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
10(EU)	->			FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
03.Eki	Kubota D722-BH-4	7(10)		FAR 917/2 M	FSO 87		
10Alpha	Kubota D722BH	7(10)	2001 -> 2003	FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
15 (T3)	D782E2U15			FA 1326 MK		FSF 77	
15 (T4)	D782-E2-BH-4			FAR 416 TS	FSO 89	FSF 77	
				FAR 917/2 M	FSO 89	FSF 77	
15-3	Kubota D782	10(13)	2011 ->	FAR 416 TS	FSO 89	FSF 77	
				FAR 917/2 M	FSO 89	FSF 77	
15-3	Kubota D782	10(14)	2005 -> 2008	FAR 416 TS	FSO 89	FSF 77	
				FAR 917/2 M	FSO 89	FSF 77	
17-3Alpha	Kubota D902	12(16)	2008 ->	FAR 416 TS	FSO 89	FSF 77	
				FAR 917/2 M	FSO 89	FSF 77	
20	->		1998 -> 2003	FAR 416 TS	FSO 89		
				FAR 917/2 M	FSO 89		
20-3	Kubota D1105-EBH-10	14(19)	2003 -> 2009	FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
20-3Alpha	Kubota D1105-E2-BH-12	14(19)		FAR 416 TS	FSO 87	FSF 77	
				FAR 917/2 M	FSO 89	FSF 77	
25 S	D1105-E2-U25 PN1J033-00001			FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
25-3	Kubota D1105-EBH-11	16(20)		FAR 416 TS	FSO 87		
				FAR 917/2 M	FSO 87		
25-3Alpha	Kubota D1105-E2-BH-13	15(20)		FAR 416 TS	FSO 87	FSF 77	
				FAR 917/2 M	FSO 89	FSF 77	
27-4 (57196)	Kubota :D1105-E4BH	16(22)	2015 ->	FAR 417 S	FSO 89	FSF 77	
				FAR 918 M	FSO 89	FSF 77	
27-4 (57197)	Kubota :D1105-E4BH	16(22)			FSO 89	FSF 77	
27-4 (57197)	Kubota D1105-E4-BH-2	15(21)			FSO 89	FSF 77	
27-4 HI	Kubota V3307CR-TE4	47(63)	2016 -> 2019		FSO 89	FSF 77	
27-4HI	Kubota D1105-E4-BH-2	15(21)			FSO 89	FSF 77	
30-3Alpha 2	Kubota D1503M-EBH	20(27)	2008 -> 2011		FSO 99/9	FSF 77	
35	D 1503-M-EBH-2	20(26)			FSO 99/9		
35 SS	D1503-M-E2BH-2-N				FSO 99/9	FSF 77	
35(EU)	->			FAR 1027/1 M	FSO 89	FEF 37 T	
				FAR 626 MS	FSO 89	FEF 37 T	
35-3	->				FSO 99/9		



U-Series (Minibagger / Mini Excavators)							
35-3Alpha	Kubota D1803-M				FSO 99/9	FSF 77	
35-3Alpha 2	Kubota D1503M-EBH-4EC-N	20(27)	2008 -> 2011		FSO 99/9	FSF 77	
35-3Alpha 3	Kubota D1803M-E3BH	23(31)	2007 -> 2011	FAR 1027/1 M	FSO 99/9	FSF 77	
				FAR 626 MS	FSO 99/9	FSF 77	
35-4	D1703MDIT4BHUS1					FSF 77	
36-4	Kubota D1703M-DI-E4	18(24)	2017 ->			FSF 77	
45	V2203-M-E2BH-2-N			FAR 1230 M		FEF 37 T	
				FAR 830 S		FSF 77	
45 S	V2203-M-E2BH-5-N			FAR 1230 M		FSF 77	
				FAR 830 S		FSF 77	
45-3	Kubota V2203-M-EBH-2	29(39)	2003 -> 2005	FAR 1230 M			
				FAR 830 S			
45-3Alpha	Kubota :V2203M	29(39)	2005 -> 2011	FAR 1230 M		FSF 77	
				FAR 830 S		FSF 77	
48-4	Kubota V2607-DI	33(46)	2010 ->	FAR 1230 M	FSO 99/9	FSF 77	FEO 48 H
				FAR 830 S	FSO 99/9	FSF 77	FEO 48 H
50-3Alpha	Kubota V2203M-EBH2	30(40)	2005 -> 2010	FAR 1230 M		FSF 77	
				FAR 830 S		FSF 77	
55	V2607-DI-E3			FAR 1230 M	FSO 99/9	FSF 77	FEO 48 H
				FAR 830 S	FSO 99/9	FSF 77	FEO 48 H
55-4	Kubota V2607-DI	34(46)		FAR 1230 M	FSO 99/9	FSF 77	FEO 48 H
				FAR 830 S	FSO 99/9	FSF 914/6	FEO 48 H
U35-3a2	->				FSO 99/9	FSF 77	
V-Series							
3600-E3B	->	50(68)			FSO 99/9		
Z200-Series (Turn Mower)							
ZG 222 A Zero	Kubota KGZ770-E2-M3	16(22)		FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 66/1		
ZG 222 Zero	Kubota KGZ770-E2-M3	16(22)		FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 66/1		
ZG 222-48 Zero	Kubota KGZ770-E2-M3	16(22)		FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 66/1		
ZG 227 / 227 A Zero	Kubota KGZ770-E2-M2	20(27)	2008 ->	FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 66/1		
ZG 227-54 Zero	Kubota KGZ770-E2-M2	20(27)		FAR 416 TS	FSO 66/1		
				FAR 917/2 M	FSO 66/1		
Z300-Series (Turn Mower)							
ZG 327 P / 327-60 Zero	Kubota KGZ770-E2-MA1	20(27)	2008 ->		FSO 87		FSO 910/13 H
ZG 332 P-60 / ZG 332 LP-72 Zero	Kubota KGZ770-E2-MA1	24(33)			FSO 66/1		FSO 910/13 H
ZP 330 LP-72 Zero	Kubota WG972-GL-E3-ZG-1	23(31)	2012 ->		FSO 66/1		FSO 910/13 H
ZP 330 P-60 Zero	Kubota WG972-GL-E3-ZG	23(31)			FSO 66/1		FSO 910/13 H
ZD-Series (Turn Mower)							
1011 Zero	Kubota D782-E4-ZD-3	14(19)	2016 ->	FAR 417 S	FSO 87		
				FAR 918 M	FSO 87		
1021 Zero	Kubota D902-E4	16(22)	2019 ->	FAR 417 S	FSO 87		
				FAR 918 M	FSO 87		
1211 Zero	Kubota D1105-E4-ZD-2	19(25)	2017 ->	FAR 1125			FSO 910/13 H
				FAR 523 S			FSO 910/13 H
18 Zero	Kubota D722	13(18)	2001 -> 2006	FAR 918 M	FSO 87		
21 EC Zero	Kubota D782-E-XFM5	15(21)	2001 -> 2006	FAR 918 M	FSO 89		
21 Zero	Kubota D782-E3	15(21)	2001 -> 2006	FAR 918 M	FSO 89		










ZD-Series (Turn Mower)							
221 Zero	Kubota D782-E3-ZD-1	15(21)	2008 ->	FAR 417 S	FSO 87		
				FAR 918 M	FSO 87		
25 F Zero	Kubota D1005-E2-ZD	19(25)	2005 -> 2006	FAR 918 M	FSO 87		
28 / EC Zero	Kubota D1005-E2-ZD	21(28)	2002 -> 2006	FAR 918 M	FSO 87		
321 / N / S Zero	Kubota D782-E2-ZD-2	19(26)	2007 -> 2011	FAR 417 S	FSO 87		FSO 910/13 H
				FAR 918 M	FSO 87		FSO 910/13 H
323 Zero	Kubota D902-E3-ZD	17(23)	2008 ->	FAR 1125	FSO 87		FSO 910/13 H
				FAR 523 S	FSO 87		FSO 910/13 H
326 + II Zero	Kubota D1005-E2-ZD-2	19(26)	2007 ->	FAR 1125			FSO 910/13 H
				FAR 523 S			FSO 910/13 H
331 Zero	Kubota D1305-E3-ZD	23(31)	2007 ->	FAR 1125	FSO 87		FSO 910/13 H
				FAR 523 S	FSO 87		FSO 910/13 H
ZG-Series (Turn Mower)							
ZG 20 Zero	Kohler GH630	15(20)	2003 -> 2007		FSO 810		
ZG 23 Zero	Kohler GH680	17(23)	2003 -> 2007		FSO 810		
ZG 23-54 Zero	Kohler GH680	17(23)	2003 -> 2007		FSO 810		

FERRAFILTER®

ÖLÇÜLER
MEASUREMENT

HAVA FİLTRESİ
AIR FILTER

DÜZ
FLAT



OVAL




YUVARLAK
ROUND




YAĞ FİLTRESİ
OIL FILTER

FİLTRE ELEMANI
FILTER ELEMENT



FİLTRE ELEMANI
(METAL İÇERMEZ)
FILTER ELEMENT (METAL FREE)



VİDA DİŞLİ FİLTRE
SPIN-ON FILTER



YAKIT FİLTRESİ
FUEL FILTER

FİLTRE ELEMANI
FILTER ELEMENT



SIRALI FİLTRE
INLINE FILTER



SIRALI FİLTRE
(YÜK. BAĞLANTILI)
INLINE FILTER
(Conn. On Top)




VİDA DİŞLİ FİLTRE
SPIN-ON FILTER



İÇ MEKAN FİLTRESİ
CABIN FILTER

DÜZ
FLAT



YUVARLAK
ROUND



Web : www.ferrafilter.com e-mail : info@ferrafilter.com

FERRAFILTER®

Kubota

Air Filter

FAR 2029 M

REPLACES		APPLICATION			DIMENSIONS
BALDWIN	RS3882	●M-Series	●M115GXDTCIV●M115GXIII●M125GXDTCIV●M125GXDTSCIV●M125GXIII●M125X●M125XDT/XDTC●M126GXDTC●M126XDTC/XDTPC●M128/X/XDT-C●M128GXI/II●M130XDTC●M135GXI+II/GSX/XDT-C●M135GXIII●M135XDTC	●KubotaF5802-TE2 | 2002->2004●KubotaF5802-TE2 | 2004->2008●KubotaV6108-CR-TIE4 | 2012->2016●KubotaV6108-CR-TIE4 | 2016->2018●KubotaV6108-CR-TIE4 | 2018->●KubotaV6108-CR-TIEF4 | 2016->●KubotaV6108	A : 206 B : 105 H : 295
DONALDSON	P537405	●MGXIII-Series			
FLEETGUARD	AF25886	●MGXIV-Series			
MANN FILTER	C 21 430/2	●MGX-Series			



FA 725 S

REPLACES		APPLICATION			DIMENSIONS
KUBOTA	1500037111	●KX-Series(Minibagger/MiniExcavators)	●121-2●121-2S●161-2●161-2S●400/B/BU●510/B●510NEWTYPE(LST)●510OLDTYPE(LST)●L2850/DT/GST/F/R●L3250/F(2WD)/DT(4WD)●L3350HDT/MDT●L3750/F(2WD)/DT(4WD)●L4150DT-Narrow/F/DT●L5450DT●M4050/D	●-> | 1986->1987●KubotaD1702-DI-A | 1985->1993●KubotaF2302-D1-L | 1984->1990●KubotaF2302-DI-2 | 1984->1990●KubotaF2803-DI | 1991->1997●KubotaS2600-AL | 1982->1985●KubotaV1902-DI-A | 1985->1990●K	A : 65 B : 54 C : 17 D : 80,5 H : 254,5
KUBOTA	1561211180				
KUBOTA	1738111181				
KUBOTA	6833543620	●L-Series			
KUBOTA	6833543621	●L2-Series			
BALDWIN	PA2489	●M-Series			
DONALDSON	P123160	●M50-Series			
FLEETGUARD	AF1966	●R-Series(CompactWheelLoaders)			
MANN FILTER	CF 75/1				



FA 1018 K

REPLACES		APPLICATION			DIMENSIONS
KUBOTA	1522111220	●B02-Series ●B1000-Series ●B4000-Series ●B5000-Series ●B6000-Series ●B7000-Series ●B8000-Series ●Bulltra-Series ●F-Series/FZ-Series(Front-mountMower) ●KH-Series(Minibagger/MiniExcavators) ●KX-Series(Minibagger/MiniExcavators) ●L02-Series ●L100-Series ●L1000-Series ●L2-Series	●005●008●008-1●008-2,008-3●012●021●024●030●031●035●036●041●36(H)●36/G/HG●61●61(H)●B1-14●B1-15●B1-16●B1-17●B1200●B1402●B1502●B1702●B1902●B4200D●B5000●B5001●B5100/DT/E●B5200/D/E●B6001	●-> | ●D662B4 | 1991->●D850 | ●D850-BH-W | ●D950 | ●D950-BH-2 | ●D950BH2 | ●KubotaD1101 | 1975->1978●KubotaD1102 | 1978->1985●KubotaD1102 | 1982->1988●KubotaD1102-A | 1991->1998●KubotaD1102-	A : 84 B : 45 C : 11 D : 105,5 H : 187
KUBOTA	1522111223				
KUBOTA	1522111224				
KUBOTA	1522111221				
KUBOTA	1522111230				
KUBOTA	1522211220				
KUBOTA	1522211221				
BALDWIN	PA1865-FN				
DONALDSON	P102745				
FLEETGUARD	AF1658K				
MANN FILTER	C 934				



FA 1018 MK

REPLACES		APPLICATION			DIMENSIONS
KUBOTA	1522111220	●B02-Series ●B1000-Series ●B4000-Series ●B5000-Series ●B6000-Series ●B7000-Series ●B8000-Series ●Bulltra-Series ●F-Series/FZ-Series(Front-mountMower) ●KH-Series(Minibagger/MiniExcavators) ●KX-Series(Minibagger/MiniExcavators) ●L02-Series ●L100-Series ●L1000-Series ●L2-Series	●005●008●008-1●008-2,008-3●012●021●024●030●031●035●036●041●36(H)●36/G/HG●61●61(H)●B1-14●B1-15●B1-16●B1-17●B1200●B1402●B1502●B1702●B1902●B4200D●B5000●B5001●B5100/DT/E●B5200/D/E●B6001	●-> | ●D662B4 | 1991->●D850 | ●D850-BH-W | ●D950 | ●D950-BH-2 | ●D950BH2 | ●KubotaD1101 | 1975->1978●KubotaD1102 | 1978->1985●KubotaD1102 | 1982->1988●KubotaD1102-A | 1991->1998●KubotaD1102-	A : 84 B : 45 C : 11 D : 105,5 H : 187
KUBOTA	1522111223				
KUBOTA	1522111224				
KUBOTA	1522111221				
KUBOTA	1522111230				
KUBOTA	1522211220				
KUBOTA	1522211221				
BALDWIN	PA1865-FN				
DONALDSON	P102745				
FLEETGUARD	AF1658K				
MANN FILTER	C 934				



FERRAFILTER®

Kubota

Air Filter

REPLACES		APPLICATION			DIMENSIONS	FA 1326 MK
KUBOTA	1510411080	●KH-Series(Minibagger/MiniExcavators) ●KX-Series(Minibagger/MiniExcavators) ●L-Series ●L02-Series ●L2-Series ●L200-Series ●L2000-Series ●L50-Series ●M-Series ●M50-Series ●RW-Series(Baggerlader/BackhoeLoaders) ●U-Series(Minibagger/MiniExcavators)	●001.1D●011●014●015●016W●020●026●027●028●030●050●051●060●066●090●10(51041)●10(51042)●101●15(T3)●25●71-2Alpha●91●91-2●91-2S●L2-602/HSTC●L2202●L2250F/DT●L235●L2402●L2650DT/DW/GST●L265	●-> | ●D1100BH | ●D1101 | ●D1301BH | ●D1302 | ●D1302BH | ●D1402-BH-5 | ●D1402-DI-AE | 1991->1993●D1402BH | ●D1402BH4 | ●D1402BH5 | ●D1505EB | 2001->2004●D782E2U15 | ●D950BH | ●KubotaD1102	A : 104 B : 62,5 C : 17 D : 128 H : 265,5	
KUBOTA	1522111080					
KUBOTA	1528711081					
KUBOTA	1528711491					
KUBOTA	1528711080					
KUBOTA	1540111081					
KUBOTA	1540111080					
BALDWIN	LL1690-FN					
DONALDSON	P101275					
FLEETGUARD	AF25442					
MANN FILTER	C 1188					

REPLACES		APPLICATION			DIMENSIONS	FA 1426 M
KUBOTA	15 74111080	●B2000-Series ●B9000-Series ●KX-Series(Minibagger/MiniExcavators) ●R-Series(CompactWheelLoaders) ●ST-Series	●310(LST)●310/B/H●310A●71●71H●B2150DT/E/HSE/HSD●B9200D/E/HSD-TOW/HST-D/HST-E●ST-30	●-> | ●KubotaV1200-5B | 1988->1996●KubotaV1200-A | 1986->1990●KubotaV1505 | 1997->2001●V1305 | ●V1305-RP | 1988->●V1502B4 | 1991->●V1505-BH |	A : 104 B : 63 C : 7,5 D : 146 H : 269	
KUBOTA	1574111083					
KUBOTA	1574111081					
KUBOTA	1754111081					
BALDWIN	PA3476					
DONALDSON	P535362					
FLEETGUARD	AF4939					
MANN FILTER	C 11 004					

REPLACES		APPLICATION			DIMENSIONS	FA 1629 MK
KUBOTA	1500037101	●KH(Minibagger/MiniExcavators) ●KX(Minibagger/MiniExcavators) ●L2000-Serie ●L300-Serie ●L3000-Serie ●L4000-Serie ●L5000-Serie ●M-Serie ●R-Serie(CompactWheelLoaders) ●RW-Serie	●101●121-2●121-2S●130●151●161-2●170L●18●191●2.0D●2.5GT●2.5i●28●3.6V6●30●33●40●400●400/B/BU●410(LST)●410/B●420/B●44683●45●510/B●510NEWTYPE(LST)●510OLDTYPE(LST)●520/B●55●60●90●L2850●L	●-> | ->●-> | ->01/90●-> | 01/85->●-> | 01/86->12/87●-> | 02/08->08/13●-> | 09/07->●-> | 09/09->●D1462-DI-AE | ->●D1503T | ->●EJ255 | 07/10->●F2302-DI | 01/88->●F2803-DI | ->●FB25 | 07/12->	A : 133 B : 66 C : 17 D : 157 H : 290	
KUBOTA	1560611080					
KUBOTA	1560611081					
KUBOTA	1560611211					
KUBOTA	1560611221					
KUBOTA	1576311081					
KUBOTA	1943311080					
BALDWIN	LL1667-FN					
DONALDSON	P105501					
FLEETGUARD	AF1956KM					
MANN FILTER	C 14 179					

REPLACES		APPLICATION			DIMENSIONS	FA 1649 MS
DONALDSON	P124047	●T-Serie(TarımMakinaları)	●T1700H●T1700HX	●-> | ->	A : 163 B : 134 C : 17 H : 495	
FLEETGUARD	AF976					

FERRAFILTER®

Kubota

Air Filter

REPLACES		APPLICATION			DIMENSIONS	FA 1916/1 MK
KUBOTA KUBOTA FLEETGUARD	1545111080 7000017500 AF25373K	●M-Serie(TarımMakinaları)	●M5500●M5500DT●M7500●M7500ACL●M7500DT●M7500DT-ACL	●-> | ->	A : 155 B : 86 C : 12 D : 192 H : 158	

REPLACES		APPLICATION			DIMENSIONS	FA 2026 M
FLEETGUARD MANN FILTER	AF4733 C 20 326	●M-Serie(TarımMakinaları)	●M8950DTS---60001●M8950S---60001●M8970●M9580●M9580DT	●-> | ->●KUBOTA-V4702 | ->	A : 200 B : 134 C : 23 H : 268	

REPLACES		APPLICATION			DIMENSIONS	FAR 416 TS
KUBOTA KUBOTA BALDWIN FLEETGUARD MANN FILTER	3272158240 3272158242 PA4633 AF25151 CF 5001	●B-Series ●B01-Series ●B1-Series ●B10-Series ●B2-Series ●B20-Series ●B2000-Series ●B30-Series ●B3000-Series ●B50-Series ●B7000-Series ●F80-Series ●F90-Series ●K-Series(Minibagger/MiniExcavators) ●KC-Series(MiniDumpers)	●008-3●10●10(EU)●10Alpha●110HR-4●15(T4)●15-3●17-3Alpha●20●20-3●20-3Alpha●25-3●25-3Alpha●25S●36-3●41-2Alpha●41-3●41-3S(>=55001)●41-3V(>=55001)●B1241/D-EC●B1610/D●B1610D●B1700/D/F●B17	●-> | ●-> | 1998->2003●D1105-E2-U25PN1J033-00001 | ●D722 | 1997->2002●D722-EBH-3PN1J021-00001 | ●D722BH | 1999->2002●D782-E | ●D782-E2-BH-4 | ●KubotaD1005-D10 | 1995->1999●KubotaD1005-E-3D22 |	A : 40 B : 31 D : 42,5 H : 163,5	

REPLACES		APPLICATION			DIMENSIONS	FAR 417 S
KUBOTA KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	7200000525 K756182360 RG15842920 RS3930 P535396 AF25967 CF 52	●BX-70Series ●BX-80Series ●KX-Series(Minibagger/MiniExcavators) ●RTV-Series(UtilityVehicle) ●U-Series(Minibagger/MiniExcavators) ●ZD-Series(TurnMower)	●016-4●018-4●019-4●1011Zero●1021Zero●1870/1870-1●1880●221Zero●2370/2370-I●2380●2670/2670-1●27-4(57196)●321/N/SZero●RTV500●RTV900G/G9/R/R6/R9/T/T5/T6/W/W6/W9	●KuboD902E3BH3 | 2011->●Kubota:D1105-E4BH | 2015->●KubotaD1005 | 2013->2014●KubotaD722 | 2013->2014●KubotaD722 | 2017->●KubotaD782-BH | 2011->●KubotaD782-E2-ZD-2 | 2007->2011●KubotaD782-E3-ZD-1	A : 43 B : 28 D : 46 H : 174	

REPLACES		APPLICATION			DIMENSIONS	FAR 523 S
KUBOTA	K318182250	●ZD-Series(TurnMower)	●1211Zero●323Zero●326+IIZero●331Zero	●KubotaD1005-E2-ZD-2 | 2007->●KubotaD1105-E4-ZD-2 | 2017->●KubotaD1305-E3-ZD | 2007->●KubotaD902-E3-ZD | 2008->	A : 54 B : 41 D : 57 H : 239	
KUBOTA	K318182251					
BALDWIN	RS3991					
DONALDSON	P780018					
FLEETGUARD	AF25726					
MANN FILTER	CF 100					

REPLACES		APPLICATION			DIMENSIONS	FAR 626 MS
KUBOTA	TA04093220	●F90-Series ●KX-Series(Minibagger/MiniExcavators) ●L-Series ●L02-Series ●L1-Series ●L10-Series ●L2-Series ●L2000-Series ●L30-Series ●L3000-Series ●L40-Series ●L60-Series ●R-Series(CompactWheelLoaders) ●RTV-Series(UtilityVehicle) ●U-Series(Minibagger/MiniExcavators)	●101-3Alpha3●101-3Alpha4●35(EU)●35-3Alpha3●420a●F3990●L1-421/DW/HDW●L1361DT/HST●L1361F●L1361H●L1361T●L2-351HSTC●L2-421DT-C/HSTC●L2500F/DT●L2800DT/F/DHV/DHW●L2900DT/GST●L2900DTN	●-> | ●-> | 2004->2013●KubotaD1105-E2-UV | 2011->●KubotaD1105-E4-UV-2E | ●KubotaD1105-E4-UV-2E | 2019->●KubotaD1301-DA | 1979->1985●KubotaD1403-AE | 1998->2000●KubotaD1403-M-E2A | 2004->2008●Ku	A : 58 B : 44 D : 60 H : 262,8	
BALDWIN	RS3705					
DONALDSON	P822858					
FLEETGUARD	AF25576					
MANN FILTER	CF 75/2					

REPLACES		APPLICATION			DIMENSIONS	FAR 630 S
KUBOTA	TD27063221	●L02-Series ●L1-Series ●L2-Series ●L40-Series ●L60-Series	●L1-501DW/HDW●L2-501●L2-501DCN/DT/HSTC●L2-602/HSTC●L4760GST/HST/HSTC-C(Cab)●L5040DT/GST/GSTC/GC/GST-III●L5060GST●L5240/HC/HST/HST-C/HST-CII●L5460HST/HSTC●L5740/HC/HST/HSTIII/HST-CII	●KubotaD1703-M-DI-E4 | 2018->●KubotaV2403-CR-E | 2013->●KubotaV2403-CR-T | 2018->●KubotaV2403-CR-T4 | 2013->●KubotaV2403-CR-TE4 | 2013->●KubotaV2403-M-T | 2007->2013●KubotaV2403-M-TE2 | 2007->●K	A : 65,5 B : 51 D : 68 H : 305	
KUBOTA	TD27093220					
KUBOTA	TD27093221					
BALDWIN	RS3943					
DONALDSON	P780024					
FLEETGUARD	AF25728					
MANN FILTER	CF 200					

REPLACES		APPLICATION			DIMENSIONS	FAR 830 S
KUBOTA	R240142280	●KC-Series(MiniDumpers) ●KX-Series(Minibagger/MiniExcavators) ●L-Series ●L30-Series ●M-Series ●M700-Series ●ME-Series ●ME700-Series ●MK-Series ●MX-Series ●R-Series(CompactWheelLoaders) ●U-Series(Minibagger/MiniExcavators)	●057-4●065●082●085●121-3●121-3Alpha●121-3R3●121-3R4A●121-3S●121-3S3●121-3S4A●121alpha(>=70001)●161-3●161-3Alpha●161-3R1●161-3R2●161-3S1●161-3S2●161-3ST●250HR-4●251●251-2●251Alpha●42	●-> | ●-> | 2004->2013●D1503-T | ●D1503T | ●Kubota:V2203M | 2005->2011●KubotaD1803-CR-E4 | 2014->●KubotaF2803-EA | 1995->1999●KubotaF2803-EA | 2000->2005●KubotaF2803-EA | 2001->2005●KubotaF280	A : 79,4 B : 62 D : 83,6 H : 297	
KUBOTA	R240142281					
KUBOTA	R551142250					
KUBOTA	RD45242280					
KUBOTA	RD45242281					
BALDWIN	RS3703					
DONALDSON	P822769					
FLEETGUARD	AF25497					
MANN FILTER	CF 97/2					

FERRAFILTER®

Kubota

Air Filter

REPLACES		APPLICATION			DIMENSIONS	FAR 831 S
KUBOTA	3A11119130	●KX-Series(Minibagger/MiniExcavators) ●L40-Series ●M-Series ●M40-Series ●M4002-Series ●M4003-Series ●M60-Series ●R-Series(CompactWheelLoaders) ●U-Series(Minibagger/MiniExcavators	●080-3●080-3a●080-3T●080-4●080-4Alpha(<=40556)●080-4Alpha(KBCK0804)●085●630●80-4a(40556+40557=>)●L4740●L4740GST-III●L4740HST-III/HSTC-III●L5040DT/GST/GSTC/GC/GST-III●L5240/HC/HST/HS	●KubotaD722BH5 | 2008->●KubotaV2403-M-E2 | 2007->2013●KubotaV2403-M-E3-GST1 | 2007->2013●KubotaV2403-M-E3-HST1 | 2007->2013●KubotaV2403-M-T | 2007->2013●KubotaV2403-M-TE2 | 2007->●KubotaV2403-M-T	A : 78 B : 62 D : 83,6 H : 317	
KUBOTA	R561142250					
BALDWIN	RS3543					
DONALDSON	P775300					
FLEETGUARD	AF25484					
MANN FILTER	CF 850/2					

REPLACES		APPLICATION			DIMENSIONS	FAR 917/2 M
KUBOTA	6A10082630	●B-Series ●B01-Series ●B1-Series ●B10-Series ●B1000-Series ●B2-Series ●B20-Series ●B2000-Series ●B30-Series ●B3000-Series ●B50-Series ●B7000-Series ●F60-Series(Frontmäher/Front-mountmower) ●F80-Series ●F90-Series	●008-3●10●10(EU)●10-3●100HD●10Alpha●110HR-4●15(T4)●15-3●17-3Alpha●20●20-3●20-3Alpha●25-3●25-3Alpha●25S●36-3●41-2Alpha●41-3●41-3S(>=55001)●41-3V(>=55001)●B1121D/D-EC●B1161/D-EC●B1181	●-> | ●-> | 1998->2003●D1105-E2-U25PN1J033-00001 | ●D722 | 1997->2002●D722-EBH-3PN1J021-00001 | ●D722BH | 1999->2002●D782-E | ●D782-E2-BH-4 | ●KubotaD1005 | ●KubotaD1005-D10 | 1995->1999●Kubo	A : 90 B : 43,5 H : 179	
KUBOTA	6A10082632					
KUBOTA	6C06099410					
KUBOTA	6C6099410					
KUBOTA	E1100780					
KUBOTA	K731182390					
BALDWIN	RS5273					
FLEETGUARD	AF26161					
MANN FILTER	C 9002					

REPLACES		APPLICATION			DIMENSIONS	FAR 918 M
KUBOTA	1665911221	●B-Series ●B01-Series ●B1-Series ●B10-Series ●B1000-Series ●B2-Series ●B20-Series ●B2000-Series ●B30-Series ●B3000-Series ●B50-Series ●B7000-Series ●BX-50Series ●BX-60Series ●BX-70Series	●008●016-4●018-4●019-4●1011Zero●1021Zero●1600EC●1600ECII●1800D●1830D●1850D●1860-48●1860-54●1860A-48●1860A-54/1860AB-54●1860B-54●1860D●1870/1870-1●1880●18Zero●2020G●2100●2100EC/II●21	●-> | ●-> | 2004->2008●KohlerGH631 | 2010->●KuboD902E3BH3 | 2011->●Kubota:D1105-E4BH | 2015->●KubotaD1005 | ●KubotaD1005 | 2013->2014●KubotaD1005-D10 | 1995->1999●KubotaD1005-E-3D22 | 2008->201	A : 90 B : 44 H : 187,5	
KUBOTA	1865911221					
KUBOTA	1G65911221					
KUBOTA	1G65911222					
KUBOTA	K121182320					
KUBOTA	K121182321					
KUBOTA	K258182311					
BALDWIN	PA1702 Ele.					
DONALDSON	P822686					
FLEETGUARD	AF25538					
MANN FILTER	C 946					

REPLACES		APPLICATION			DIMENSIONS	FAR 933 S
KUBOTA	5523126150	●M--40-Series ●M-Series ●M40-Series ●M40N-Series ●M5001N-Series ●M5001-Series ●M5002-Series ●M60-Series ●ME-Series ●MGXIII-Series ●MGXIV-Series ●MGX-Series ●MX-Series	●M100GX●M100GXDTC●M100GXIII●M100XDTC●M105GX●M105GX-III●M105GX-IV●M105S/SDSC/SDT/SHC/SHDC/XDTC●M108●M108S●M108SDT●M108SDTC●M108XDTC●M110GXI+II/GXDTC●M110XDTC●M5-092H(ROPS)●M5-092HC(C	●-> | ●KubotaV2403-M-EA | 2002->2008●KubotaV2403-M-TE3 | 2009->2014●KubotaV3300-TE | ●KubotaV3300-TE | 1997->2005●KubotaV3300-TE | 1997->2010●KubotaV3300-TIE | 1997->2005●KubotaV3300T-IE | 2003-	A : 88 B : 72 D : 94,5 H : 344,5	
BALDWIN	PA3783					
DONALDSON	P775302					
FLEETGUARD	AF25485					
MANN FILTER	CF 990/2					

FERRAFILTER®

Kubota

Air Filter

REPLACES		APPLICATION			DIMENSIONS	FAR 1027/1 M
KUBOTA	HWTAT93230	●F90-Series ●KX-Series(Minibagger/MiniExcavators) ●L-Series ●L02-Series ●L1-Series ●L10-Series ●L2-Series ●L2000-Series ●L30-Series ●L3000-Series ●L40-Series ●L60-Series ●R-Series(CompactWheelLoaders) ●RTV-Series(UtilityVehicle) ●U-Series(Minibagger/MiniExcavators)	●101-3Alpha3●101-3Alpha4●161-2S●35(EU)●35-3Alpha3●420a●F3990●L1-421/DW/HDW●L1361DT/HST●L1361F●L1361H●L1361T●L2-351HSTC●L2-421DT-C/HSTC●L2500F/DT●L2800DT/F/DHV/DHW●L2900DT/GST●L2900D	●-> | ●-> | 2004->2013●KubotaD1105-E2-UV | 2011->●KubotaD1105-E4-UV-2E | ●KubotaD1105-E4-UV-2E | 2019->●KubotaD1301-DA | 1979->1985●KubotaD1403-AE | 1998->2000●KubotaD1403-M-E2A | 2004->2008●Ku	A : 105,5 B : 60 H : 274,3	
KUBOTA	TA04093230					
KUBOTA	TA04093231					
BALDWIN	RS3704					
DONALDSON	P821575					
FLEETGUARD	AF25575					
MANN FILTER	C 1196/2					

REPLACES		APPLICATION			DIMENSIONS	FAR 1125
KUBOTA	K318182240	●ZD-Series(TurnMower)	●1211Zero●323Zero●326+IIZero●331Zero	●KubotaD1005-E2-ZD-2 | 2007->●KubotaD1105-E4-ZD-2 | 2017->●KubotaD1305-E3-ZD | 2007->●KubotaD902-E3-ZD | 2008->	A : 111 B : 62 H : 254	
KUBOTA	K318182241					
BALDWIN	RS3990					
DONALDSON	P778979					
FLEETGUARD	AF25725					
MANN FILTER	C 11 100					

REPLACES		APPLICATION			DIMENSIONS	FAR 1230 M
KUBOTA	R140142270	●KC-Series(MiniDumpers) ●KX-Series(Minibagger/MiniExcavators) ●L-Series ●L30-Series ●M-Series ●M700-Series ●ME-Series ●ME700-Series ●MK-Series ●MX-Series ●R-Series(CompactWheelLoaders) ●U-Series(Minibagger/MiniExcavators)	●057-4●065●082●085●121-3●121-3Alpha●121-3R3●121-3R4/R4A●121-3R4A●121-3S●121-3S3●121-3S4/S4A●121-3S4A●121alpha(>=70001)●161-3●161-3Alpha●161-3R1●161-3R2●161-3S1●161-3S2●161-3ST●250HR	●-> | ●-> | 2004->2013●D1503-T | ●D1503T | ●Kubota:V2203M | 2005->2011●KubotaD1803-CR-E4 | 2014->●KubotaF2803-EA | 1995->1999●KubotaF2803-EA | 2000->2005●KubotaF2803-EA | 2001->2005●KubotaF280	A : 126 B : 82 H : 312,5	
KUBOTA	R140142280					
KUBOTA	R551142270					
KUBOTA	RD45242270					
KUBOTA	RD45242271					
BALDWIN	RS3549					
DONALDSON	P532410					
FLEETGUARD	AF25308					
MANN FILTER	C 13 145/2					

REPLACES		APPLICATION			DIMENSIONS	FAR 1232
KUBOTA	TD27093230	●L40-Series ●L60-Series	●L4760GST/HST/HSTC-C(Cab)●L5040DT/GST/GSTC/GC/GST-III●L5060GST●L5460HST/HSTC●L6060HST(ROPS), HSTC(Cab)	●KubotaV2403-CR-E | 2013->●KubotaV2403-CR-T4 | 2013->●KubotaV2403-CR-TE4 | 2013->●KubotaV2403-M-T | 2007->2013	A : 121 B : 73 D : 122 H : 321	
BALDWIN	RS3942					
DONALDSON	P778984					
FLEETGUARD	AF25727					
MANN FILTER	C 14 200					

FERRAFILTER®

Kubota

Air Filter

REPLACES	APPLICATION			DIMENSIONS	FAR 1232 X
	●L4000-Serie(TarımMakinaları) ●L5000-Serie(TarımMakinaları) ●L6000-Serie(TarımMakinaları)	●L4060DT/GST●L4060HST●L4060HSTC●L4740GST-3●L4740HST-3/HSTC-3●L4760GST●L4760HST●L4760HSTC●L5040GST-3●L5060GST●L5240HST-3●L5460HST●L5460HSTC●L5740HST-3/HSTC-3●L6060HST●L6060HSTC	●-> | ->	A : 122 B : 74 H : 320	

REPLACES		APPLICATION			DIMENSIONS	FAR 1333 M
DONALDSON FLEETGUARD MANN FILTER	P827653 AF25555 C 14 202/1	●KX-Serie(Minibagger/MiniExcavators)(İnşaatveMadenMakinaları) ●L40-Serie(TarımMakinaları) ●L4000-Serie(TarımMakinaları) ●L5000-Serie(TarımMakinaları) ●M**40-Serie(TarımMakinaları) ●M-Serie(TarımMakinaları) ●M800-Serie(TarımMakinaları) ●SVL-Serie(TarımMakinaları)	●080-3●080-3T●L4740●L5040-GSTC●L5040GST●L5040GSTC●L5240●L5240-HSTC●L5240HSTC●L5740●L5740-HSTC●L5740HSTC●M5040/DT●M5040HDC●M59●M6040●M6040DT●M6040DTH●M6040DTH-C●M6040DTHC●M6040DTHNB●	●-> | ->	A : 137 B : 80,5 H : 327	

REPLACES		APPLICATION			DIMENSIONS	FAR 1432 M
KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	5980026110 R561142270 RS3542 P772579 AF25291 C 14 210/2	●KX-Series(Minibagger/MiniExcavators) ●M-Series ●R-Series(CompactWheelLoaders) ●U-Series(Minibagger/MiniExcavators)	●080-3●080-3T●080-4●080-4Alpha(<=40556)●085●630●80-4a(40556+40557=>)●M7040DTH-C	●KubotaD722BH5 | 2008->●KubotaV2607-CR-TE4Tier4 | ●KubotaV2607CR | 2015->2018●KubotaV3307-DI-E2-1-SS | 2012->●KubotaV3307CR-TE4 | ●KubotaV3307CR-TE4 | 2013->2016●KubotaV3307CR-TE4 | 2016->2019●V	A : 140 B : 83,5 H : 327	

REPLACES		APPLICATION			DIMENSIONS	FAR 1432/1 M
BALDWIN DONALDSON FLEETGUARD MANN FILTER	RS3542 P783403 AF25291 C 14 101	●KX-Series(Minibagger/MiniExcavators) ●L40-Series ●M-Series ●M40-Series ●M4002-Series ●M4003-Series ●M60-Series	●080-3●080-3a●080-4●080-4Alpha(KBCK0804)●80-4a(40556+40557=>)●L4740●L4740GST-III●L4740HST-III/HSTC-III●L5040DT/GST/GSTC/GC/GST-III●L5240/HC/HST/HST-C/HST-CII●L5740/HC/HST/HSTIII/HST	●KubotaD722BH5 | 2008->●KubotaV2403-M-E2 | 2007->2013●KubotaV2403-M-E3-GST1 | 2007->2013●KubotaV2403-M-E3-HST1 | 2007->2013●KubotaV2403-M-T | 2007->2013●KubotaV2403-M-TE2 | 2007->●KubotaV2403-M-T	A : 135,5 B : 83 H : 327	

FERRAFILTER®

Kubota

Air Filter

REPLACES		APPLICATION			DIMENSIONS	FAR 1635 M
KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	5970026112 RS3544 P772580 AF25292 C 17 337/2	●M--40-Series ●M-Series ●M40-Series ●M40N-Series ●M5001N-Series ●M5001-Series ●M5002-Series ●M60-Series ●ME-Series ●MGXIII-Series ●MGXIV-Series ●MGX-Series ●MX-Series	●M100GX●M100GXDTC●M100XDTC●M105GX●M105GX-III●M105GX-IV●M105S/SDSC/SDT/SHC/SHDC/XDTC●M108●M108S●M108SDT●M108SDTC●M108XDTC●M110GXI+II/GXDTC●M110XDTC●M5-092H(ROPS)●M5-092HC(CABINE)●M5-	●KubotaV2403-M-EA | 2002->2008●KubotaV2403-M-TE3 | 2009->2014●KubotaV3300-TE | ●KubotaV3300-TE | 1997->2005●KubotaV3300-TE | 1997->2010●KubotaV3300-TIE | 1997->2005●KubotaV3300T-IE | 2003->2010●	A : 161,5 B : 91,5 H : 354	

REPLACES		APPLICATION			DIMENSIONS	FAR 1635/3 M
FLEETGUARD	AF25292	●M**40-Serie ●M-Serie ●ME-Serie ●MX-Serie ●SVL-Serie	●M100GXDTC●M100XDTC●M105●M105S●M105SDSC●M105SDT●M105SHC●M105SHDC●M105XDTC●M108●M108S●M108SDTC●M108XDTC●M110GXDTC●M110XDTC●M8200/C/CCS●M8200DT●M8200DTC●M8200HD●M8200HDC●M8200SDNB●M82	●-> | ->●-> | 01/06->01/07●-> | 12/04->●KubotaV3300 | 01/99->●KubotaV3300-TIE | 01/99->●KubotaV3800-DI-TI | 12/04->●V2403-M-EAPN1G813-00001 | ->●V2403-M-TE3 | ->●V3300 | ->●V3300-TE | ->●V330	A : 161 B : 91,5 H : 354	

FERRAFILTER®

Kubota

Fuel filter

REPLACES		APPLICATION			DIMENSIONS	FSB 815
KUBOTA MANN FILTER	RG10823410 WK 842/3	●KX-Series(Minibagger/MiniExcava	●41-2Alpha●41-2SV●71-2Alpha	●-> | ●D1105-EBH-6 | ●D1505EB | 2001->2004	A : 82 F : 8 H : 170	

REPLACES		APPLICATION			DIMENSIONS	FEF 28
KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	1523143560 1523143563 1523143561 1523143562 1523143160 1523243160 1532143560 PF872 P502138 FF5104 P 33	●B-Serie ●B1000-Serie ●B2000-Serie ●B4000-Serie ●B5000-Serie ●B6000-Serie ●B7000-Serie ●B8000-Serie ●B9000-Serie ●F-Serie/FZ-Serie ●G/GL/GV-Serie ●K/KGP/KHP-Serie ●KH(Minibagger/MiniExcavators) ●ST-Serie	●008-2,008-3●2●2-HST●21●30●31●5●7●B1550D●B1550E●B1550HST-D/-E●B1700●B1700DT/E●B1700HST-D●B1750E/D●B1750HST-D/-E●B20●B2100DT●B2100HST-D●B2100HST-DB●B2150DT●B2150E●B2150HSE/HSD●B2400●	●-> | ->●D1005-D10 | 01/95->01/99●D1005-D10PN1G036-20001 | 01/95->01/99●D1105-D10 | 01/95->01/99●D1105-D10PN1G037-20001 | 01/95->01/01●D600 | ->●D640 | ->●D650-B | ->●D722 | 01/97->01/02●D722-	A : 29 B : 13 H : 86	

REPLACES		APPLICATION			DIMENSIONS	FEF 37 T
KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA BALDWIN FLEETGUARD MANN FILTER	1529143010 1529143012 1583143380 1583143381 1G31143380 PF9873 FF5468 P 4003	●KX-Series(Minibagger/MiniExcavators) ●L-Series ●L60-Series ●M--40-Series ●M-Series ●M40-Series ●M40N-Series ●M60-Series ●M6001-Series ●M6002-Series ●M700-Series ●M7001-Series ●M7002-Series ●ME-Series ●ME700-Series	●080-3●121-2●35(EU)●41-2●41-2S●45●520●520/B●61-2●61-2S●91●91-2●91-2S●L3301/HST(4WD)●L3560DT(4WD)/GST(4WD12 Speed)●L3560HST(4WDHydro)●L3560HSTC-C(4WDHydroCab)●L3901/HST(4WD)●L4060DT(4	●-> | ●D1105-BH-7 | ●D1105-BH6 | ●D1105-EBH-6 | ●D1105-EBH-7 | ●KubotaD1803-CR-E4 | 2013->●KubotaD1803-CR-E4 | 2014->●KubotaD722BH5 | 2008->●KubotaF2803-EA | 2001->2005●KubotaF2803-EA | 2003->	A : 34,7 B : 11 H : 70,5	

REPLACES		APPLICATION			DIMENSIONS	FEF 38
KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	1627143560 PF981 P502166 FF5259 P 45	●F-Series/FZ-Series(Front-mountMower) ●ST-Series ●STV-Series ●STW-Series	●F2400●FZ2100●FZ2400●ST-30●ST341/C●ST401/C/R●STA-25●STA-30●STA-35●STAlpha35/D●STV32●STV36●STV40●STW34/C●STW34D●STW37/C●STW40/C	●-> | ●-> | 2002->2005●KubotaD1105-FM | 1988->1997●KubotaD1503-M | 2006->2014●KubotaD1643 | 2002->2005●KubotaD1703-E-TVCS | 2014->●KubotaD1703-EU | 2003->●KubotaD1703-M | 2004->●KubotaD1703-M-E	A : 35 B : 11 H : 89	

REPLACES		APPLICATION			DIMENSIONS	FEF 45/1
KUBOTA BALDWIN	6A32059930 PF9911	●->		●-> | ->	A : 35 B : 5 D : 45,5 H : 53,7	

REPLACES		APPLICATION			DIMENSIONS	FEF 58
FLEETGUARD	FF5103	●KH-Serie(Minibagger/MiniExcavators)(İnşaatveMadenMakinaları) ●L-Serie(TarımMakinaları) ●M-Serie(TarımMakinaları)	●KH130●KH151●KH191●KHK151●L2250●L2250/GST●L2250DT●L2250F●L235●L2550●L2550/GST●L2550DT●L2550DTGST●L2550F●L2650DT●L2650DTGST●L2650F●L2650GST●L275●L2850●L2850DT●L2850F●L2850GST●L2850L●	●-> | ->●-> | 01/90->●-> | 01/94->●KUBOTA-3CYL | ->●KUBOTA-4CYL | ->●KUBOTA-4CYL | 01/92->●KUBOTA-D1803MEGST | ->●KUBOTA-F2302-DI-L | ->●KUBOTA-F2803EA | ->●KUBOTA-S2800D | 01/90->●KUBOTA-V19	A : 50 B : 20 H : 87	

REPLACES		APPLICATION			DIMENSIONS	FEF 58/1
KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	1522143160 15221431600 1552143160 1552143160 155214316 1552143760 1A00143160 PF717 P502161 FF5103 P 5006	●KC-Series(MiniDumpers) ●KH-Series(Minibagger/MiniExcavators) ●L-Series ●L02-Series ●L1-Series ●L10-Series ●L2-Series ●L30-Series ●L40-Series ●L4000-Series ●L50-Series ●M-Series ●M700-Series ●MK-Series ●MX-Series	●151●191●250HR-4●L1-421/DW/HDW●L1-501DW/HDW●L1802●L2-351HSTC●L2-421DT-C/HSTC●L2-501●L2-501DCN/DT/HSTC●L2-601/DT●L2250F/DT●L235F●L2550DT/DTGST/F●L2650DT/DW/GST●L2650F●L275/DT●L2850/D	●D1402-DI-AE | 1991->1993●KubotaD1102 | 1978->1985●KubotaD1102-A | 1991->1998●KubotaD1301-DA | 1979->1985●KubotaD1302-A | 1981->1985●KubotaD1302-DI-A | 1985->1991●KubotaD1402-DI-A | 1985->1991●K	A : 50 B : 21 H : 88,7	

REPLACES		APPLICATION			DIMENSIONS	FSF 77
KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	1522143080 1522143081 1522143170 1522143170 1522443010 1552143080 5471123410 BF940 P550127 FF5106 WK 812	●KH-Series(Minibagger/MiniExcavators) ●KX-Series(Minibagger/MiniExcavators) ●L-Series ●L02-Series ●L100-Series ●L1000-Series ●L2-Series ●L200-Series ●L2000-Series	●001.1D●008●008-1●012●014●015●016-4●016W●018-4●019-4●021●024●026●027-4●027-4●030●030-4●031●033●035●036●037-4●040●041●050●051●057-4●060●065●066●080-3●082●090●101●101-3●101-3Alpha●101-3	●-> | ●-> | 1994->1997●D1100BH | ●D1105-BH | ●D1105-BH-7 | ●D1105-BH6 | ●D1105-EBH-7 | ●D1105B4 | 1991->●D1105B4G | 1991->●D1105BH | 1998->2003●D1301BH | ●D1302 | ●D1402-BH-5 | ●D1402BH |	A : 76 B : 55,2 C : 62 G : M 20 x 1.5 H : 74	

FERRAFILTER®

Kubota

Fuel filter

REPLACES		APPLICATION			DIMENSIONS	FSF 87/1
KUBOTA	1545143560	●M-Series ●M30-Series ●M50-Series	●M5500/DT●M5950/C/DT/DTS/S●M6030DT●M6030DT Narrow/DTNB●M6950/C/DT/DTC/DTS/S●M7030●M7030DT(4WD)●M7030MDT/DT-NB●M7030Narrow●M7030SU/SUDT●M7500/DT/DT/ACL●M7950/DT●M7950S●M8030/DT/MDT●M8	●KubotaD3000-A | 1979->1984●KubotaD3200-2A | 1986->1998●KubotaD3200-2A | 1987->●KubotaD3200-A | 1983->1993●KubotaV4000 | 1986->1998●KubotaV4000-2A | 1983->1993●KubotaV4000-3A | 1986->1998●Kubota	A : 84 B : 19,2 C : 16 H : 72	
KUBOTA	7000014632					
KUBOTA	7000037500					
BALDWIN	BF825					
DONALDSON	P556245					
FLEETGUARD	FF138					
MANN FILTER	P 917 x					

REPLACES		APPLICATION			DIMENSIONS	FSF 811/4
KUBOTA	1663143560	●KX-Series(Minibagger/MiniExcavators) ●M--40-Series ●M-Series ●M40-Series ●M40N-Series ●M5001N-Series ●M5001-Series ●M5002-Series ●M60-Series ●M700-Series ●M80-Series ●ME-Series ●ME700-Series ●MGXIII-Series ●MGXIV-Series	●080-3●080-3a●080-3T●251●251-2●251Alpha●M100GX●M100GXDTC●M100GXIII●M100XDTC●M105GX●M105GX-III●M105GX-IV●M105S/SDSC/SDT/SHC/SHDC/XDTC●M108●M108S●M108SDT●M108SDTC●M108XDTC●M110/DT●M11	●-> | ●KubotaD722BH5 | 2008->●KubotaF2803-A | 1998->2004●KubotaF2803-EA | 2001->2005●KubotaF2803-EA | 2003->2010●KubotaF2803-EA-1 | ●KubotaF2803-EA-2Q | ●KubotaF2803-EA-E-TVCS | 2008->●KubotaF2	A : 82 B : 55,3 C : 61,5 G : 3 / 4 " - 16 H : 112,2	
KUBOTA	1G77243560					
KUBOTA	HH16643560					
KUBOTA	HH1G043560					
KUBOTA	W21ESF1660					
KUBOTA	W21ESF1G00					
BALDWIN	BF954					
DONALDSON	P502163					
FLEETGUARD	FF5172					
MANN FILTER	WK 7041					

REPLACES		APPLICATION			DIMENSIONS	FSF 816/1
BALDWIN	BF7954-D	●M-Series ●M40-Series ●M60-Series ●MGX-Series	●M100GX●M100GXDTC●M108SDTC●M110GXI+II/GXDTC●M128/X/XDT-C●M130XDTC●M6040/HDNB/DTH/DTHC/DTHNB●M6040DTN/Narrow●M6060DTH/DTHC●M6060HD/HDC●M7040/DTH/SUD/DTHQ/SUHD/DTH-C/DTHNBC●M7040DT/DT	●KubotaV3300-DIE2 | 2013->2016●KubotaV3307-CR-TE4 | 2013->2016●KubotaV3307-DI-TE3-1 | ●KubotaV3307-DI-TE3-1-Q | ●KubotaV3307-DI-TE3-E-CDIS | 2008->●KubotaV3307-DI-TE3-E-CDIS | 2009->2014●KubotaV3	A : 69 B : 21,9 D : 79 G : 3 / 8 " - 16 H : 135 I : 151,3	
FLEETGUARD	FS19972					
MANN FILTER	WK 8137					

REPLACES		APPLICATION			DIMENSIONS	FSF 912
KUBOTA	1J52143170	●M6001-Series ●M6002-Series ●M7001-Series ●M7002-Series ●MGXIII-Series ●MGXIV-Series ●MGX-Series ●R-Series(CompactWheelLoaders)	●430●M115GXDTCIV●M125GXDTCIV●M125GXDTSCIV●M125GXIII●M126GXDTC●M128GXI/II●M135GXI+II/GSX/XDT-C●M135GXIII●M6-122●M6-132●M6-142●M6121●M7-131Premium/KVT/POWERSHIFT●M7-131withoutAirCompr	●KubotaD1803-CR-TIE4-WL5 | 2019->●KubotaV6108-CR-TIE-F4 | 2018->●KubotaV6108-CR-TIE4 | 2012->2016●KubotaV6108-CR-TIE4 | 2018->●KubotaV6108-CR-TIEF4 | 2015->2018●KubotaV6108-CR-TIEF4 | 2016->●Kubo	A : 89,8 B : 55,2 C : 62 G : M 20 x 1.5 H : 126	
KUBOTA	HH1J043170					
BALDWIN	BF7538					
DONALDSON	P552561					
FLEETGUARD	FF5089					
MANN FILTER	WK 10 020					

Fuel filter

REPLACES		APPLICATION			DIMENSIONS	FSF 914/6
KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	HHV0051920 V062151920 BF7535 P550385 FF5159 WK 828	●KX-Series(Minibagger/MiniExcavators) ●R-Series(CompactWheelLoaders) ●U-Series(Minibagger/MiniExcavators)	●080-4●080-4Alpha(<=40556)●080-4Alpha(KBCK0804)●085●55-4●630●80-4a(40556+40557=>)	●KubotaV2607-CR-TE4Tier4 | ●KubotaV2607-DI | ●KubotaV2607CR | 2015->2018●KubotaV3307-CRT-EU6 | 2019->●KubotaV3307CR-TE4 | ●KubotaV3307CR-TE4 | 2013->2016●KubotaV3307CR-TE4 | 2016->2019	A : 93 B : 62,5 C : 70,5 G : 3 / 4 " - 16 H : 143,5 J : M 36 x 1.5	

FERRAFILTER®

Kubota

Hydraulic filter

REPLACES		APPLICATION			DIMENSIONS	FSO 910/13 H
KUBOTA	3A43182623	●L-Series ●L1-Series ●L2-Series ●L3000-Series ●M--40-Series ●M-Series ●M40-Series ●M40N-Series ●M60-Series ●M700-Series ●ME-Series ●RTV-Series(UtilityVehicle) ●ST-Series ●STV-Series ●Z300-Series(TurnMower)	●1211Zero●321/N/SZero●323Zero●326+IIZero●331Zero●L1361DT/HST●L1361F●L1361H●L1361T●L2800DT/F/DHV/DHW●L3200/DT●L3200/F/DT/HST●L3400HST(4WDHydro)/DT(4WDGear)/F(2WD)●L3700SUHSTP●L3800HS	●-> | ●-> | 2002->2005●KubotaD1005-E2-ZD-2 | 2007->●KubotaD1105-E4-ZD-2 | 2017->●KubotaD1305-E3-ZD | 2007->●KubotaD1403-M-E2A | 2004->2008●KubotaD1503-M | 2006->2014●KubotaD1503E-TVCS | 2011->20	A : 93 B : 81,5 C : 90 G : 1 - 1 / 8" - 16 H : 100	
KUBOTA	3A43182630					
KUBOTA	3A43182632					
KUBOTA	HH3A082623					
KUBOTA	HH3A082630					
KUBOTA	W21TSH3A00					
KUBOTA	W21TSH3A10					
MANN FILTER	WD 10 001 x					

REPLACES		APPLICATION			DIMENSIONS	FEO 48 H
KUBOTA	R141164930	●KX-Series(Minibagger/MiniExcavators) ●R-Series(CompactWheelLoaders) ●U-Series(Minibagger/MiniExcavators)	●042-4●057-4●065●080-3●080-3a●080-3T●080-4●080-4Alpha(<=405556)●082●085●420a●420S●430●48-4●520S●55●55-4●630●80-4a(40556+40557=>)	●-> | 2004->2013●D1503-M-T-E3 | ●KubotaD1803-CR-TE4 | 2017->●KubotaD1803-CR-TIE4-WL5 | 2019->●KubotaD722BH5 | 2008->●KubotaV2607-CR-TE4Tier4 | ●KubotaV2607-DI | ●KubotaV2607-DI | 2010->●KubotaV	A : 41,5 B : 21,2 H : 87	
KUBOTA	R141164930					
BALDWIN	PT8392					
DONALDSON	P550576					
FLEETGUARD	HF28836					
MANN FILTER	HD 47					

REPLACES		APPLICATION			DIMENSIONS	FEO 919/3 H
BALDWIN	PT9238	●KX-Serie(Minibagger/MiniExcavat	●101●101H●121-2●151●151H●161-2●U35	●-> | ->	A : 90,5 G : R 1" x 11 H : 198 J : M 5 x 0,8	
FLEETGUARD	HF28946					

REPLACES		APPLICATION			DIMENSIONS	FSO 812 H
KUBOTA	6795537710	●B1000-Serie(TarımMakinaları) ●B2000-Serie(TarımMakinaları)	●B1700DT●B1700E●B1700HST●B2100●B2100DT●B2400DT●B2400HSTD●B2410HSD●B2710HSD●B2910HSD	●D1005D10 | ->●D1105 | ->●D1105D10 | ->●D905-D10 | ->●V1305 | ->●V1505E | ->	A : 80 G : M 20 x 1.5 H : 122	
KUBOTA	HH67037710					
KUBOTA	W21TSH6700					
KUBOTA	W950115001					
BALDWIN	BT8902					

FERRAFILTER®

Kubota

Hydraulic filter

REPLACES		APPLICATION			DIMENSIONS	FSO 913/1 H
KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	32 70137950 R141163860 BT260 P556005 HF6005 W 935/1	●B2000-Series ●B8000-Series ●B9000-Series ●KH-Series(Minibagger/MiniExcavators) ●M6002-Series ●R-Series(CompactWheelLoaders) ●ST-Series	●008●008-2,008-3●420a●430●520a●B2150DT/E/HSE/HSD●B8200/D/E/HST/HST-D/HST-E●B9200D/E/HSD-TOW/HST-D/HST-E●M6-122●M6-132●M6-142●ST-30	●-> | 2004->2013●KubotaD1803-CR-TIE4-WL5 | 2019->●KubotaD850BH | ●KubotaD850BH | 1987->1991●KubotaD950-A-DT-M | 1983->1990●KubotaV1200-5B | 1988->1996●KubotaV1200-A | 1986->1990●KubotaV1505 | 19	A : 92,5 B : 62,5 C : 70,5 G : 1 - 1 / 8" - 16 H : 131	

REPLACES		APPLICATION			DIMENSIONS	FSO 917/14 H
		●M-Serie(TarımMakinaları) ●R-Serie(CompactWheelLoaders)	●420(LST)D1503-T●510NEWTYPE(LST)V2203-DI-BDW●510OLDTYPE(LST)V2203-BDW●520SV2203-M-ERP●520V2203●M100GXDTCV3800-CR-TIE4PN1J540-21001●M100XDTCV3800DICR-TIE3PN1J576-110001●M105SDSCV3800	●-> | ->●-> | 01/99->	A : 93 B : 62,6 C : 71 G : 1 - 1 / 8" - 16 H : 175,5	

REPLACES		APPLICATION			DIMENSIONS	FSO 917/26 H
KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	5220015320 HH52015320 BT305 P551348 HF35018 W 935/2	●M-Series ●MGX-Series ●R-Series(CompactWheelLoaders)	●420(LST)●510NEWTYPE(LST)●510OLDTYPE(LST)●520●520S●M100GX●M105S/SDSC/SDT/SHC/SHDC/XDTC●M108S●M108XDTC●M110/DT●M110FC/DTC●M110GXI+II/GXDTC●M110XDTC●M120DT●M120FC/DTC●M125X●M125XDT/XD	●D1503-T | ●KubotaF2803-A | 1998->2004●KubotaF5802-TE2 | 1999->2004●KubotaF5802-TE2 | 2002->2004●KubotaF5802-TE2 | 2004->2008●KubotaV2203-M-E3 | ●KubotaV3800-CR-E3-S2 | 2007->●KubotaV3800-CR-TIE	A : 93 B : 66,5 C : 72,5 G : 1 - 1 / 8" - 16 H : 173	

REPLACES		APPLICATION			DIMENSIONS	FSO 917/31 H
KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	3259038381 3396038380 3396082630 3396082631 3396082632 87300044 HH33082630 BT8488 P551779 HF35274 WD 10 002	●L-Series ●L02-Series ●L1-Series ●L10-Series ●L2-Series ●L30-Series ●L40-Series ●L4000-Series ●L50-Series ●L60-Series ●M--40-Series ●M-Series ●M40-Series ●M40N-Series ●M5001-Series	●L1-421/DW/HDW●L1-501DW/HDW●L2-351HSTC●L2-421DT-C/HSTC●L2-501●L2-501DCN/DT/HSTC●L2-602/HSTC●L2900DT/GST●L2900DTNEW●L2900F●L3010DT/F(Gear)/GST(GlideShift)/HST(Hydro)●L305●L3130/F/DT/	●KubotaD1301-DA | 1979->1985●KubotaD1503-L-A | ●KubotaD1503-L-A | 1994->●KubotaD1503-L-A | 1994->1999●KubotaD1503-L-AN | 1998->2002●KubotaD1503-MA-E | 2003->2007●KubotaD1703 | 2003->2007●KubotaD	A : 93 B : 81,5 C : 90 G : 1 - 1 / 8" - 16 H : 178	

Hydraulic filter

REPLACES		APPLICATION			DIMENSIONS	FSO 924 HMT
KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	3J02808961 BT758 P164384 HF6555 WH 980	●M6001-Series ●M7001-Series ●M7002-Series	●M6121●M7-131Premium/KVT/POWERSHIFT●M7-131withoutAirCompressor●M7-151withoutAirCompressor●M7-171Premium/KVT/S●M7-171withoutAirCompressor●M7132P-KVTwithAirCompressor/P/PC/S●M7152P-KV	●KubotaV6108-CR-TIE-F4 | 2018->●KubotaV6108-CR-TIEF4 | 2015->2018●KubotaV6108-CR-TIEF4 | 2018->	A : 95,7 B : 62,5 C : 70,5 G : 1 - 3 / 8" - 12 H : 247	

FERRAFILTER®

Kubota

Oil filter

REPLACES		APPLICATION			DIMENSIONS	FSO 66/1
KUBOTA	1585332430	●B02-Series ●B10-Series ●B1000-Series ●B20-Series ●B2000-Series ●B5000-Series ●B6000-Series ●B7000-Series ●B8000-Series ●BX-60Series ●BX-70Series ●BX-80Series ●BX-Series ●F80-Series ●G-Series(GardenTractor)	●1600EC●1600ECII●1800D●1830D●1850D●1860D●1870/1870-1●1880●2020G●2100●2110●2160●2230D●2250D●2260●231/C/D5-C/D5-R●2360●2370/2370-I●2380●2660●36-3●41-3●41-3S(>=55001)●41-3V(>=55001)●B1	●-> | ●D782-E | ●KohlerGH631 | 2010->●KubotaD1005-E-3D22 | 2008->2015●KubotaD1005-E3-BX | 2008->2013●KubotaD1105-D10 | 1995->1999●KubotaD1105-D18 | 2000->2007●KubotaD1105-E2-FM-2 | 2006->2007●K	A : 68 B : 56,9 C : 64,3 G : M 20 x 1.5 H : 66 BPV : 0,8 Bar ADV : Yes	
KUBOTA	HH15032430					
BALDWIN	B1400					
DONALDSON	P550461					
FLEETGUARD	LF3692					
MANN FILTER	W 67/1					

REPLACES		APPLICATION			DIMENSIONS	FSO 67/1
KUBOTA	1585399170	●G-Series(GardenTractor) ●KX-Series(Minibagger/MiniExcavators) ●T-Series(LawnTractor)	●36(H)●G1800/S●T1600H	●-> | ●KubotaD662 | 1989->2000●KubotaZ482 | 1990->1996	A : 67 B : 54 C : 62 G : M 20 x 1.5 H : 76 BPV : 1 Bar ADV : Yes	
FLEETGUARD	LF3925					
MANN FILTER	W 68					

REPLACES		APPLICATION			DIMENSIONS	FSO 67/6
KUBOTA	11249911210	●T-Series(LawnTractor) ●TG-Series(LawnTractor)	●1860G-48/1860GA-48/1860GAB-48●1860G-54●1860GA-54/1860GAB-54●T1460/S●T1560/S●T1700H●T1700HX●T1760/S●T1870/A	●KawasakiFC420V | 1997->2001●KawasakiFD501V | 1997->2001●KawasakiGH540V | ●KawasakiGH540V | 1990->1996●Kohler | 2002->2007●KubotaWG590V |	A : 66,5 B : 54 C : 62,4 G : 3 / 4 " - 16 H : 76 BPV : 1 Bar ADV : Yes	
BALDWIN	B33					
DONALDSON	P502015					
FLEETGUARD	LF3495					
MANN FILTER	W 68/3					

REPLACES		APPLICATION			DIMENSIONS	FSO 87
KUBOTA	1524132092	●B-Series ●B01-Series ●B02-Series ●B1-Series ●B10-Series ●B1000-Series ●B2-Series ●B20-Series ●B2000-Series ●B30-Series ●B4000-Series ●B50-Series ●B5000-Series ●B6000-Series ●B7000-Series	●005●007●008●008-2,008-3●012●021●024●030●031●035●036●041●050●051●10●10(EU)●10-3●1011Zero●1021Zero●10Alpha●14●18Zero●20-3●20-3Alpha●21●2200/D/E●221Zero●24●25-3●25-3Alpha●25FZero●25S●	●-> | ●-> | 1985->1992●D1105-BH-7 | ●D1105-E2-U25PN1J033-00001 | ●D1105-EBH-6 | ●D1105-EBH-7 | ●D1105B4 | 1991->●D1105B4G | 1991->●D662B4 | 1991->●D722BH | 1999->2002●D850 | ●D850-BH-W | ●D	A : 82 B : 58,5 C : 64,5 G : M 20 x 1.5 H : 75 BPV : 1 Bar ADV : Yes	
KUBOTA	1524132093					
KUBOTA	1524132094					
KUBOTA	1524132099					
KUBOTA	1524139092					
KUBOTA	1524132040					
KUBOTA	1524132091					
BALDWIN	B1421					
DONALDSON	P550716					
FLEETGUARD	LF3403					
MANN FILTER	W 811/80					

FERRAFILTER®

Kubota

Oil filter

REPLACES		APPLICATION			DIMENSIONS	FSO 88/3
DONALDSON MANN FILTER	P550162 W 87	●KX-Series(Minibagger/MiniExcavators) ●R-Series(CompactWheelLoaders)	●310/B/H●41H	●D1105-BH | ●V1305-RP | 1988->	A : 80 B : 54 C : 62 G : M 20 x 1.5 H : 88 BPV : 1 Bar ADV : Yes	

REPLACES		APPLICATION			DIMENSIONS	FSO 89
KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	1524132090 1584132431 1584132432 1584132439 1627132092 1627132093 HH15232432 B1425 P552849 LF3361 W 814/80	●B-Series ●B02-Series ●B1-Series ●B10-Series ●B1000-Series ●B2-Series ●B20-Series ●B2000-Series ●B30-Series ●B3000-Series ●B50-Series ●B5000-Series ●B6000-Series ●B7000-Series ●B8000-Series	●008-3●016-4●018-4●019-4●027-4●030-4●100HD●15(T4)●15-3●1600EC●1600ECII●17-3Alpha●1860-48●1860-54●1860A-48●1860A-54/1860AB-54●1860B-54●20●20-3Alpha●2100●2100EC/II●2120/S●21ECZero●217	●-> | ●-> | 1985->1992●-> | 1998->2003●-> | 2004->2008●D1105-BH | ●D1105-BH6 | ●D1105-BH9 | 2001->2004●D1105-EBH-6 | ●D1105BH | 1998->2003●D1105BH | 2002->2004●D1505EB | 2001->2004●D722 | 19	A : 80 B : 58,5 C : 64,5 G : M 20 x 1.5 H : 88 BPV : 1 Bar ADV : Yes	

REPLACES		APPLICATION			DIMENSIONS	FSO 98/1
FLEETGUARD	LF3682	●Engine ●KH-Serie(Minibagger/MiniExcavators)(İnşaatveMadenMakinaları) ●KX-Serie(Minibagger/MiniExcavators)(İnşaatveMadenMakinaları) ●L-Serie(TarımMakinaları) ●M-Serie(TarımMakinaları) ●R-Serie(CompactWheelLoaders) ●U-Serie	●->●KH130●KH60●KH65/66●KX121-3S●KX161-3●KX91-3S2●L2250DT●L2850GST●L2900●L345●L3450DT●L3450GST●L345W●L3650DT●L3650GST●L3750●L4150●L4850DT●M4500DT●M4500OC●M4950●M4950DT●M5030●R520S●U3	●-> | ->●KUBOTA-4CYL | ->●KUBOTA-6-158.5 | ->●KUBOTA-6CYL2598CC | ->●KUBOTA-D1402-BH4 | 01/91->●KUBOTA-D1703-M-E3 | ->●KUBOTA-F2302-DI-L | ->●KUBOTA-KUBOTA | ->●KUBOTA-S2800-A | ->●KUBOTA-V190	A : 92,5 B : 62,5 C : 70,8 G : 3 / 4 " - 16 H : 85,8 BPV : 0,8 Bar ADV : Yes	

REPLACES		APPLICATION			DIMENSIONS	FSO 99/6
KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	1528487211 1540232090 1540232091 1552132431 1552132430 1732132430 1732132431 B7152 P551268 LF3341 W 920/48	●KH-Series(Minibagger/MiniExcavators) ●KX-Series(Minibagger/MiniExcavators) ●M-Series ●M60-Series ●ME-Series ●MGXIII-Series ●R-Series(CompactWheelLoaders) ●RW-	●011●020●026●027●030●033●040●045●066●080-4Alpha(KBCK0804)●101●101-3Alpha4●101H(SN11313)●101H(SN11314)●121-3●151●151H(10610)●161-3●161-3R2●161-3S1●161-3S2●25●30●33●40●410/B●45●510/B●	●-> | ●D1302BH | ●D1402BH | ●D1402BH4 | ●D1402BH5 | ●KubotaD1803-M-E3-BH | 2014->●KubotaV2203-M-EBH-2 | ●KubotaV3300T-IE | 2003->2010●KubotaV3307-CRT-EU6 | 2019->●KubotaV3800-CR-TE4 | 2012->20	A : 92 B : 62,5 C : 70,3 G : 3 / 4 " - 16 H : 96,4 BPV : 0,8 Bar ADV : Yes	

FERRAFILTER®

Kubota

Oil filter

FSO 99/9

REPLACES		APPLICATION			DIMENSIONS
KUBOTA	1505632432	●KX-Series(Minibagger/MiniExcavators) ●L-Series ●L02-Series ●M--40-Series ●M-Series ●M40-Series ●M4002-Series ●M4003-Series ●M40N-Series ●M50-Series ●M5001N-Series ●M5001-Series ●M5002-Series ●M60-Series ●M7001-Series	●057-4●065●080-3●080-3a●080-3T●080-4●080-4Alpha(<=40556)●082●085●101-3●101-3(>=70001)●101-3Alpha●101-3Alpha(>=70001)●101-3Alpha2●101-3Alpha3●251●251-2●251Alpha●30-3Alpha2●35●35-3●35	●-> | ●D1503-M | 2005->2008●D1503-M-E2BH-2-N | ●D1503-M-EBH-2 | ●D1803-M | ●KubotaD1302-DI-A | 1985->1991●KubotaD1503-M-EBH-1-EC | 2005->2008●KubotaD1503-M-EBH-2-EC | ●KubotaD1503-M-EBH-4-EC-N	A : 93 B : 62,5 C : 70,5 G : 3 / 4 " - 16 H : 96,7 BPV : 1,2 Bar ADV : Yes
KUBOTA	1609831291				
KUBOTA	1C01032430				
KUBOTA	1C02032430				
KUBOTA	HH1C032430				
KUBOTA	HH1CO32430				
KUBOTA	W21ES01C00				
BALDWIN	B7298				
DONALDSON	P550318				
FLEETGUARD	LF3376				
MANN FILTER	W 920/7				



FSO 810

REPLACES		APPLICATION			DIMENSIONS
KUBOTA	6602136060	●B01-Series ●B1-Series ●B10-Series ●B1000-Series ●B20-Series ●B2000-Series ●B30-Series ●B3000-Series ●B4000-Series ●B50-Series ●B6000-Series ●B7000-Series ●F-Series/FZ-Series(Front-mountMower) ●F60-Series(Frontmäher/Front-mountmower) ●F80-Series	●2100●2110●2160●B1550D/E/HST-D/-E●B1700/D/F●B1700/DT/E/HST-D●B1710●B1750E/D/HST-D/-E●B2100/D/DT/H●B2301/HSD●B2400/HD/HST-D/HST-E●B2410/D/DB/HDB/H/HSE/HSD/HSDB●B2530/C/D/DC/HDB/HDBC●	●-> | 2002->2005●KohlerGH630 | 2003->2007●KohlerGH680 | 2003->2007●KubotaD1005-D10 | 1995->1999●KubotaD1005-E-D16 | 2000->2003●KubotaD1005-E-D16 | 2004->2007●KubotaD1005-E-FM | 1997->2005●Kubota	A : 82 B : 56 C : 64,5 G : 3 / 4 " - 16 H : 102,5 ADV : Yes
KUBOTA	HH66036060				
BALDWIN	B113				
DONALDSON	P550711				
FLEETGUARD	LF3434				
MANN FILTER	W 7041				



FSO 910/5

REPLACES		APPLICATION			DIMENSIONS
MANN FILTER	W 920/80	●B-1000-Serie ●B-2000-Serie ●KH(Minibagger/MiniExcavators) ●KX(Minibagger/MiniExcavators) ●L1000-Serie ●L2000-Serie ●L3000-Serie ●L4000-Serie ●R-Serie(CompactWheelLoaders) ●RW-Serie	●101●101H●11●121-3●151●151H●161-3●161-3R2●161-3S1●161-3S2●20●25●26●27●30●33●40●410/B●45●510/B●60●66●71●90●B1902●B2201●L1500●L1501●L1511●L1801●L1802●L2000●L2002●L2202●L2402●L2600●L26	●-> | ->●-> | 01/78->01/85●-> | 01/82->01/88●D1302 | ->●D1302BH | ->●D1402BH | ->●D1402BH4 | ->●D1402BH5 | ->●D1403-AE | 01/99->●D1503-ELA | 01/99->●V1500BWD | ->●V1502B4 | 01/91->●V1702 |	A : 93 B : 62,5 C : 70,5 G : 3 / 4 " - 16 H : 97 BPV : 1 Bar ADV : Yes



FSO 914/28

REPLACES		APPLICATION			DIMENSIONS
KUBOTA	1521132431	●KH-Series(Minibagger/MiniExcavators) ●L-Series ●M-Series ●M30-Series ●M50-Series ●R-Series(CompactWheelLoaders)	●018●028●090●10(51042)●10(SN51042->)●170L●191●520S●L345/W●L4150DT-Narrow/F/DT●M4000●M4030/DT●M4030SU/TF●M4950/DT●M5030/DTL/F/L/MDT/MDTL/MF/SU/SUMDT/V	●-> | ●D1101 | ●KubotaF2302-DI-2 | 1984->1990●KubotaF2402-DI-A | 1988->1998●KubotaS2200-A | 1976->1983●KubotaS2602-DI-A | 1986->1989●KubotaS2800-A | 1983->1993●KubotaS2802-DI-A | 1986->1996●Kub	A : 92,8 B : 62,1 C : 70,3 G : 3 / 4 " - 16 H : 141 BPV : 2,5 Bar ADV : Yes
KUBOTA	1540232430				
KUBOTA	7000014647				
BALDWIN	B114				
DONALDSON	P550168				
FLEETGUARD	LF3402				
MANN FILTER	W 940				



FERRAFILTER®

Kubota

Oil filter

REPLACES		APPLICATION			DIMENSIONS	FSO 1013/2
KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	7000057500 BT348 P553411 LF682 W 1140	●M-Series ●M6001-Series ●M6002-Series ●M7001-Series ●M7002-Series ●MGXIII-Series ●MGXIV-Series ●MGX-Series	●M115GXDTCIV●M125GXDTCIV●M125GXDTSCIV●M125GXIII●M126GXDTC●M126XDTC/XDTPC●M128/X/XDT-C●M130XDTC●M135GXI+II/GSX/XDT-C●M135XDTC●M6-122●M6-132●M6-142●M6121●M7-131Premium/KVT/POWERSHIFT●	●KubotaV6108-CR-TIE-F4 | 2018->●KubotaV6108-CR-TIE4 | 2018->●KubotaV6108-CR-TIEF4 | 2015->2018●KubotaV6108-CR-TIEF4 | 2018->●KubotaV6108-CR-Tier4F | 2017->●KubotaV6108-EB3-QB | 2009->2014●KubotaV	A : 108 B : 62,5 C : 70,5 G : 3 / 4 " - 16 H : 136 BPV : 2,5 Bar ADV : Yes ASV : Pipe	

REPLACES		APPLICATION			DIMENSIONS	FSO 1017/6
KUBOTA KUBOTA BALDWIN DONALDSON FLEETGUARD MANN FILTER	7000014652 HH16032430 BT347 P551603 LF3347 W 8005	●M-Series ●M30-Series ●M50-Series ●M700-Series ●M80-Series ●MGXIII-Series ●MGX-Series	●M100XDTC●M110FC/DTC●M115GXIII●M120DT●M120FC/DTC●M125GXIII●M125XDT/XDTC●M128/X/XDT-C●M128GXI/II●M135GXI+II/GSX/XDT-C●M135GXIII●M5500/DT●M5700/DT/DTC/HDC/HDF/DTH/Narrow●M5700DT/SDNar	●KubotaD3000-A | 1979->1984●KubotaD3200-1A | 1986->1998●KubotaD3200-2A | 1986->1998●KubotaD3200-2A | 1987->●KubotaD3200-A | 1983->1993●KubotaF2803-A | 1998->2004●KubotaF2803-EA | 2000->2005●Kubo	A : 108 B : 63 C : 70,5 G : 3 / 4 " - 16 H : 171 BPV : 1 Bar ADV : Yes ASV : Pipe	



Reliable brand for filtration...



www.ferrafilter.com

Fabrika / Factory

FERRA FİLTRE SANAYİ VE TİCARET A.Ş.
Osmaniye Organize Sanayi Bölgesi Vali C. Cerrah Bulvarı No : 4 Toprakkale
Osmaniye / TURKEY
Email: info@ferrafilter.com
Telefon : +90 328 790 22 22 FAX : +90 328 790 22 33

facebook twitter Linked in